

12

TN NO: N-1627

TITLE: INTERACTION OF ANCHORS WITH SOIL AND ANCHOR DESIGN

AUTHOR: Robert J. Taylor

DATE: April 1982

SPONSOR: Naval Facilities Engineering Command

PROGRAM NO: YF59.556.091.01.205

NOTE

NAVAL CIVIL ENGINEERING LABORATORY
PORT HUENEME, CALIFORNIA 93043

Approved for public release; distribution unlimited.

DTIC
ELECTE
S JUL 7 1982 D
D

82 07 07 019

AD A116597


TECHNICAL

DTIC FILE COPY

METRIC CONVERSION FACTORS

Approximate Conversions to Metric Measures				Approximate Conversions from Metric Measures			
When You Know	Multiply by	To Find	Symbol	When You Know	Multiply by	To Find	Symbol
LENGTH							
inches	*2.5	centimeters	cm	millimeters	0.04	inches	in
feet	30	centimeters	cm	centimeters	0.4	inches	in
yards	0.9	meters	m	meters	3.3	feet	ft
miles	1.6	kilometers	km	meters	1.1	yards	yd
AREA							
square inches	6.5	square centimeters	cm ²	kilometers	0.6	miles	mi
square feet	0.09	square meters	m ²	square centimeters	0.16	square inches	in ²
square yards	0.8	square meters	m ²	square meters	1.2	square yards	yd ²
square miles	2.6	square kilometers	km ²	square kilometers	0.4	square miles	mi ²
acres	0.4	hectares	ha	hectares (10,000 m ²)	2.5	acres	
MASS (weight)							
ounces	28	grams	g	grams	0.035	ounces	oz
pounds	0.45	kilograms	kg	kilograms	2.2	pounds	lb
short tons (2,000 lb)	0.9	tonnes	t	tonnes (1,000 kg)	1.1	short tons	
VOLUME							
teaspoons	5	milliliters	ml	milliliters	0.03	fluid ounces	fl oz
tablespoons	15	milliliters	ml	liters	2.1	pints	pt
fluid ounces	30	milliliters	ml	liters	1.06	quarts	qt
cups	0.24	liters	l	liters	0.26	gallons	gal
pints	0.47	liters	l	cubic meters	35	cubic feet	ft ³
quarts	0.95	liters	l	cubic meters	1.3	cubic yards	yd ³
gallons	3.8	liters	l	TEMPERATURE (exact)			
cubic feet	0.03	cubic meters	m ³	°C	9/5 (then add 32)	Fahrenheit temperature	°F
cubic yards	0.76	cubic meters	m ³	TEMPERATURE (exact)			
			°F	subtracting 32)	9/5	Celsius temperature	°C

*1 in = 2.54 (exactly). For other exact conversions and more detailed tables, see NBS Misc. Publ. 286, Units of Weights and Measures, Price \$2.25, SD Catalog No. C13.10.286.



Unclassified

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1 REPORT NUMBER TN-1627	2 GOVT ACCESSION NO. DN987005	3 RECIPIENT'S CATALOG NUMBER
4 TITLE (and Subtitle) INTERACTION OF ANCHORS WITH SOIL AND ANCHOR DESIGN		5 TYPE OF REPORT & PERIOD COVERED Final; Jan 77 - Jan 81
		6 PERFORMING ORG REPORT NUMBER
7 AUTHOR(s) Robert J. Taylor		8 CONTRACT OR GRANT NUMBER(s)
9 PERFORMING ORGANIZATION NAME AND ADDRESS NAVAL CIVIL ENGINEERING LABORATORY Port Hueneme, California 93043		10 PROGRAM ELEMENT PROJECT, TASK AREA & WORK UNIT NUMBERS 62759N; YF59.556.091.01.205
11 CONTROLLING OFFICE NAME AND ADDRESS Naval Facilities Engineering Command Washington, DC 22332		12 REPORT DATE April 1982
		13 NUMBER OF PAGES 44
14 MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)		15 SECURITY CLASS (of this report) Unclassified
		15a DECLASSIFICATION DOWNGRADING SCHEDULE
16 DISTRIBUTION STATEMENT (of this Report) Approved for public release; distribution unlimited.		
17 DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18 SUPPLEMENTARY NOTES		
19 KEY WORDS (Continue on reverse side if necessary and identify by block number) Anchors, site selection, ocean soils, deadweight anchors, direct-embedment anchors, drag-embedment anchors, pile anchors.		
20 ABSTRACT (Continue on reverse side if necessary and identify by block number) The report provides a practical up-to-date guide that enables the practicing engineer to select and size common anchor types, including direct-embedment anchors, deadweight anchors, drag-embedment anchors, and pile anchors. For each anchor type, the report includes site survey recommendations, a brief description of various anchors within each anchor category, methods for determining anchor performance, and, in certain cases, continued		

DD FORM 1 JAN 73 1473 EDITION OF 1 NOV 65 IS OBSOLETE

Unclassified

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

Unclassified

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

20. Continued

suggestions for improving poor anchor behavior. Sources for additional information are suggested where the treatment of a broad topic is necessarily limited.

Library Card

Naval Civil Engineering Laboratory
INTERACTION OF ANCHORS WITH SOIL AND ANCHOR
DESIGN (Final), by Robert J. Taylor
TN-1627 44 pp illus April 1982 Unclassified

1. Anchors 2. Site selection I. YF59.556.091.01.205

The report provides a practical up-to-date guide that enables the practicing engineer to select and size common anchor types, including direct-embedment anchors, deadweight anchors, drag-embedment anchors, and pile anchors. For each anchor type, the report includes site survey recommendations, a brief description of various anchors within each anchor category, methods for determining anchor performance, and, in certain cases, suggestions for improving poor anchor behavior. Sources for additional information are suggested where the treatment of a broad topic is necessarily limited.

Unclassified

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

FOREWORD

This report was prepared for presentation at "Recent Developments in Ocean Engineering," sponsored by the University of California at Berkeley in January 1981. It was written in outline format to provide a practical up-to-date guide for the practicing engineer to enable selection and sizing of common anchor types including direct embedment anchors, deadweight anchors, drag embedment anchors, and pile anchors.

For each anchor type, the report includes site survey recommendations, briefly describes various anchors within each anchor category, presents methods for determining anchor performance and, in certain cases, suggests practical options for improving poor anchor behavior.

The topic of anchor design is broad, and this report does not pretend to provide complete solutions for all anchor selection and design problems. However, it does provide state-of-practice solutions to most general anchoring problems and makes the designer more aware of his options and the limitations of each anchor type. For complex or critical anchoring applications, the reader is referred to sources of information and references that are provided throughout the report.

A majority of the information presented in this report was taken from published and unpublished reports by the Foundation Engineering Division of the Naval Civil Engineering Laboratory under the sponsorship of the Naval Facilities Engineering Command and the Department of Energy.

Accession For	
NTIS GRA&I	<input checked="" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By _____	
Distribution/ _____	
Availability Codes	
Dist	Avail and/or Special
A	

DTIC
COPY
INSPECTED
2

CONTENTS

	Page
SITE SURVEY	1
GENERAL FEATURES OF VARIOUS ANCHORS	7
PLATE ANCHORS	8
DRAG EMBEDMENT ANCHORS	17
DEADWEIGHT ANCHORS	25
PILE ANCHORS	33
ACKNOWLEDGMENTS	40
REFERENCES	41

SITE SURVEY

A. Site Survey Requirements

- Requirements differ according to:

Anchor type [Pile, Deadweight, Drag, Embedment]
Loading condition [Static, Dynamic]
Soil type [Sand (cohesionless), Clay (cohesive)]
Mooring use [Manned, Unmanned]

Minimum Recommended Site Survey Requirements

Required Site Information*

Anchor Type	Non-Critical Mooring	Critical Mooring
Deadweight	General seafloor type (mud, clay, sand, rock).	Seafloor type, depth of sediment, areal variability, estimate of soil cohesion, friction angle, scour potential.
Drag Embedment	Seafloor type.	Seafloor type and strength, (approximate) depth to rock, stratification in upper 10' to 30' (depending on soil type), areal variability.
Plate Anchor	Seafloor type; depth to rock; o Use estimated properties provided or other available info.	Engineering soil data to expected embedment depth (soil strength, sensitivity, density, grain size, origin, depth to rock), additional data required for dynamic analysis.
Pile Anchor	Sediment type, depth of sediment. o Use estimated properties provided or other available info.	Engineering soil properties to full embedment depth (soil strength, sensitivity, grain size, origin, density), soil modulus of subgrade reaction for laterally loaded piles.

*Geologic literature survey suggested for all situations to help define soil type and existence of seafloor anomalies.

B. Sediment Property Determination

- Variety of tools exist to acquire quantitative or qualitative data.

Static, dynamic penetrometers, in-situ
vane shear device, corers, grab samplers

Sub-bottom profiling
side scan sonar

[Refer to Lee and Clausner (1979) - Soil Sampling Techniques]

- Information/Data-Sources

Lamont-Doherty Geological Observatory of Columbia University, Palisades,
N. Y. 10964

National Geophysical and Solar-Terrestrial Data Center, Environmental Data
Service, National Oceanic and Atmospheric Administration, Boulder, Colo. 80302

Chief of Operations Division, National Ocean Survey, NOAA, 1801 Fairview
Avenue, East Seattle, Wash. 98102

Chief of Operations Division, National Ocean Survey, NOAA 1439 W. York
Street, Norfolk, Va. 23510

Naval Oceanographic Office, Code 3100, National Space Technology Laboratories,
NSTL Station, Miss. 39522

Scripps Institution of Oceanography, La Jolla, Calif. 92093

Chief Atlantic Branch of Marine Geology, United States Geological Survey,
Bldg. 13, Quissett Campus, Woods Hole, Mass. 02543

Chief Pacific Arctic Branch of Marine Geology, United States Geological
Survey, 345 Middle Road, Menlo Park, Calif. 94025


Woods Hole Oceanographic Institution, Woods Hole, Mass. 02543

C. Sediment Property Estimation

(When detailed physical survey not practical)

- Determine whether sediments are:

Terrigenous (land-derived) sediments or pelagic
(ocean-derived) sediments (e.g., pelagic clay, oozes).



Ocean sediment distribution

1. Terrigenous Sediment Properties

- Assume all continental shelves and slopes are terrigenous.
- Typically complex and varied sediment type particularly, near-shore, glaciated areas, high current areas.
- Refer to National Ocean Survey charts to determine whether sand or mud (cohesive).


Sand

If nearshore and a "grab" sample is available for grain size determination, safe values of ϕ and γ_b are:

Soil Description	Friction Angle, ϕ (deg)	Buoyant Unit Weight, γ_b/m^3 (lb/ft ³)
Sandy silt	20	880 (55)
Silty sand	25	880 (55)
Uniform sand	30	880 (55)
Well-graded sand	35	960 (60)

For-locations classed as Abyssal Plains properties for turbidites are appropriate.

Proximal \sim < 30 miles from shore
 Distal \sim > 30 miles from shore



Typical strength profile - turbidites.


Mud

If sediment is mud (cohesive) this provides a lower bound for a normally consolidated sediment.

If site is near river mouth, Miss., Nile, Amazon, etc., mud probably underconsolidated (Young - not yet in equilibrium with wt overlying soil, may be limited strength buildup with depth. Consult an expert for design advice.


Much of the nearshore is overconsolidated (greater past overburden than presently existing) usually a desirable anchoring situation. Locations (e.g., glaciated areas, high current areas, tops of rises, passages).

Unusually strong overconsolidated sediment could lead to less conservative design (long-term loading).




2. Deep Ocean (Pelagic) Sediment Properties

If deep ocean site is not an abyssal plain, determine if depth is above or below Calcite Compensation Depth (CCD).




Topography of the calcite compensation depth (CCD). Calcareous sediments are found only in those locations where actual water depth is less than the CCD; numbers on contours denote kilometers below sea surface

If above the CCD - sediment probably calcareous.
 If below the CCD - sediment probably pelagic clay.




Typical profiles - calcareous ooze.



Typical profile - pelagic clay.

If location is classed as siliceous ooze

Whenever possible consult experts at a nearby oceanographic institution for property data.



Typical profile - siliceous ooze.

D. Hazardous/Unusual Seafloor Conditions

- If these conditions are encountered or anticipated, caution is necessary
- Design possible, but requires more detailed procedures than presented

Examples of Hazardous/Unusual Seafloor Conditions

- Submarine lava flows occupying a relatively small and irregular area.
- Small sediment channels, local extreme bottom slopes, cliff-like topography, or giant seafloor ripples.
- Erratics from ice-deposited glacial detritus.
- Metallic nodules or "pavement" formations above soft sediments.
- Sloping seafloor greater than 10 degrees.
- Deep ocean siliceous ooze (>30% biogenic and siliceous).
- Clean calcareous ooze (>60% biogenic and calcareous).
- Sensivity >6 in a cohesive soil.
- Cohesive soil strength varying by more than 50% or + 100% from typical profiles presented.
- Unconsolidated or very high void ratio clays with c/p values near 0.1-0.15.
- Thin sediment layer above rock.
- Layered seafloors - soft sediment over stiff/dense sediment or vice versa.

GENERAL FEATURES OF VARIOUS ANCHORS

Deadweight Anchor

Large vertical reaction component, permitting shorter mooring line scope
 No setting distance
 Reliable holding force, because most holding force due to anchor mass
 Simple, on-site constructions feasible, tailored to task
 Size limited only by load-handling equipment
 Economical; weighting material readily available
 Reliable on thin sediment cover over rock
 Mooring line connection easy to inspect and service
 Good energy absorber when used in conjunction with "non-yielding" anchors (i.e., piles, embedded plate anchors)
 Good reaction to vertical load components; works well in combination with drag embedment anchors permitting short mooring line scopes
 Lateral load resistance low compared to other anchor types
 Usable water depth reduced; deadweight can be undesirable obstruction

Drag Embedment Anchor

Broad range of anchor types and sizes available
 High capacity (greater than 100,000 lb) achievable
 Standard off the shelf equipment
 Broad use experience
 Can provide continuous resistance even though maximum capacity exceeded
 Anchor is recoverable
 Usable with wire or chain mooring lines
 Anchor does not function in lithified seafloors
 Anchor behavior erratic in layered seafloors
 Low resistance to uplift, therefore, large line scopes required to cause near horizontal loading at seafloor
 Penetrating/Dragging anchor can damage pipelines, cables, etc.

Plate Anchor

High capacity (greater than 100,000 lb) achievable
 Resists uplift as well as lateral loads enabling short scope moorings
 Anchor dragging eliminated
 Higher holding capacity to weight ratio than any other type of anchor
 Handling is simplified due to relatively light weight
 1.* Anchors can function on moderate slopes and in lithified seafloors
 1.* Installation is simplified due to possibility of instantaneous embedment or seafloor contact
 Accurate anchor placement possible
 Does not protrude above seafloor
 2,3,4* Can accommodate layered seafloors or seafloors with variable resistance because of continuous power expenditure during penetration
 2,3,4* Penetration is controlled and can be monitored
 Susceptible to cyclic load strength reduction when used in taut moorings in loose sand, coarse silt seafloors
 For critical moorings, soil engineering properties required
 Anchor plate typically not recoverable
 1.* Special consideration needed for ordnance
 1.* Anchor cable susceptible to abrasion/fatigue
 1.* Gun system not generally retrievable in deep water (>1,000 ft)
 2,3,4* Surface vessel must maintain position during installation
 2,3* Operation limited to sediment seafloors

Pile Anchor



High capacity (greater than 100,000 lb) achievable
 Resists uplift as well as lateral loads permitting use with short mooring line scopes
 Anchor setting not required
 Anchor dragging eliminated
 *Short mooring line scopes permit use in areas of limited sea room or where minimum vessel excursions are required
 Drilled and grouted piles especially suitable for hard coral or rock seafloor
 Does not protrude above seafloor
 Driven piles cost competitive with other high capacity anchors when driving equipment is available
 Drilled and grouted piles incur high installation costs and require special skills and installation equipment
 Wide range of sizes and shapes are possible (pipe, structural shapes)
 Field modifications permit piles to be tailored to suit requirements of particular applications
 *Taut moorings may aggravate ship response to waves (low resilience)
 *Taut lines and fittings must continually withstand high stress levels
 Costs increase rapidly in deeper water or exposed locations where special installation vessels are required
 Special equipment (pile extractor) required to retrieve or refurbish the mooring
 More extensive site data is required than for other anchor types
 *True for any taut mooring.

- *1. Propellant-embedded anchor
- *2. Screw-in anchor
- *3. Vibrated-in anchor
- *4. Driven Anchor

PLATE ANCHORS

A. Plate Anchors - Summary of Types (Refer to Taylor et al. (1975))

Propellant-Embedded Anchor




Current Developments

Primarily U. S. Navy developed CEL 10k, 20k, 100k, SUPSALV 100k, 300k - Refers to normal long term capacity in soft seafloor.


- 100k anchor commercially available

Driven Anchor



Navy Umbrella Pile Anchor (current work in U. K.)

Menard Rotating Plate Anchor



Screw (Auger) Anchor




-One or more helices screwed into the ground from surface or at seafloor.

Auger pin anchor





Vibrated Anchor

Anchor at base of long slender shaft, vibrated into the seafloor; plate is "keyed" to operating position.

Jetted-In Anchors




Hydropin Anchor (National Eng. Lab. U.K.)



Royal Dutch shell jetted anchor (Netherlands)

B. Plate Anchor Failure Definitions



C. Plate Anchor Design Loading Conditions

Static { Short-Term Loading - An increasing load to failure such that in fine-grained soils drainage does not occur.
Long-Term Loading - Uniform static load where full drainage occurs.

- Dynamic { Impulse Loading - Non-rhythmic loads > static capacity, < 10 seconds in duration - sands; < 10 minutes duration - clays.
Cyclic Loading - Repetitive loading with double amplitude magnitude > 5% static capacity.
Earthquake Loading - Cyclic loading induced to the entire soil mass by earthquake energy.

D. Plate Anchor Design Process (Refer to Beard, 1980)

1. Site Survey: Determination of hazardous/unusual condition, soil property selection, soil type determination.
2. Determine Anchor Embedment Depth
 - a. Control embedded anchors (e.g., driven, jetted, vibrated, screwed).
 Depth = f/soil type, strength, plate, size, equipment limitations.
 - b. Dynamically embedded anchors (propellant-embedded)

Cohesive soil
 Calculate by method of True (1976)

Cohesionless soil - Penetration prediction schemes are poor.

Calculated Penetrations for CEL Clay Flukes

Estimated Penetrations for CEL Sand Flukes

Soil Type	Anchor Penetration, m (ft) for --			
	300K	100K	20K	10K
Soft basin soil	19.5 (64)	15.9 (52)	10.7 (35)	7.6 (25)
Distal turbidite (low)	17.4 (57)	13.1 (43)	8.2 (27)	5.8 (19)
Distal turbidite (high)	14.9 (49)	11.9 (39)	7.9 (26)	5.8 (19)
Proximal turbidite	12.5 (41)	10.1 (33)	7.0 (23)	5.2 (17)
Calcareous ooze (deep water)	22 (72)	18.3 (60)	11.9 (39)	8.2 (27)
Course calcareous ooze (low)	19.2 (63)	16.5 (54)	10.7 (35)	7.6 (25)
Course calcareous ooze (high)	15.2 (50)	12.8 (42)	8.2 (27)	5.8 (19)
Siliceous ooze	24.1 (79)	19.8 (65)	13.1 (43)	9.2 (30)
Pelagic clay (low)	24.7 (81)	20.7 (68)	14.3 (47)	10.1 (33)
Pelagic clay (high)	19.2 (63)	15.9 (52)	11.3 (37)	8.2 (27)


Anchor	Anchor Penetration, m (ft) in --		
	Loose Sand ^a	Medium Dense Sand	Dense Sand ^c
CEL 10K sand/coral fluke	3.8 (12.5)	3.4 (11)	3.1 (10)
CEL 20K sand/coral fluke	5.2 (17)	4.9 (16)	4.6 (15)
CEL 100K sand/coral fluke	7.6 (25)	7.0 (23)	6.4 (21)
CEL 300K universal fluke	9.2 (30)	8.2 (27)	7.6 (25)

^a φ = 30 degrees; γ_t = 1,760 kg/m³ (110 lb/ft³)

^b φ = 35 degrees; γ_t = 1,920 kg/m³ (120 lb/ft³)

^c φ = 40 degrees; γ_t = 2,080 kg/m³ (130 lb/ft³)

c. Anchor Keying



Plates embedded edgewise are "keyed" to assume horizontal orientation.

CEL propellant anchors key according to:

$$D_{(\text{cohesive})} = D_p - 2L \quad (L = \text{fluke length})$$

$$D_{(\text{cohesionless})} = D_p - 1.5L$$

3. Determine loading condition, calculate capacity.

- a. Short-term static holding capacity (no drainage).

$$F_{st} = \underbrace{A(c \bar{N}_c f + \gamma_b D \bar{N}_q)}_{\substack{\text{After Vesic (1969) \\ with disturbance \\ correction factor \\ (f) by Valent (1978)}}} \overbrace{(0.84 + 0.16 B/L)}^{\substack{\text{Shape factor} \\ \text{(Skempton, 1951)}}$$

where F_{st} = Short-term holding capacity

A = Projected fluke area

c = Soil cohesion

f = Disturbance correction factor

= 0.8 - terrigenous silty-clays, clayey-silts

= 0.7 - pelagic clays

= 0.25 - calcareous ooze (validity of this factor in doubt)

γ = Buoyant unit weight of soil



D = Plate embedment depth

B = Plate width

L = Plate length

\bar{N}_c = Short-term holding capacity factor-cohesive soil

\bar{N}_q = Holding capacity factor for drained or frictional condition



$$F_{st} \text{ (Cohesive soil)} - \bar{N}_q = 1$$

Neglect $\gamma_b D \bar{N}_q$ term

$$F_{st} \text{ (Cohesive soil)} = A (s_u \bar{N}_c f) (0.84 + 0.16 B/L)$$

$$F_{st} \text{ (Cohesionless soil)} c = s_u = 0$$

$$F_{st} \text{ (Cohesionless soil)} = A \gamma_b D \bar{N}_q (0.84 + 0.16 B/L)$$

Short-Term Capacity Sloping Seafloors

Refer to Kulhawy et. al., (1978).

Short-Term Capacity Laterally Loaded Plates

Refer to Neely et. al., (1973).

- Plate anchor capacity is enhanced with lateral loading.
- For propellant anchors, keying distance is minimized.

b. Long-Term Static Holding Capacity (full drainage)

- Time to full drainage = f (permeability load, drainage path, anchor size, shape, etc.)

Cohesionless soil - drainage almost immediate

$$F_{lt} \text{ (cohesionless soil)} = F_{st}$$

Cohesive soil - long-term capacity governed by drained strength parameters: friction angle, ϕ , and cohesion intercept c .

$$F_{lt} \text{ (cohesive soil)} = A(c' \bar{N}'_c + \gamma_b D \bar{N}_q)(0.84 + 0.16 B/L)$$


F_{lt} = Long-term holding capacity

c' = Soil cohesion intercept

$A_1 \gamma_b, B_1 L$ = Refer to short-term section

\bar{N}_q = Holding capacity factor drained/frictional condition (Refer to short-term section)

\bar{N}'_c = Long-term holding capacity factor for cohesive soil



Loose/soft seafloors - failure associated with relatively large displacements; reduce c' , ϕ by 1/3. $\bar{c} = 2/3c'$, $\bar{\phi} = \tan^{-1}(\tan 2/3 \phi)$

Creep rupture - cohesive soil - increasing rate of shear until failure occurs (poorly understood phenomenon)

- Problem appears minimal for calcareous ooze, pelagic clay.
- $F \times S = 2$ adequate to prevent creep rupture.

c. Dynamic Holding Capacity

1) Impulse Loading - refer to Douglas (1978), or Beard (1980), for details of prediction procedure.

- Consider only if large infrequent loads may be unexpectedly applied to a plate anchor mooring.
- Can have a positive effect on anchor holding capacity for loads of up to:

- 500 sec duration - cohesive soil
- 10 sec duration - cohesionless soil

- For load durations $< .01$ sec impulse holding capacity can be:


2-5 times short-term capacity for a normally consolidated clay.

2-6 times short-term capacity for a mid-density sand

- Impulse loads near or somewhat above F_{st} can be tolerated.

2) Cyclic Loading - Refer to Beard (1980) for details of cyclic capacity prediction scheme developed by Herrmann (1980).

- Caused by wave induced forces and cable strumming.



- Cyclic loads $< 5\%$ static capacity of no concern, therefore, cable strumming can be ignored.
- Cyclically loaded anchors designed to preclude failure from liquefaction or cyclic creep.

Characterized by strength loss and sudden anchor instability

Accumulation of small movements that reduce anchor depth until pull out occurs.



Strength Loss During Cyclic Loading

The following procedure excludes soils such as uniform fine sand, coarse silts, and some clean oozes which are susceptible to true liquefaction failure. Use of plate anchors in these soils under cyclic loading is not recommended at this time.

Procedure

Determine t_{cd} from the soil permeability.

For the assumed sea conditions, determine the number of loading cycles during t_{cd} found from the soils permeability. Enter the figure below to find the loading bounds as a function of soil type. This table can also be used directly to find the limiting number of cycles for a given loading.




APPROXIMATE RELATION BETWEEN COEFFICIENT OF PERMEABILITY AND GRAIN SIZE RANGE

Soil type	Limits of grain size, mm	Size at which permeability is measured, mm	Coefficient of permeability	
			cm-sec	ft-yr
Gravel	2.0	4	1	10^6
Sand	0.06	0.6	10^{-2}	10^4
Silt	0.002	0.008	10^{-6}	1
Clay		0.001	10^{-8}	10^{-2}


Cyclic Creep During Cyclic Loading

- Poorly understood phenomena that does occur in the laboratory.
- Number and magnitude of significant loading cycles occurring during the life of an anchor control cyclic creep.
- For cases where static load exceeds 20% static capacity, add portion above 20% to cyclic component and proceed.




3) Earthquake Loading (Refer to Wilson, 1969)

- Cohesive soils not susceptible to significant strength loss during earthquake loading.
- Granular soils can liquefy during earthquake loading.
- Granular liquefaction is a function of soil relative density. Potential for liquefaction is illustrated below.



Liquefaction potential profiles for earthquake loading of granular soils (from Seed and Idriss, 1971).

Maximum ground accelerations are a function of earthquake magnitude and distance from the quake epicenter.



Maximum acceleration associated with earthquakes of various magnitudes (from Seed et al., 1969).


If analysis of the site and its expected earthquake indicates a high probability of soil liquefaction, the site is hazardous. Use of plate anchors which are loaded a significant percentage of time should be avoided.

DRAG EMBEDMENT ANCHORS


A. Anchor Descriptions (Refer to Ogg, 1969; Valent et al., 1976)

1. Standard Drag Anchor


- Significant portion of anchor capacity generated by anchor wt.
- Full embedment-rare.
- Develops peak capacity with minimal drag.




(a) STOCK (ADMIRALTY) ANCHOR
KEDGE TYPE



(c) MUSHROOM ANCHOR
REINFORCED CONCRETE



(b) MUSHROOM ANCHOR





(d) PEARL HARBOR CONCRETE ANCHOR

Standard Drag Anchors

Anchor	Weight (Air) (lb)	Weight (Wet) (lb)	Average Lateral Load Capacity (lb)		
			Length of Drag (ft)		
			50	100	150
Wedge sand mud	10,580	6,000	25,000	27,300	27,500
			9,300	11,900	11,700
Mushroom sand mud	10,500	6,000	21,300	23,000	21,600
			9,100	10,000	13,300

2. Standard Burial Anchor

- Achieves most of capacity as a result of soil shear strength.
- Designed to improve their capacity through dragging to cause embedment to deeper, stronger soil.
- Most anchors in this category fabricated according to rules of geometric similarity where dimensions are proportional to (weight)^{1/3}



STATO Mooring Anchor

Standard burial anchor performance is idealized below.


- β = fluke angle
- α = shank angle
- θ = line angle



- a. placed on seafloor
- b. flukes keying into seafloor
- c. in dense/stiff seafloor $\alpha = +0^\circ$ to 15°
- d. in soft seafloor $\alpha = -20^\circ$ to -45°


Idealized anchor remains stable and holds stably even though dragged (achieves equilibrium).

Pick Type Burial Anchor




- Anchor designed to turn to penetrating position even if dropped on its side.

Cast Bruce Anchor



Twin-Shank Bruce Anchor.

Mud Type Burial Anchor



- Permanent mooring anchor.
- Designed to be control lowered to seafloor.
- Designed for very soft seafloors.

Doris Mud Anchor

B. Anchor Performance

1. General Behavior (Refer to Saurwalt, 1971, 1972a, 1972b, 1973, 1974a, 1974b)

Seafloor Type - [Performance as defined by broad seafloor categories.]

Mud or silt - Wide range in anchor performance; "mud" strength varies considerably.

Sand - Performance reasonably consistent provided anchor penetrates; dense sand can be difficult.


Clay - good holding capacity.

Coral - Function if anchors snag an outcrop, fall in crevice, blasted in.

Rock - Unsatisfactory.


Layered (sand/clay/mud) - Performance erratic for high efficiency anchors.

Roll Stability



Performance of 18,000-lb Navy anchor with and without stabilizers


- Anchors improperly stabilized will roll limiting peak capacity.
- If an anchor rolls in a mud or clay, the anchor will come out with a "mud clod" fixing the fluke preventing re-embedment.
- Erratic/poor performance can sometimes be corrected by extending stabilizers.



Navy anchor.

Mooring Line Angle

Effect of line angle on mooring performance can be significant.




Holding capacity versus weight for STATO anchors at various mooring line angles.

Majority of decrease probably attributed to reduction in chain capacity.


Fluke/Shank Angle

- Figure shows significance of fluke angle on anchor performance.
- Optimum angle for mud ($\approx 50^\circ$)
- Optimum angle for sand ($30-35^\circ$)




Test results on an 18,000 pound Statelink Anchor with stabilizers in sand

- Figure illustrates problem with excessive fluke angle in sand.



Mooring Line Type (Wire Versus Chain)

- Overall mooring capacity ~ similar assuming sufficient sediment for complete burial.
- Anchor penetration in mud significantly less with chain mooring - less sediment required.
- Anchor drag distance to peak load less with chain mooring - as much as 50 versus 250 ft.
- Anchor stability requirements greater for wire than chain mooring.





Anchor Size

- Small anchors (<3,000 lb) often exhibit higher efficiencies (by as much as a factor of 1-1/2 to 2) than anchors 10,000 to 30,000 lb.
- **Manufacturers' claims of constant efficiency with size based on geometrically similar designs (dimensions \sim anchor wt^{1/3}). Data do not support this as a general rule. Refer to section on Anchor Capacity.**

2. Recent Anchor Performance Data (Refer to Taylor, 1980a, 1980b, 1980c)


STATO Anchor in Sand



Test results for 3000 lb STATO with various modifications - dense sand, San Diego

STATO Anchor in Mud

- Graph shows trajectory of anchor embedment in soft mud (Puget Sound).
- Extended stabilizers (about 30% increase) needed to maintain stability (6,000 lb STATO with standard stabilizers rolled during embedment).
- Majority of load carried by chain.




Stockless Anchor in Mud

Stockless Anchor in mud

- A. Sk stockless w/stabilizers w/fixed flukes
- B. Sk stockless w/stabilizers w/movable flukes
- C. Sk stockless w/movable w/o stabilizers w/movable flukes

	Embedment Depth to Crown	Mooring Efficiency
A	16.1 ft	5.1
B	10.8 ft	3.8
C	-	3.1




3. Chain Capacity (Refer to Cole and Beck, 1964; and Taylor, 1980a, 1980b, 1980c)

- Chain efficiency varies considerably for "similar" soil types.
sand - efficiency of 1 to >3 depending on density
mud - efficiency of 0.4 to 1.1 depending on strength and clay content.

4. Tandem Anchors (Refer to Taylor, 1980a)

- Option A - Shank to shackle technique; good tandem capacity; chain should be lightly lashed to inbound anchor crown during deployment.
- Option B - Crown to shackle technique; slightly less efficient than "A" but easier to install.
- Option C - Ground ring to shackle technique; less efficient than "A" or "B" - relatively easy to install in shallow water; Anchor B installed first.



RIGGING METHOD FOR TANDEM ANCHORS FOR ADEQUATE PERFORMANCE.

5. Options to Improve Poor Anchor Performance

<u>Problem</u>	<u>Possible Reason</u>	<u>Solution</u>
Poor mud performance	- Flukes not tripping	- Increase size of tripping palms - Weld flukes in open position
	- Anchor unstable	- Increase stabilizer length/add stabilizers
	- Unknown	- Add chain - Use backup anchor
Poor sand performance	- Flukes not penetrating	- Check fluke angle; reduce if > 30-32° - Sharpen flukes
	- Anchor unstable	- Extend stabilizers - Add stabilizers
	- Unknown	- Add chain - Use backup anchor

C. Methods to Determine Drag Embedment Anchor Capacity

1. Method of Cole and Beck (1964)

- Verified procedures relating anchor capacity to soil engineering properties not available.
- Available procedure dated to Leahy and Farrin (1955) is reasonable provided anchor test data available

Anchor capacity relates to anchor wt as follows:

$$F = C W_a^b$$

Where F = Short-term holding capacity (lbs)


W_a = Anchor wt in air (lbs)

C, b = Empirical soil constants, dimensionless

- Relationship plots as a straight line on log-log plot, C is the intercept, b is the slope.
- Results valid for that anchor, mooring line type, soil type.

OPTIONAL-PROCEDURE

- Perform single test, use $b = 0.75$ to calculate C .
- Extent of extrapolation of this procedure questionable.
- Theoretical limit for b is $2/3$, where steel stress is controlling factor. Refer to Valent et al., 1979.
- Use verified manufacturer data to calculate C for $b = 0.75$.



2. Prototype Data

- Refer to manufacturers for data; data often based on small anchor tests at unlimited drag (request details of tests).
- Data valid for specific test conditions; anchor performance very sensitive to conditions (use data with caution for other conditions).

3. Full-Scale Pull Test


- Most accurate/costly.

DEADWEIGHT ANCHORS

A. Anchor Types

Vary from: sophisticated (concrete/steel anchors with cutting edges) to engine blocks, concrete clumps, etc.

Added capacity from sophistication must be balanced against cost.



Several variations on the basic deadweight anchor.

B. Design Procedures


1. Simple Form (anchors w/o shear keys)

Idealized deadweight resists lateral load component by static friction; vertical load resisted by portion of anchor wt.

Net normal force, R_n , contributes to lateral load resistance, R_1 , according to:

$$R_1 = \mu R_n$$

Where μ is the coefficient of friction between anchor block and seafloor; μ varies w/seafloor type/strength.



Fundamental Concept of Deadweight Anchor

a. Cohesionless Seafloor

- Trapped water dissipates rapidly. μ up to 0.8 possible ($\phi = 38^\circ$); simple frictional behavior controls.
- Friction coefficient dependent on surface smoothness, anchor material, sand type.

Coefficients of Friction Between Cohesionless Soils and Some Marine Construction Materials (Valent, 1979)

Soil	Internal Friction Coefficient	Surface Friction Coefficient for --				
		Smooth Steel	Rough Steel	Smooth Concrete	Rough Concrete	Smooth PVC
Quartz Sand	0.67	0.27	0.60	0.60	0.69	0.33
Coralline Sand	0.67	0.20	0.63	0.63	0.66	0.20
Oolitic Sand	0.79	0.23	0.56	0.58	0.74	0.26
Foram Sand-Silt	0.64	0.40	0.66	0.67	--	0.40

b. Cohesive Seafloor

μ (immediate) can be < 0.1 (attributed to thin film trapped water between anchor and seafloor).

μ (short term - normally consolidated seafloor) can be 0.15-0.2

$$R_1 \sim \frac{R_n}{5.7} \quad \text{where} \quad 5.7 \sim \frac{\text{Anchor bearing capacity}}{\text{Anchor-soil shear resistance}}$$


Value (5.7) assumes adhesion between anchor base and soil equals soil undrained shear strength.

μ (long term) - up to 0.7 for $\phi_{\text{drained}} = 35^\circ$

μ (short term - over consolidated seafloor) depends upon soil strength, anchor roughness.

c. Effect of Sloping Seafloor

- Low initial μ can cause instability on sloping seafloors.
- Deadweights on slopes $\sim 10^\circ$ have slid under own weight.
- Avoid use on sloping seafloors.
- Sloping clay seafloors likely over consolidated; down slope creep possible.



2. Detailed Procedure - (Refer to Valent, et al 1979)
Used when peak deadweight lateral capacity is desired.

a. Considerations

Bearing Capacity


- Not considered problem when resultant normal soil reaction lies within middle one-third of anchor base.

Vertical Load

- Resisted directly by a portion of the submerged anchor wt.; wt in excess of that required to develop lateral capacity.
- Discount suction effect.

Horizontal Load


- Components composing horizontal load resistance



1. shear along anchor base
2. shear along base of passive wedge at anchor front
3. uplift (weight) of passive wedge
4. shear along anchor sides
5. suction at rear of anchor

Items can be neglected

Calculated capacities assume displacement only to mobilize base shear (< 10% anchor width; capacity will typically increase with drag) and assumes no auxiliary embedment means (jetting).



Deadweight Anchor with Corrug Skirts
(Note: $R_1 = R_2 = R_3$)

- Deadweight capacity enhanced by roughened surface or addition of skirts.
- Skirts in cohesive soil move sliding surface to deeper, stronger soil; optimum length ~ 0.1B

- Skirts in cohesionless soil - marginal increase in capacity; optimum length $\sim 0.05 B$; interior skirts not needed; exterior skirt helps reduce scour and undercutting.

- Overturning - Anchor must be designed to prevent overturning. Anchor center of mass should be low; mooring attachment points should be low.
- Stabilizing moment > overturning moment

Cyclic Loading

- Effect depends on magnitude of cyclic component relative to the quasi-static load as well as the absolute load level.
- "Porous" deadweight may be less susceptible to mooring line transmitted cyclic loads because drainage path is shortened (pore pressure dissipation occurs more rapidly).
- Refer to section on plate anchor design for added details; also, see Foss, et al, (1978).

Other Design Considerations

- Scour, slumping, wave induced instabilities of the seabed, earthquakes, wave forces on anchors.
- Degree of attention to these depends on location, water depth, soil type, soil degree of consolidation, seafloor slope.

b. Anchor Design - Cohesionless Soil

- Anchor designed to realize lateral capacity (R_1) according to:

$$R_1 = (W - F_v) \tan(\bar{\phi} - 5^\circ) + 1/2 K_p \gamma_b z_s^2 B$$

where: W = submerged anchor wt (F); F_v = uplift force (F);

$\bar{\phi}$ = effective angle of internal friction (degrees);

K_p = coefficient of lateral earth pressure.

c. Anchor Design Cohesive Soil

- Anchor designed to yield lateral capacity (R_1) according to:

$$R_1 = s_{uz} A + 2 s_{ua} z B$$

where s_{uz} = soil undrained shear strength at depth z (F/L^2)
 s_{ua} = average soil strength between surface and z (F/L^2)
 A = anchor base area
 z = anchor or shear key penetration into seafloor (L)
 B = anchor base dimension (L)

DEADWEIGHT ANCHOR DESIGN PROCEDURES

Cohesionless Seafloor: Deadweight Anchor Design Procedure


Step	Item	Equation
a	Loads	F_h, F_v (given)
b	Soil	$\gamma_b, \bar{\phi}$ (given)
c	Weight (in water) required to resist sliding	$W = \frac{F_h}{\tan(\bar{\phi} - 5^\circ)} \rightarrow F_v$
d	Anchor width (min): with shear keys	$B = \left[\frac{6 W F_h}{\gamma_s (W - F_v - 0.3 F_h)} \right]^{1/3}$
	without shear keys	$B = \left[\frac{6 W F_h}{\gamma_b (W - F_v)} \right]^{1/3}$
e	Shear keys ^a number	$n = \frac{200(W - F_v) \tan(\bar{\phi} - 5^\circ)}{K_p \gamma_b B^3} + 1$
	thickness	$t = 0.042 \left(\frac{\gamma_b B^3}{f_b} \right)^{1/2}$
	weight	$W_k = 0.05 \gamma_k B^2 t$
	embedment force for one shear key	$q_e = \frac{\gamma_b B^2}{400} [20 t N_q + B \tan(\bar{\phi} - 5^\circ)]$
f	Maximum pull height with or without shear keys	$H_m = \frac{B(W - F_v)}{6 F_h}$

^aAssumes shear key penetration = 0.05 B.

Coefficients of Passive Lateral Earth Pressure, K_p , on Deadweight Shear Key^a (after Tschebotarioff, 1962)

$\bar{\phi}$ (deg)	K_p
10	1.56
12.5	1.76
15	1.98
17.5	2.25
20	2.59
25	3.40
30	4.78
35	6.88
40	10.38

^aAssumptions: a. shear key wall is vertical
b. soil surface is horizontal
c. soil is non-cohesive, $s_u = 0$
d. angle of wall friction, $\delta = 0.5\bar{\phi}$



Bearing capacity factors for shallow footings

Cohesive Seafloor: Deadweight Anchor Design Procedure

Step	Item	Equation
a	Loads	F_h, F_v
b	Soil	s_u, S_t, γ_b versus z
c	Anchor width: without shear keys	$B = \left(\frac{F_h}{s_{uo}} \right)^{1/2}$
	with shear keys ^a	$R_1 = B^2 (s_{uz} + 0.2 s_{ua})$
d	Shear keys ^a number, n	$n = \frac{200 s_{uz}}{40 s_{ua} + \gamma_b B} + 1$
	thickness, t	$t = \frac{B}{22.4} \left(\frac{40 s_{ua} + \gamma_b B}{f_b} \right)^{1/2}$
	weight per shear key, W_k	$W_k = 0.1 \gamma_k B^2 t$
	embedment force for one shear key, q_e	$q_e = 9 s_{uz} t B + \frac{B^2 s_{ua}}{5 S_t} - W_k$
e	Submerged weight (1) to resist overturning. (a) for $H = 0.2 B$, $z_s = 0.1 B$ (b) for H minimized, $z_s = 0.1 B$ (c) for H minimized, $z_s = 0$	$W = 1.2 F_h + F_v$ $W = \frac{0.6 F_h + F_v}{1 - \frac{6 F_h}{B A \gamma_s}}$ $W = \frac{F_v}{1 - \frac{6 F_h}{B A \gamma_s}}$
	Submerged weight (continued) (2) to embed shear keys: (a) omni-directional anchor (b) uni-directional anchor	$W = 2 n q_e$ $W = n q_e$
	where	$q_e = 9 s_{uz} t B + \frac{B^2 s_{ua}}{5 S_t} - W_k$

^aAssumes cutting edge penetration = 0.1 B, anchor square in plan.

LIST OF SYMBOLS

F_h, F_v	Horizontal and vertical load components	R_1	Anchor lateral load resistance	γ_k	Submerged unit weight of shear key
s_u	Soil undrained shear strength	s_{uz}	Soil undrained shear strength at depth z	γ_b	Buoyant unit weight of deadweight
S_t	Soil sensitivity	s_{ua}	Average soil strength between surface and z	$\bar{\phi}$	Effective angle of internal friction
γ_b	Submerged unit weight of soil	z	Anchor shear key penetration into seafloor	W	Submerged weight of the anchor
B	Anchor width	f_b	Allowable steel stress	K_p	Coefficient of lateral earth pressure
s_{ud}	Undrained shear strength at seafloor surface	Z_s	Shear key height	N_q	Coefficient of passive lateral earth pressure

Step

Calculation/Discussion

Design of assumed steel shear keys:

Number of keys one direction:

$$n = \frac{200(55 \text{ kips} - 20 \text{ kips}) \tan(35^\circ - 5^\circ)}{7(0.060 \text{ kips/ft}^3)(14 \text{ ft})^3} + 1$$

= 4.5 \approx 5 shear keys each direction

Thickness of shear key:

$$t = 0.042 \left[\frac{0.060 \text{ kips/ft}^3 (14 \text{ ft})^3}{21.6 \text{ ksi} (144 \text{ in.}^2/\text{ft}^2)} \right]^{1/2}$$

= 0.0097 ft = 0.116 in.

\approx 1/8 in. plate minimum required

Assume that 1/4-in. plate will be used to allow for corrosion and to provide added shear key strength to resist damage during handling.

Weight of each shear key:

$$W_k = 0.05(426 \text{ pcf})(14 \text{ ft})^2(0.25 \text{ in.}/12 \text{ in./ft})$$

= 87 lbf per shear key

Force required to embed one shear key is:

$$Q_e = \frac{60 \text{ pcf} (14 \text{ ft})^2}{400} \left[20 \left(\frac{0.25}{12} \text{ ft} \right) 45 + (14 \text{ ft}) \tan(35^\circ - 5^\circ) \right]$$

$Q_e = 788 \text{ lbf}$

(Note: The submerged weight of a shear key is about 10% of the total force needed to embed that shear key for this sand seafloor example.)

Total force required to embed all shear keys, 5 keys in each of two directions, is:

$$2 n Q_e = 2(5)(788 \text{ lbf})$$

= 7880 lbf = 7.9 kips

Design submerged weight of deadweight is 54.6 kips, much greater than the 7.9 kips required to embed the shear keys. Maximum height of mooring line connection point above the base of the anchor, taken at tips of the shear keys:

$$H_m = \frac{B(W - F)}{6 F_h}$$

$$= \frac{14 \text{ ft}(54.6 \text{ kips} - 20 \text{ kips})}{6(20 \text{ kips})}$$

= 4.0 ft

Check: Top of concrete mass above shear key tips is:

$$H \approx 0.05(14 \text{ ft}) + \frac{54.6 \text{ kips} - 7.9 \text{ kips}}{0.086 \text{ kips/ft}^3(14 \text{ ft})^2}$$

= 0.7 + 2.8 = 3.5 ft < 4.0 ft

EXAMPLE PROBLEMS

Example 1: Deadweight Design, Sand Seafloor

Given Information: A deadweight anchor is to be designed to resist a lateral force of 20 kips and an uplift force of 20 kips. The anchorage is to be used as a single point mooring for small vessels. Water depth is 40 feet. The seafloor sediment is well graded sand with a submerged unit weight of 60 pcf and a friction angle of 35 degrees. The 3-foot-thick sand layer covers massive basalt. Sea room is limited on one side of the mooring. A barge with a 50-ton which is available for anchor placement.

Solution

Step

anchor selection

Calculation/Discussion

The thin sediment layer prevents the use of efficient, deep embedment type anchors. Less efficient drag type anchors are also unsuitable. They would not provide the required uplift capacity necessitated by the short mooring line length. Pile anchors are eliminated because of high cost and unavailability of drilling and grouting equipment. A deadweight anchor remains as the most plausible selection.

deadweight type

The deadweight selected must resist lateral and uplift loads. The limited sea room available requires that the anchor develop maximum capacity with little or no dragging. The anchor should also resist omni-directional load. A concrete slab fitted with shear keys meets these requirements. The anchor may be lowered with the available barge.

shear key length

As a minimum, a perimeter shear key with a length equal to 5% of the anchor base dimension could be chosen to reduce scour and prevent undercutting of the anchor. For the example, a full grid of shear keys is assumed to ensure against sliding.

c

Anchor weight (in water) required to resist sliding:

$$W = \frac{20}{\tan(35^\circ - 5^\circ)} + 20 = 54.6 \text{ kips}$$

skirt embedment force calculated in step e

Anchor width required, assumed concrete:

$$B = \left\{ \frac{6(55 \text{ kips})(20 \text{ kips})}{(0.086 \text{ kips/ft}^3)[55 \text{ kips} - 20 \text{ kips} - 0.3(20 \text{ kips})]} \right\}^{1/3}$$

= 13.8 ft \approx 14 ft

(similar calculations yield B = 8 ft for a steel anchor)

Example 2: Deadweight Design, Clay Seafloor

Given: Assume all data given for Example 1 remains unchanged except for soil type. The soil is now a 3-ft-thick layer of silty clay. The undrained shear strength for this sediment is found to increase linearly with depth according to $s_u = 1.0 + 0.026 z$, where s_u equals undrained shear strength (psi) and z equals depth below seafloor (in.). The sensitivity (S_u) of the material is reported as 2.0 and the submerged unit weight as 28 pcf.

Step Calculation/Discussion

a Mooring line forces applied to deadweight:

Vertical, $F_v = 20$ kips

Horizontal, $F_h = 20$ kips

Strength profile description for clay soil

$$s_{uz} = 1.0 + 0.026 z$$

where s_{uz} is in psi, z is in inches.

A deadweight anchor with shear keys is selected to maximize anchor lateral load efficiency. Anchor width (size) is determined by solving the equation below by trial and error:

$$R_1 = 9^2 (s_{uz} + 0.2 s_u)$$

Trial 1: Assume $B = 72$ in., $z = 7.2$ in. Soil shear strength at z :

$$s_{7.2} = 1.0 + 0.026(7.2 \text{ in.}) = 1.19 \text{ psi}$$

Average soil shear strength over depth z :

$$s_{ua} = \frac{1}{2} (s_u + s_{7.2}) = \frac{1}{2} (1.0 \text{ psi} + 1.19 \text{ psi}) = 1.09 \text{ psi}$$

Lateral load capacity for assumed $h = 72$ in.:

$$R_1 = (72 \text{ in.})^2 [1.19 \text{ psi} + (0.2)(1.09 \text{ psi})]$$

$$= 7300 \text{ lbf} < F_1 = 20,000 \text{ lbf}$$

Thus, $B = 72$ in. is too small.

Trial 2: Assume $B = 120$ in., $z = 12$ in. Soil shear strength at z :

$$s_{12} = 1.0 + 0.026(12 \text{ in.}) = 1.31 \text{ psi}$$

$$s_{ua} = \frac{1}{2} (s_u + s_{12}) = \frac{1}{2} (1.0 \text{ psi} + 1.31 \text{ psi}) = 1.16 \text{ psi}$$

$$R_1 = (120 \text{ in.})^2 [1.31 \text{ psi} + (0.2)(1.16 \text{ psi})]$$

$$= 22,200 \text{ lbf} > F_1 = 20,000 \text{ lbf}$$

Therefore, $B = 120$ in. = 10 ft OK

Design of shear keys:

Required number of shear keys in one direction:

$$n = \frac{200(1.3 \text{ psi})(144 \text{ in.}^2/\text{ft}^2)}{40(1.16 \text{ psi})(144 \text{ in.}^2/\text{ft}^2) + (28 \text{ pcf})(10 \text{ ft})} + 1 = 5.38 + 1 = 6.38$$

Use 6 shear keys in each direction or 12 total.

Thickness of shear keys to resist bending under lateral loading:

$$t = \frac{120 \text{ in.}}{22.4} \left[\frac{40(1.16 \text{ psi}) + \left(\frac{28}{1728} \text{ pcf} \right) (120 \text{ in.})^2}{21,600 \text{ psi}} \right]^{1/2}$$

= 0.25 in. say 3/4-in. plate

Submerged weight per shear key:

$$W_k = 0.1(626 \text{ pcf})(10 \text{ ft})^2 \left(\frac{0.25}{12} \text{ ft} \right) = 89 \text{ lbf}$$

Force required to embed one shear key less submerged weight of that key:

$$Q_e = 9(1.31 \text{ psi})(0.25 \text{ in.})(120 \text{ in.})$$

$$+ \frac{(120 \text{ in.})^2 (1.16 \text{ pcf})}{5(2)} = 89 \text{ lbf}$$

$$= 1935 \text{ lbf}$$

Submerged weight required is the larger of

- (1) the weight required to prevent overturning, and
- (2) the weight required to embed the shear keys

Weight required to resist overturning is:

$$W = 1.2 F_h + F_v$$

$$= 1.2(20 \text{ kips}) + 20 \text{ kips} = 44 \text{ kips}$$

Weight required to embed shear keys is:

$$W = 2 n Q_e$$

$$= 2(6)(1935 \text{ lbf}) = 23,200 \text{ lbf} = 23 \text{ kips}$$

Thus, required weight = 44 kips

Total weight of shear keys = 12 W_k = 12(89 lbf) = 1070 lbf

Submerged weight of the mass block required:

$$= 44 \text{ kips required} - 1 \text{ kip (keys)} = 43 \text{ kips}$$

Density of the deadweight material:

$$\gamma_s = \frac{\text{weight deadweight}}{B^2 H} = \frac{43,000 \text{ lbf}}{(10 \text{ ft})^2 (1 \text{ ft})} = 430 \text{ pcf submerged}$$

PILE ANCHORS


A. Operation

Definition. Pile anchors achieve holding capacity by mobilizing shear strength of surrounding seafloor material. Bearing pressure and/or skin friction/adhesion are used to achieve capacity.

Cost. High installation costs usually dictate pile anchor use as last resort.

Construction. Basic steel shapes usually modified to act as anchor piles.

Installation. By driving, often in partially predrilled holes; in hard strata, by grouting in fully predrilled holes. Screw-in pile anchor (considered under plate anchors) [Refer to Chellis, 1961, Havers and Stubbs, 1971, for detailed discussions of pile systems.]



B. Pile Types/Methods to Improve Performance

1. Mooring Line Connection

Surface attachment - Inspection and maintenance possible
- Swivel/U-joint desirable to reduce connection torsion (Ref Doris, 1977).

Subsurface attachment - Inspection not practical
- Applicable to unidirectional loading
- Enhances pile lateral load resistance; pile bending stress reduced
- Changes direction of pile load; higher vertical, less lateral load.

2. Pile Head Burial

- Places pile in deeper-stronger soil
- Used for offshore moorings when drillship is available for drilling and grouting
- Load at pile can be reduced significantly, by mooring line resistance (see drag anchor section)
- In sand, pile anchors buried few ft to allow for scour.


3. Near Surface Fins/Collars

- Used to limit pilehead deflection/bending moment

4. Built-up Sections

- Fabricated to produce section modulus to resist high bending forces/limit bending
- Sections symmetrical or asymmetrical depending on loading directions.

Variations of the Basic Pile Anchor



C. Installation (Refer to Chellis, 1961, 1962, and 1979; Compton, 1977)

1. Driving

- Most piles in soil/soft rock installed by driving
- Many hammer types easily modified for use to 80 ft
- Pile hammers developed for underwater operation by Raymond (1979), and Hydroblock (1979), (Hydroblock to 1,600 ft)
- Can use follower in shallow water
- Deep water - refer to Anon 1979 for discussion of a self stabilizing "puppet" system for pile installation.


2. Drivability

- Best method for evaluation of pile drivability/hammer efficiency is the wave equation. Refer to Smith (1962).

3. Drilling and Grouting


- Used when predicted driving resistance exceeds hammer capacity
- Typically used in hard coral, rock
- Recommended for use in calcareous sands and soft silt where developed frictional capacities are low.

File Installation Methods



Pile installation methods.

- Grouted piles can be underreamed to greatly increase vertical capacity.
- Underreams of more than 5m dia have been constructed @ 40m depth in the North Sea.




D. Pile Capacity

1. Lateral and uplift force at the anchor

- Forces on buried pile are altered in magnitude and direction.

a. Simplified Analysis

- Assumes no friction along buried chain



(a) Definition of Terms

- Results in over estimation of F_v and under estimation of F_h by up to 25%.

Sand

$$F_{cb} = z_c^2 d_b \gamma_b \bar{N}_q$$

d_b = characteristic chain or wire diameter (for chain use 3 x chain size)

Soil Friction

Angle	\bar{N}_q
20	3
25	5
30	8
35	12
40	22

Clay

$$F_{cb} = 11 s_u d_b z_c$$

s_u = soil undrained shear strength

Force components at the anchor given by:

$$F_h = P_h - F_{cb}$$

$$F_v = \sqrt{P^2 - F_h^2}$$

b. Refined Analysis

- Refer to Reese 1973 and Gault and Cox 1974.

2. Lateral Pile Capacity

- Depends on soil strength, stiffness, load type, pile dimensions and stiffness
- Rigid and long (semi-rigid) pile analyses are possible

Rigid Pile Analysis. Assumes soil failure occurs as an infinitely rigid pile rotates about a point on its length.

Procedure is very conservative; results in pile with minimum deflection at head; can be used for preliminary pile selection for long pile analysis, (Refer to Czerniak 1957).

Long Pile Analysis

- Many procedures available (Refer to Gill 1970, Matlock 1970, Reese 1974, Broms 1964)
- Procedures are labor intensive; generally have been computerized
- Procedures rely on a pile/soil interaction analysis where pile/soil deflection characteristics are needed
- Procedures rely on establishment of load-deflection (P-Y) curves for soil, typically based on test experience.

3. Pile Axial Capacity

Capacity treated as function of shear along the pile/soil interface. Both cohesive and cohesionless soils can be treated as frictional materials.


a. Cohesive Soil

Refer to semi-empirical method of Vijayvergiya and Focht (1972).

Pile frictional resistance (R_a) expressed as function of mean undrained shear strength (s_m) and mean effective overburden stress (σ_m) over pile length.

$$R_a = \lambda(\sigma + 2s_m)A_s$$


λ = empirical coefficient (below); A_s = lateral area of embedded pile (use area of enclosed rectangle for "H" pile in clay.



Frictional capacity coefficient, λ , versus pile penetration (after Vijayvergiya and Focht, 1972).

λ Method Simplification

- Above equation is rearranged to simplify process. $R_a/A_s = f_m =$ average, pile side friction
- Iterative selection process required; Determine axial capacity then increase length if needed.



Average unit side friction, f_m , in cohesive soil.

b. Cohesionless Soil

Unit skin friction f_1 at any depth is $f = K \bar{\sigma} \tan \delta$

Assume K (coefficient of lateral earth pressure) = 0.5

$\bar{\sigma}$ = effective overburden pressure

δ = angle of friction between pile and soil
 (assume $\delta = \phi - 5^\circ$)

- Pile capacity $R_g = f A_s$

- Average skin friction has been found to peak at pile embedment ~ 20 diameter.
- Recommended value of f , for long piles compiled from Ehlers (1977), Angemeer (1975).

Recommended Skin Friction Values for Soils

Soil	Installation	α deg	K	$f_{p, max}$	
				psi	kPa
Sand	driven or drilled and grouted	0-5	0.5	13.9	96
Silty sand	driven or drilled and grouted	0-5	0.5	11.5	81
Sandy silt	driven or drilled and grouted	0-5	0.5	9.7	67
Silt	driven or drilled and grouted	0-5	0.5	6.9	48
Calcareous sand	drilled and grouted	0-5	0.5	11.5	81
	driven	0-5	0.5	1.7	12

*Depends on installation technique; may be as low as 2 kPa (0.5 psi).

E. Anchor Pile Loading

- Effects of combined axial and lateral loading are poorly understood, currently treated separately.
- Repetitive loading can cause large increase in lateral pile deflection. Methods to dampen/avoid repetitive loading should be considered for piles in loose sand/soft silt seafloors.
- Chellis (1969), suggests "a rough assumption" coefficient of horizontal subgrade reaction for soils of high relative density might be reduced by 1/2, for soils of low relative density - reduced to 1/4 initial value (data provided for plate anchors may be useful as a guide in evaluating effects of repetitive loading).
- Effects of repetitive loading on vertical piles are speculative, (research projects underway in United Kingdom and Norway).

ACKNOWLEDGMENTS

Published and unpublished NCEL reports on anchors and soils provide the basis for this summary report. The contributions of Phil Valent, Mike Atturio, Rick Beard, and Homa Lee of the Foundation Engineering Division at NCEL are acknowledged.

REFERENCES

- Angemeer, J. et al. (1975). "Pile load tests in calcareous soils conducted in 400 feet of water from a semi-submersible exploration rig," in 1975 Offshore Technology Preprints, Houston, Tex., May 1975, p. 664.
- Anon (1979). "Unsupported underwater pile driving: The soil-independent system," Petroleum Engineer International, Mar 1979, pp 10-15.
- Beard, R. M. (1980). Holding capacity of plate anchors, Civil Engineering Laboratory, Technical Report R-882. Port Hueneme, Calif., Oct 1980.
- Broms, B. B. (1964). "Lateral resistance of piles in cohesionless soils," Proceedings ASCE I, Soil Mechanics and Foundation Engineering, vol 90, SM3, 1964.
- Chellis, R. D. (1961). Pile foundations. New York, N.Y., McGraw-Hill Book Company, Inc., 1961.
- Chellis, R. D. (1962). "Chapter 7. Pile foundations," in Foundation Engineering, G. A. Leonards, editor. New York, N.Y., McGraw-Hill Book Company, Inc., 1962, pp 633-768.
- Chellis, R. D. (1979). Handbook of ocean and underwater engineering. New York, N.Y., McGraw-Hill Book Company, Inc., 1969, pp 8-56 to 8-98.
- Cole, M. W., and R. W. Beck (1969). "Small anchor tests to predict full scale holding power," Society of Petroleum Engineers, SPE 2637, 1969.
- Compton, G. R., Jr. (1977). "Selecting pile installation equipment," paper presented at the Associated Pile and Fitting Corp. Piletalk Seminar, San Francisco, Calif., 1977, 13 p.
- Czerniak, E. (1957). "Resistance to overturning of single, short piles," Journal of the Structural Division, ASCE, vol 83, no. ST2, Mar 1957, pp 1-25.
- Douglas, B. J. (1978). Effects of rapid loading rates on the holding capacity of direct embedment anchors, Civil Engineering Laboratory, PO No. M-R450. Port Hueneme, Calif., Oct 1978.
- Ehlers, C. J., and E. J. Ulrich, Jr. (1977). "Design criteria for grouted piles in sand," in 1977 Offshore Technology Conference Preprints, Houston, Tex., May 1977, p. 480.
- Foss, I., R. Dahlberg, and T. Kvalstad (1978). "Design of foundations of gravity structures against failure in cyclic loading," 10th Annual Offshore Technology Conference, Houston, Tex., May 8-11, 1978. (Paper No. OTC 3114)

- Gault, J. A., and W. R. Cox (1974). "Method for predicting geometry and load distribution in an anchor chain from a single point mooring buoy to a buried anchorage," in Preprints, Sixth Annual Offshore Technology Conference, Houston, Tex., pp 309-318.
- Gill, H. L., and K. R. Demars (1970). Displacement of laterally loaded structures in nonlinearly responsive soil, Naval Civil Engineering Laboratory, Technical Report R-670. Port Hueneme, Calif., Apr 1970.
- Havers, J. A., and F. W. Stubbs, Jr. (1971). Handbook of heavy construction. New York, N.Y., McGraw-Hill Book Company, Inc., 1971, pp 27-1 to 27-50.
- Herrmann, H. G. (1980). Design procedures for embedment anchors subjected to dynamic loading conditions, Civil Engineering Laboratory, Technical Report R-___. Port Hueneme, Calif. (to be published)
- Hydroblok (1979). Brochure, Hydroblok Technical Data, Hollandsche Beton Maatschappij bv, P. O. Box 82, 2280 AB Rijswijk, The Netherlands, Apr 79/5000.
- Kulhawy, R. H., D. A. Sangrey, and S. P. Clemence (1978). Direct embedment anchors on sloping seafloors state-of-the-art, Civil Engineering Laboratory, PO No. M-R510. Port Hueneme, Calif., Oct 1978.
- Leahy, W. H., and I. M. Farrin (1935). "Determining anchor holding power from model tests," SNAME (London), vol 43, 1935.
- Lee, H. J., and J. E. Clausner (1979). Seafloor soil sampling and geotechnical parameter determination - Handbook, Civil Engineering Laboratory, Technical Report R-873. Port Hueneme, Calif., Aug 1979.
- Matlock, H. (1970). "Correlations for design of laterally loaded piles in soft clay," Preprint, Offshore Technology Conference, Houston, Tex., 1970. (OTC paper 1204, vol I, pp 544-595)
- Neely, W. J. (1973). "Failure loads of vertical anchor plates in sand," Journal of the Soil Mechanics and Foundations Division, SM9, Sep 1973, pp 669-685.
- Ogg, R. D. (1969). Handbook of ocean and underwater engineering. New York, N.Y., McGraw-Hill Book Company, Inc., 1969, pp 4-70 to 4-74.
- Raymond (1979). Brochure, "Two new underwater piledriving hammers," Raymond International, Inc., Houston, Tex., 1979.
- Reese, L. C., W. R. Cox, and B. R. Grubbs (1974). "Analysis of laterally loaded piles in sand," Preprint, Offshore Technology Conference, Houston, Tex., 1974. (OTC paper 2030, pp 743-483)
- Reese, L. C. (1973). "A design method for an anchor pile in a mooring system," in 1973 Offshore Technology Conference Preprints, Houston, Tex., May 1973.

Saurwalt, K. J. (1971). Movements and equilibrium of anchors holding on an impervious sea bed, Section I. Schip en Werf, Rotterdam, Nr. 25, 1971.

Saurwalt, K. J. (1972a). Movements and stability of anchors on an impervious inclined uneven sea bed, Section II. Schip en Werf, Rotterdam, Nr. 9, 1972.

Saurwalt, K. J. (1972b). Stocked anchors holding on an impervious sea bed, Section III. Schip en Werf, Rotterdam, Nr. 26, 1972.

Saurwalt, K. J. (1973). Anchors penetrating and holding on a soft planar sea bed, Section IV. Schip en Werf, Rotterdam, Nr. 16, 1973.

Saurwalt, K. J. (1974a). Anchors digging in and holding in a soft planar sea bed, Section V. Schip en Werf, Rotterdam, Nr. 25, 1974.

Saurwalt, K. J. (1974b). Explanatory anchor experiments, Section VI. Schip en Werf, Rotterdam, Nr. 26, 1974.

Seed, H. B., and I. M. Idriss (1971). "Simplified procedure for evaluating soil liquefaction potential," Journal of the Soil Mechanics and Foundations Division, vol 97, no. SM9, Proceedings Paper No. 8371. American Society of Civil Engineers, Sep 1971, pp 1249-1273.

Seed, H. B., I. M. Idriss, and F. W. Kiefer (1969). "Characteristics of rock motions during earthquakes," Journal of the Soil Mechanics and Foundations Division, vol 95, no. SM5, Proceedings Paper No. 6783. American Society of Civil Engineers, Sep 1969, pp 1199-1218.

Skempton, A. W. (1951). "The bearing capacity of clays," Building Research Congress. England, 1951.

Smith, A. E. L. (1962). "Pile driving analysis by the wave equation," Proceedings ASCE, Civil Engineering Division, vol 127, no. 1, 1962.

Taylor, R. J., D. Jones, and R. M. Beard (1975). Handbook for uplift-resisting anchors, Civil Engineering Laboratory. Port Hueneme, Calif., Sep 1975.

Taylor, R. J. (1980a). Conventional anchor test results at San Diego and Indian Island, Civil Engineering Laboratory, Technical Note N-1581. Port Hueneme, Calif., Jul 1980.

Taylor, R. J. (1980b). Test data summary for commercially available drag embedment anchors, Civil Engineering Laboratory. Port Hueneme, Calif., Jun 1980. FOR OFFICIAL USE ONLY

Taylor, R. J. (1980c). Conventional anchor test results at Guam, Civil Engineering Laboratory, Technical Note N-1592. Port Hueneme, Calif., Oct 1980.

True, D. G. (1975). Penetration of projectiles into seafloor soils, Civil Engineering Laboratory, Technical Report R-822. Port Hueneme, Calif., May 1975.

Valent, P. J., R. J. Taylor, H. J. Lee, and R. D. Rail (1976). State-of-the-art in high capacity, deep water anchor systems, Civil Engineering Laboratory, Technical Memorandum M-42-76-1. Port Hueneme, Calif., Jun 1976.

Valent, P. J., R. J. Taylor, J. M. Atturio, and R. M. Beard (1979a). "Single anchor holding capacities for ocean thermal energy conversion (OTEC) in typical deep sea sediments," Ocean Engineering, vol 6, nos. 1/2, 1979.

Valent, P. J. (1979b). Coefficients of friction between calcareous sands and some building materials, and their significance, Civil Engineering Laboratory, Technical Note N-1542. Port Hueneme, Calif., Jan 1979.

Vesic, A. S. (1969). "Breakout resistance of objects embedded in ocean bottom," in Proceedings of Civil Engineering in the Oceans II, Miami Beach, Fla., American Society of Civil Engineers, 1969, pp 137-165.

Vijayvergiya, V. N. and J. A. Focht, Jr. (1972). "A new way to predict the capacity of piles in clay," in 1972 Offshore Technology Conference Preprints, Houston, Tex., 1972, vol 2, pp 865-874.

Wilson, B. W. (1969). Earthquake occurrence and effects in ocean areas, Naval Civil Engineering Laboratory, Contract Report CR 69.027. Port Hueneme, Calif., Feb 1969.