

AD-A268 476



EVALUATION OF SURVIVOR-06 WATER
PURIFICATION DEVICE

K.W. JAMES, G.F. THOMSON AND A.T. HANCOCK

MRL-TN-625

MARCH 1993


S DTIC ELECTE D
E AUG 23 1993

APPROVED FOR PUBLIC RELEASE
DISTRIBUTION STATEMENT

MATERIALS RESEARCH LABORATORY

DSTO

DISCLAIMER NOTICE



THIS DOCUMENT IS BEST QUALITY AVAILABLE. THE COPY FURNISHED TO DTIC CONTAINED A SIGNIFICANT NUMBER OF PAGES WHICH DO NOT REPRODUCE LEGIBLY.

REPORT DOCUMENTATION PAGE			
1 AGENCY USE ONLY		2 REPORT DATE MARCH 1993	
4 TITLE AND SUBTITLE EVALUATIONN OF SURVIVOR-06 WATER PURIFICATION DEVICE.		3 TYPE/DATES COVERED	
6 AUTHOR K W JAMES, G F THOMSON AND A T HANCOCK		5 FUNDING NUMBERS	
7 PERFORMING ORG NAME/ADDRESSES DEFENCE SCIENCE AND TECHNOLOGY ORGANISATION, MATERIALS RESEARCH LABORATORY, P.O. BOX 50, ASCOT VALE, VICTORIA 3032, AUSTRALIA.		8 PERFORMING ORG. REPORT NO	
9 SPONSORING/MONITORING AGENCY NAME AND ADDRESS			
11 SUPPLEMENTARY NOTES			
12 DISTRIBUTION/AVAILABILITY STATEMENT UNCLASSIFIED <i>Unlimited A</i>		13 DISTRIBUTION CODE	
13 ABSTRACT (MAX 200 WORDS) THE SURVIVOR 06 WATER PURIFICATION DEVICE WAS EVALUATED FOR THE EFFICACY OF THE BIocide CLEANING PROTOCOL AND THE EFFICIENCY OF THE DEVICE IN AUSTRALIAN DEFENCE APPLICATIONS. A FIELD METHOD OF ASSURING THE INTEGRITY OF THE MEMBRANE WAS DEVELOPED. IT WAS CONCLUDED THAT THE BIocide CLEANING PROTOCOL IS EFFECTIVE, THE DEVICE IS SUITABLE FOR SUPPLYING EMERGENCY DRINKING WATER FOR RELATIVELY INACTIVE GROUPS OF UP TO THREE PERSONS, AND THAT THE INTEGRITY OF THE MEMBRANE SHOULD BE TESTED DURING ROUTINE MAINTENANCE USING A PROTOCOL BASED ON THE SPARK SEA MARKER DYE.			
14 SUBJECT TERMS		15 NUMBER OF PAGES 11	
		16 PRICE CODE	
17 SECURITY CLASS. REPORT UNCLASSIFIED	18 SRC CLASS PAGE	19 SRC CLASS ABST.	20 LIMITATION OF ABSTRACT UL

Evaluation of Survivor-06 Water Purification Device

K.W. James, G.F. Thomson
and A.T. Hancock

MRL Technical Note
MRL-TN-625

Abstract

The Survivor 06 water purification device was evaluated for the efficacy of the biocide cleaning protocol and the efficiency of the device in Australian Defence applications. A field method of assuring the integrity of the membrane was developed. It was concluded that the biocide cleaning protocol is effective, the device is suitable for supplying emergency drinking water for relatively inactive groups of up to three persons, and that the integrity of the membrane should be tested during routine maintenance using a protocol based on the SeaMark sea marker dye.

Accession For	
NTIS	<input checked="" type="checkbox"/>
CRA&I	<input checked="" type="checkbox"/>
DTIC	<input type="checkbox"/>
TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification
By	
Distribution /	
Availability Codes	
Dist	Avail and/or Special
A-1	

DEPARTMENT OF DEFENCE
DSTO MATERIALS RESEARCH LABORATORY

DTIC QUALITY INSPECTED 3

Published by

***Materials Research Laboratory
Cordite Avenue, Maribyrnong
Victoria, 3032 Australia***

***Telephone: (03) 246 8111
Fax: (03) 246 8999***

Author's address

***Materials Research Laboratory - Tasmania
PO Box 147, Scottsdale
Tasmania, 7260 Australia***

***Telephone: (003) 52 2033
Fax:: (003) 52 3044
© Commonwealth of Australia 1993
AR No. 008-227***

Contents

1. INTRODUCTION 5
2. METHODS 6
 - 2.1 Chemical Methods 6
 - 2.2 Microbiological Methods 6
3. RESULTS AND DISCUSSION 6
4. CONCLUSIONS 8
5. REFERENCES 8

APPENDIX A - *Test for Membrane Integrity of Reverse Osmosis Water Purification Device* 10

9 3 8 20 0 4 3

409014

93-19465
■■■■■■■■■■

Evaluation of Survivor-06 Water Purification Device

1. Introduction

The Royal Australian Air Force Institute of Aviation Medicine (AVMED) requested an evaluation of a small, hand-operated reverse osmosis unit with the brand name *SURVIVOR-06* (Boothby, 1991). Two of the units were supplied, one packaged in original packaging. Literature detailing previous evaluations available to AVMED was provided.

The *Survivor 06* reverse osmosis water purification device is based on reverse osmosis membrane technology with a specially designed plumbing system to recover energy and minimise effort by the operator (Hembree, 1988). Operation and care of the device are fully described in the technical manual (Recovery Engineering, 1989) and a condensed version is supplied with the device (Lifestream, 1989).

The intended use of the device would be to supply water for drinking in an emergency. The device would be included as part of the survival equipment of the life raft used in small aircraft with only a few crew or passengers. Life rafts of large aircraft would be supplied with a larger device. It may also have applications for small Army units operating in inland Australia wishing to use highly saline bore water, or highly contaminated river or swamp water.

There is extensive literature documenting the efficacy of reverse osmosis for sterilising and desalinating water (Scott, 1981; Wellon and Soucey, 1987; Wellon, Kournikakis, Fulton, Bhatti, Fildes, Knodel and Spence, 1987; Aircraft Support Executive, 1989; Hembree, 1988; Dickinson, Burrows and Nelson, 1988). Provided the membrane is intact and the effluent tube has not become contaminated, then this technology is capable of providing potable water from sea water or swamp water. The manufacturer describes the membrane as a thin film polyamide composite (Recovery Engineering, undated), which has good resistance to hydrolysis and may be stored dry (Scott, 1981, p. 68). This membrane material is sensitive to chlorinated feed waters (Ko and Guy, 1988, p. 199), hence the membrane is sterilised with sulphite before drying and storage.

After reviewing the literature, it was decided that there were gaps in knowledge regarding the *Survivor 06* in the areas of:

1. efficacy of the biocide for cleaning the effluent tube for the likely period of usage in an emergency;
2. a field method of ensuring the integrity of the membrane during inspections of safety equipment;
3. efficiency of the device in Australian Defence survival applications.

2. Methods

2.1 Chemical Methods

Untreated waters were examined for pH and conductivity according to the *Standard Methods For The Examination of Water and Wastewater* (Franson, Greenberg, Trussell and Clesceri, 1985, p.431 and p.76).

A solution of sea marker dye was prepared and passed through the *Survivor 06* device. The spectrum of the dye solution and the permeate solution was scanned from 450 to 550 nm with a Shimadzu 240C Graficord UV-visible spectrophotometer.

2.2 Microbiological Methods

The efficacy of the biocide protocol provided by the manufacturer (Lifestream, 1989) was evaluated after treating naturally contaminated water from three sources that had various degrees of salinity. Total viable counts of micro-organisms were determined by the Pour Plate Method (SAA, 1975) for:

- i. untreated water;
- ii. permeate from passage of untreated water (i) through *Survivor 06* device;
- iii. permeate, from passage of sterile deionised water through the *Survivor 06*, 24 h after biocide treatment.
- iv. permeate, from passage of sterile deionised water through the *Survivor 06*, 5 d after biocide treatment.

3. Results and Discussion

Local natural waters were tested for use as feedstock for the *Survivor 06* with the results obtained in Table 1. Pond water was chosen as an example of biologically contaminated water with a low dissolved ion content. Great Forester River estuary water was chosen as a moderately brackish water with biological

contamination. The beach effluent water was chosen as a salty water with biological contamination.

Table 1: pH, Conductivity and Total Viable Count of Initial Untreated Water

Water Source	pH	Conductivity μS	Total Viable Count/mL
Pond water	8.9	1.2×10^3	6.2×10^3
Great Forester River estuary	8.1	1.4×10^3	4.0×10^3
Beach effluent (town drainage)	7.4	5.0×10^3	3.2×10^4

Treatment of further samples with the device virtually eliminated the biological contamination from each of the permeate waters (Table 2). The biocide protocol for the device was found to be effective over a five day period (Table 2). The two units tested gave similar results. Therefore, the device is effective, provided the membrane remains intact.

Table 2: Microbiological Results of Test Waters

Source Water	Treatment	Total Viable Count/mL
Pond water	Untreated	5.7×10^2
	Permeate	< 1
Sterile deionised water	24 h post biocide permeate	< 1
Great Forester River estuary	Untreated	3.8×10^4
	Permeate	< 10
Sterile deionised water	24 h post biocide permeate	< 1
Sterile deionised water	5 d post biocide permeate	< 1
Beach effluent (Town Drainage)	Untreated	2.5×10^5
	Permeate	< 1
Sterile deionised water	24 h post biocide permeate	< 1
Sterile deionised water	5 d post biocide permeate	< 1

The dye marker solution (strongly coloured red/green) was found to have an absorbance maxima of 2 absorbance units at 490 nm. The clear permeate from the dye marker solution was found to have zero absorbance at 490 nm. This demonstrates that the dye marker will not permeate through an intact membrane and can be used for field testing of the integrity of the membrane. A suggested field testing protocol is included at Appendix A.

Throughput of the permeate is of the order of 1 L/h (2 US pints/h, Hembree, 1988) using 2.8 kJ energy (Pers. comm., D. Watson, AVMED, 1991). The typical adult (70 kg male) requires a minimum of 2 L water per day and up to 20 L per

day under extreme conditions of climate and exercise. This throughput would be adequate for a group of up to three persons in a life raft when water production is the major exercise activity. It would be too slow and inadequate for an active small Army unit in inland Australia. There may be some applications when this device would be adequate for small Army units, but they would require conditions where the device could be used for a sufficient period.

4. Conclusions

The *Survivor 06* hand operated reverse osmosis water purification device is effective in producing potable water for an individual and groups of up to three persons, depending on the conditions of use. It is suitable for use in an emergency to supply water for crashed aircrew at sea. It may have limited applications for Army to desalinate bore water for small groups. However, a larger unit would be more effective.

The biocide treatment used for storage of the device is effective in preventing biological contamination of the permeate stream, provided the manufacturer's instructions are followed.

If the membrane is damaged, the permeate water will be brackish from a salty water source and the device will be easier to operate. It will also pass sea marker dye through the membrane. The sea marker dye should be used for routine testing of the device during normal maintenance as described in Appendix A.

5. References

- Aircraft Support Executive, (1989). *Reverse Osmosis Hand Pump Packing and Evaluation Trial*, Report Number 1/89, London UK.
- Boothby, G. (1991). *Evaluation of Survivor-06 Water Purification Device*, RAAF Institute of Aviation Medicine Letter, AVMED 1802/10/2/MED Part 2 (10) of 7 Feb 91, Department of Defence, Australia.
- Dickinson, W., Burrows, D. and Nelson, J.H. (1988). *IV Fluidmaker: Preparation of Sterile Water for Injection in a Field Setting*, Tech. Rpt. 8814, US Army Biomedical Research and Development Laboratory, Frederick, Maryland, USA.
- Franson, M.A., Greenberg, A.E., Trussell, R.R. and Clesceri, L.S., (Ed) (1985). *Standard Methods for the Examination of Water and Wastewater*, 16 Ed, American Public Health Association, American Water Works Association and Water Pollution Control Federation, Washington, DC, USA.
- Hembree, R. (1988). *Manual Reverse Osmosis Desalinators: Development and Applications*, Technical Bulletin 001, Recovery Engineering, Minneapolis, MN, USA.

- Ko, A. and Guy, D.B. (1988). *Brackish and Seawater Desalting*, in Parekh, B.S. (Ed), *Reverse Osmosis Technology - Applications for High-Purity-Water Production*. Dekker, New York, USA.
- Lifestream International Water Systems (1989). *Survivor 06 Hand Operated Watermaker Operating Instructions*. Lifestream, Long Beach, CA, USA.
- Recovery Engineering Inc., (1989). *Technical Manual Survivor 06, Recovery Engineering*, Minneapolis, MN, USA.
- Recovery Engineering Inc., (undated). *Performance Characteristics of Reverse Osmosis Membrane*, Recovery Engineering, Minneapolis, MN, USA.
- Scott, J. (1981). *Desalination of Seawater by Reverse Osmosis*, Noyes Data, Park Ridge, NJ, USA.
- Standards Association Australia, (1975). *AS1766 Methods for the Microbiological Examination of Food Part 1.2.2 General Procedures and Techniques, Plate Count Methods*, Standards Association of Australia, Sydney.
- Wellon, G.C., Kournikakis, B.V.E., Fulton, R.E., Bhatti, A.R., Fildes, J., Knodel, M. and Spence, M.R. (1987). *Evaluation of a Reverse Osmosis Water Purification System - Part III: Biological Simulant Challenge*, PCN 2313P-11, Defence Research Establishment Suffield, Ralston, Alberta, Canada.
- Wellon, G.C. and Soucey, W.G. (1987). *Evaluation of a Reverse Osmosis Water Purification System - Part 1: Nuclear and Chemical Simulant Challenge*, PCN 2313P-11, Defence Research Establishment Suffield, Ralston, Alberta, Canada.

Appendix A



Test for Membrane Integrity of Reverse Osmosis Water Purification Device

1. Add one small pellet (0.3 g) of sea marker dye (SeaMark) to 1 L water.
2. Allow at least 10 minutes with stirring for dye to disperse. The water becomes reddish green.
3. Pump through the *Survivor 06* sufficient dye solution to collect 50 - 100 mL of clear permeate solution.
4. If there is any evidence of green colour in the permeate water the membrane of the *Survivor 06* should be replaced.
5. Reverse osmosis water treatment devices that pass this test should be repacked using the biocide according to the manufacturer's instructions.

REPORT NO.
MRL-TN-625AR NO.
AR-008-227REPORT SECURITY CLASSIFICATION
Unclassified

TITLE

Evaluation of Survivor 06 Water Purification Device

AUTHOR(S)
K.W. James, G.F. Thomson and
A.T. HancockCORPORATE AUTHOR
DSTO Materials Research Laboratory
PO Box 50
Ascot Vale Victoria 3032REPORT DATE
March, 1993TASK NO.
90/073SPONSOR
DGFD(L)FILE NO.
G6/4/8-4218REFERENCES
13PAGES
11

CLASSIFICATION/LIMITATION REVIEW DATE

CLASSIFICATION/RELEASE AUTHORITY
Chief, Protective Chemistry Division

SECONDARY DISTRIBUTION

Approved for public release

ANNOUNCEMENT

Announcement of this report is unlimited

KEYWORDS

Reverse Osmosis
MicrobiologyBiocide Protocols
Membrane IntegrityPotable Water
Drinking Water

ABSTRACT

The Survivor 06 water purification device was evaluated for the efficacy of the biocide cleaning protocol and the efficiency of the device in Australian Defence applications. A field method of assuring the integrity of the membrane was developed. It was concluded that the biocide cleaning protocol is effective, the device is suitable for supplying emergency drinking water for relatively inactive groups of up to three persons, and that the integrity of the membrane should be tested during routine maintenance using a protocol based on the SeaMark sea marker dye.

Evaluation of Survivor 06 Water Purification Device

K.W. James, G.P. Thomson and A.T. Hancock

(MRL-TN-625)

DISTRIBUTION LIST

Director, MRL
Chief, Protective Chemistry Division
Dr R.J. Richards
K.W. James
G.P. Thomson
A.T. Hancock
MRL Information Service

Chief Defence Scientist (for CDS, FASSP, ASSCM) (1 copy)
Director, Surveillance Research Laboratory
Director (for Library), Aeronautical Research Laboratory
Director, Electronics Research Laboratory
Head, Information Centre, Defence Intelligence Organisation
QC Technical Reports Centre, Defence Central Library
Officer in Charge, Document Exchange Centre (8 copies)
Army Scientific Adviser, Russell Offices
Air Force Scientific Adviser, Russell Offices
Navy Scientific Adviser, Russell Offices
Scientific Adviser, Defence Central
Director-General Force Development (Land)
Senior Librarian, Main Library DSTOS
Librarian, MRL Sydney
Librarian, H Block
UK/USA/CAN ABCA Armies Standardisation Rep. c/- DGAT (8 copies)
Librarian, Australian Defence Force Academy
Counsellor, Defence Science, Embassy of Australia - data sheet only
Counsellor, Defence Science, Australian High Commission - data sheet only
Scientific Adviser to DSTC, C/- Defence Adviser - data sheet only
Scientific Adviser to MRDC, C/- Defence Attache - data sheet only
Head of Staff, British Defence Research and Supply Staff (Australia)
NSA Senior Scientific Representative in Australia
E-SPEC: Acquisitions Section Institution of Electrical Engineers
Head Librarian, Australian Nuclear Science and Technology Organisation
Senior Librarian, Hargrave Library, Monash University
Library - Exchange Desk, National Institute of Standards and Technology, US
Exchange Section, British Library Document Supply Centre
Periodicals Recording Section, Science Reference and Information Service, UK
Library, Chemical Abstracts Reference Service
Engineering Societies Library, US
Documents Librarian, The Center for Research Libraries, US

Dr Dougal Watson, Research Officer, Institute of Aviation Medicine, RAAF Base Williams,
Point Cook, VIC. 3027
SC Science, HQ 1st Division, Gallipoli Barracks, Enoggera, Qld 4052
SC 2 LE, DEGP-A, Materiel Division (Army), Russell Offices, Canberra ACT 2600
SC PD(L) (B-3-5), Russell Offices, Canberra ACT 2600
DSTIC, Department of Defence, Anzac Park West Offices, Canberra ACT 2600 (18 copies)
MRL Queensland, 456 Palmerston Highway, Innisfail, QLD 4860
Dr INHS, Department of Defence, Campbell Park Offices, Canberra ACT 2600

DISTRIBUTION LIST (Continued)

Naval Support Command, PO Box 706, Darlinghurst NSW 2070
Directorate of Fleet Supply Services, Dept. of Defence (Navy), Campbell Park 3-1-5, Canberra ACT 2600
Assistant Chief Material - A (ACMAT-A), Russell Offices, Canberra ACT 2600
Assistant Chief Logistics - A (ACLOG-A), Russell Offices, Canberra ACT 2600
Director of Ordnance, MILPO, Bandiana VIC 3694
Director Army Training and Doctrine, National Standardisation Office, Russell Offices,
Canberra ACT 2600 (6 copies)
Director General of Army Health Services, Campbell Park Offices, Canberra ACT 2600
Land Force Headquarters, Victoria Barracks, Paddington NSW 2021
Director of Infantry, HQ Infantry Centre, MILPO, Singleton NSW 2331
Director of Catering, HQ Catering Centre, MILPO, Puckapunyal VIC 3001
Senior Inspector Foodstuffs, Headquarters Logistic Command, GPO Box 1932R,
Melbourne VIC 3001
Headquarters Logistic Command, St James Plaza, GPO Box 1932R, Melbourne VIC 3001 (3 copies)
Headquarters Training Command, Naval PO, Balmoral NSW 2091
Headquarters Land Warfare Centre, Kokoda Barracks, Canungra QLD 4275
Head, Defence Centre - Brisbane, Locked Bag 4, Roma Street PO, Brisbane QLD 4003
Head, Defence Centre - Sydney, PO Box 706, Darlinghurst NSW 2010 (2 copies)
Head, Defence Centre - Melbourne, GPO Box 1932R, Melbourne VIC 3007 (2 copies)
Librarian, H Block, Victoria Barracks, Melbourne VIC 3000
Head, Defence Centre - Adelaide, Keswick Barracks, Keswick SA 5035
Head, Defence Centre - Perth, Locked Bag 5001, Fremantle WA 6160 (2 copies)
Head, Defence Centre - Hobart, Anglesea Barracks, Davey St, Hobart TAS 7001
Head, Defence Centre - Darwin, GPO Box 4746, Darwin NT 0801
Librarian, Bridges Memorial College, Duntroon ACT 2600
Commanding Officer/Chief Instructor, RAAOC Centre, MILPO, Bandiana VIC 3662 (3 copies)
Director of Logistics Policy (LPOL2), Dept. of Defence (Air Force), Russell Offices,
Canberra ACT 2600
Director General Air Force Health Services, Dept. of Defence, Campbell Park Offices,
Canberra ACT 2600
Headquarters Operational Command (Staff Office Catering), RAAF, Glenbrook NSW 2773
Headquarters Support Command (CEO4/E41), RAAF, Defence Centre, 366 St Kilda Rd.
Melbourne VIC 3000
Commanding Officer, Institute of Aviation Medicine, Point Cook VIC 3029
Associate Professor C.W. Binns, Head, School of Community Health, Curtin University of
Technology, GPO Box U1987, Perth WA 6001
Librarian, CSIRO Division of Food Processing, PO Box 52, North Ryde NSW 2113
Australian Govt Analyst, PO Box 65, Belconnen ACT 2616
The Director, Australian Government Analytical Laboratories, PO Box 385, Pymble NSW 2073
The Director, Australian Government Analytical Laboratories, 51-65 Clarke St,
South Melbourne VIC 3205
The Director, Australian Government Analytical Laboratories, 338 Tapleys Hill Rd, Seaton SA 5023
The Director, Australian Government Analytical Laboratories, PO Box 83, Cottesloe WA 6011
The Director, Australian Government Analytical Laboratories, PO Box 84, Kingston TAS 7050
Librarian, Antarctic Division, Channel Highway, Kingston TAS 7050
Librarian, Dept. Community Services & Health, GPO Box 9848, Canberra City ACT 2601 (2 copies)
Dr R.C. Hutchinson I.S.O., Derwentlaken Road, Otago, TAS 7017
Serials Section, State Library of Tasmania, Hobart TAS 7000 (2 copies)
Serials Unit, State Library of Queensland, PO Box 488, South Brisbane QLD 4101
Head, School of Food Technology, University of NSW, Kensington NSW 2033
Serials, Biomedical Library, University of NSW, Kensington NSW 2033
The Medical Library, Flinders University of South Australia, Bedford Park SA 5042
Australian Archives, Tasmanian Regional Office, 4 Rosny Hill Road, Rosny Park TAS 7018 (2 copies)

(MRL-TN-625)

DISTRIBUTION LIST (Continued)

Australian Army Representative, Australia House, Strand, London WC2 B4LA, UK
DGST(N) 82B, Room 91, D Block, MOD Ensign, Bath BA1 5AB, UK
Senior Food Chemist, Room 88, D Block, MOD Ensign, Bath BA1 5AB, UK
MOD, Defence Medical Services Directorate (EMR2), First Avenue House, High Holborn,
London WC1V 6HE, UK
Library, APRE, Building F138, C/- RAE, Farnborough GU14 6TD, UK
Librarian, Leatherhead Food R.A. Randalls Road, Leatherhead KT22 7RY, UK
Dr D.A.T. Southgate, Nutrition & Food Quality Dept. Institute of Food Research, Colney Lane,
Norwich NR4 7UA, UK
Principal Food Chemist, Laboratory of the Government Chemist, Armed Services Food
Laboratory, Royal Clarence Yard, Gosport PO12 1AY, UK
Librarian, AFRC Institute of Food Research, Bristol Laboratory, Langford, Bristol BS18 7DY, UK
Food Science Laboratory - MAFF, 65 Romney St, London SW1, UK
D Food S, National Defence Headquarters, 101 Colonel By Drive, Ottawa,
Ontario K1A 0K2, Canada
NDHQ Main Library (Att. Land Technical Library), National Defence Headquarters,
101 Colonel By Drive, Ottawa, Ontario K1A 0K2, Canada
Librarian, Research Branch, Food Research and Development Centre, 3600 Casavant Blvd West,
Saint-Hyacinthe, Quebec J2s 8E3, Canada
Director, Food Research & Nutrition Council, C/- Food Commissioner, Union Place,
Colombo, Sri Lanka
Armed Services Food Chemist, 89 Supply Depot RAOC (BFPO 40), Viersen, Germany
Defence Adviser, Ghana High Commission, 13 Belgrave Square, London SW1X 8PR, UK (5 copies)
Director General, Research & Development Organisation, Ministry of Defence, New Delhi 11,
India (2 copies)
Director, Food Research Laboratory, Jyothinagar, Mysore 570 010, India (2 copies)
Director, Ministry of Defence, Jalan Padang Tembak, Kuala Lumpur 40634, Malaysia (3 copies)
The Director, Defence Scientific Establishment, Ministry of Defence, Auckland Naval Base
Post Office, Auckland, NZ
DTMC, RNZCT Directorate, Army General Staff, Private Bag, Wellington, NZ
S03 Foodstuffs/POL Section, Directorate of Supply, HQ PNGDF, Free Mail Bag, Boroka NCD,
Papua New Guinea
Science Research Supervisor, Food Research Division, Food & Nutrition Research Institute,
Manila, Philippines (3 copies)
Mr Philip Brandler, Food Engineering Laboratory, US Army Natick RDT & E Center,
Attn: STRNC-Y, Natick MA 01760-5020, USA
Dr Elizabeth Sutphen, Department of the Army, US Army Foreign Science & Technology Center,
220 Seventh Street, NE, Charlottesville, Virginia 22901, USA
STRNC-W, US Army Natick R & D Center, Natick MA 01760-5020, USA