# UNCLASSIFIED

AD 295 585

Reproduced by the

ARMED SERVICES TECHNICAL INFORMATION ACENCY ARLINGTON HALL STATION ARLINGTON 12, VIRGINIA



UNCLASSIFIED

The second secon

SOTICE: When government or other drawings, specifications or other data are used for any purpose other than in connection with a definitely related government procurement operation, the U.S. Sovernment thereby incurs no responsibility, nor any obligation whatsoever; and the fact that the Government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data is not to be regarded by implication or otherwise as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to movincture, use or sell any patented invention that may in any way be related thereto.

SOATING and CHEMICAL AND LABORATORY

CATALOGED BY ASTIA



CCL REPORT NO. 135

THE DETERMINATION OF CHLORIDE ION CONCENTRATION

IN INHIBITED ENGINE COOLANTS

**3**Y

ROBERT WAGHER

AMCMS CODE NO. 5026-11-84205 DA PROJECT 593-32-007

9 JANUARY 1963



ABERDEEN PROVING GROUND MARYLAND

DESTROY; DO NOT RETURN

#### ASTIA AVAILABILITY NOTICE

Qualified requesters may obtain copies of this report from the Armed Services Technical Information Agency, Arlington Hall Station, Arlington 12, Virginia.

Copies available at Office of Technical Services, \$ 0.50

THE FINDINGS IN THIS REPORT ARE NOT TO BE CONSTRUED AS AM OFFICIAL DEPARTMENT OF THE ARMY POSITION.

## TABLE OF CONTENTS

	Page No.
TITLE PAGE	11
ABSTRACT	111
INTRODUCTION	1
DETAILS OF TEST	1 - 2
DISCUSSION	2
REFERENCES	Ž
APPENDIX	3
Tables   \$ 11	4
OLCTRIBUTION LICT	E _ 6

1

#### UNCLASSIFIED

Repo	rt No	CCL #	135	
Сору	Number			

#### THE DETERMINATION OF CHLORIDE ION CONCENTRATION IN INHIBITED

ENGINE COOLANTS

Ву

Robert Wagner

9 January 1963

AMCMS Code 5026.11.84205

Dept of the Army Project No-593-32-007

Coating and Chemical Laboratory Aberdeen Proving Ground Maryland

UNCLASSIFIED

AUTHOR: Cherken Chemist

Chemical Cleaning &

Corrosion Branch

Chemical Cleaning & Corrosion Branch

C. F. PICKETT, Technical Director

Coating & Chemical Laboratory

#### ABSTRACT

It is important to determine the concentration of chloride ions in engine coolants, as their presence greatly accelerates corresion of the system. The presence of mercaptobensothlazole in inhibited coolants interferes with this determination. A method to determine chlorides in inhibited coolants is described.

#### 1. INTRODUCTION

The presence of chlorides greatly accelerates the onset and rate of corrosion in an automotive cooling systems. One of the difficulties encountered in the chloride determination is the presence of mercaptobenzothizable and dyes. The purpose of this work was to develop a method of analysis for chlorides even in the presence of mercaptobenzothiazole. Chloride lons even in concentrations as low as 10 ppm accelerate the corrosion process.

#### 11. DETAILS OF TEST

#### A. Reagents:

Ammonium thiocyanate - 0.05N: Dissolve 3.8 grams and make up to 1 liter with distilled water.

Ferric alum indicator: Decolorize a saturated aqueous solution of ferric ammonium sulfate with colorless concentrated ni\*ric acid.

Hydrogen peroxide - 30%.

Nitric acid 1:1.

Silver nitrate - 0.1N: Dissolve 17.0 grams and make up to 1 liter with distilled water. Standardize against sodium chloride. Calculate the equivalence as grams chloride per milliliter(E).

Sodium chloride: Dissolve 0.329 grams sodium chloride and make up to 1 liter with distilled water. Standardize by precipitating with silver nitrate.

#### B. Procedure:

Fifty milliliters of the sample are pipetted into a 300 ml. Erlenmeyer flask. Standard sodium chloride solution equal to 1 milligram chloride ion (this is equivalent to 20 ppm chloride) is added to the sample. Five milliliters of hydrogen peroxide are added, the contents thoroughly mixed and then let stand for 2 hours. It is then heated rapidly to boiling and the contents boiled gantly for 10 minutes. Cool the sample to room temperature and acidify with nitric acid.

Pipet 5.0 ml. of standard silver nitrate into the flask and mix thoroughly. Two milliliters of ferric alum indicator and 2 ml. cyclohexanol or nitrate are added and the flask is shaken vigorously. The excess silver nitrate is titrated with 0.05N ammonium thiocyanate (B).

A blank is carried through all the steps in the procedure and the volume of ammonium thiocyanate to titrate the blank (A) is equivalent to 5.0 ml. silver nitrate.

Concentration of chlorides, ppm = (A-B)(f) - 20.0

- A = volume ammonium thiocyanate equivalent to 5.0 ml. silver nitrate.
- B = volume ammonium thiocyanate to titrate excess sliver nitrate.

E = equivalence of silver nitrate in grams chloride per milliliter.

#### 111. DISCUSSION

The eight references for chloride determinations are not applicable in the presence of mercaptobenzothiazole. Mercaptobenzothiazole is one of the ingredients in Specification 0-1-490 and is also used in commercial inhibitors and antifreeze.

As mercaptobenzothiazole reacts with silver nitrate it is titrated as chloride. Hydrogen peroxide effectively oxidizes mercaptobenzothiazole in water or antifreeze solutions under the test conditions specified. Variations in test method as specified leads to incomplete oxidation of mercaptobenzothiazole, which interferes with the determination of chlorides.

Chloride addition was resorted to because the method is accurate only when concentration of chlorides exceeds 15 ppm and increasing the concentration of chlorides by evaporation is not practically applicable to glycol solutions.

The factor, 1.037, was obtained by calculating the ratio of chloride present to that determined and is substantially constant as shown in Table I whether determined in antifreeze or in water.

The results of tests using this procedure are given in Table !!.

#### IV. REFERENCES

- 1. American Society for Testing Materials, Method D 512-55, "Chloride Ion in Industrial Water and Industrial Waste Water".
- Furman, N. H., ed., "Scotts Standard Methods of Chemical Analysis", 272,
   D. Van Nostrand, New York (1939).
- 3. Hanna, J. G., Jura, J., J. Anal. Chem. 31, 1820 (1959).
- 4. Juliard, A. L., J. Anal. Chem. 30,137 (1958).
- 5. Kakihanc, H., J. Chem. Soc. Japan 71,481 (1950) quoted from CA 45-6125c.
- 6. Fartin, A. J., J. Anal. Chem. 30,233 (1958).
- 7. Northrop, J. H., J. Gen. Phys. 31,213 (1948) quoted from CA 42-2891d.
- 8. Shilov, E. A., Zhur. Anel. Khim. 3,232-5 (1948), quoted from CA 43-8947f.
- 9. Wagner, A., Mitt. Ver. Grosskesselbesitzer 52,50-3 (1958) quoted from CA 52-10798a.

APPENDIX

TABLE 1 - DETERMINATION OF FACTOR

Antifreeze-	50% with 0.7	15% 0-1-490 In	hibitor	Water with	1.5% 0-1-490	Inhibitor
Chlorides: (Ppm)	Present	Determined	Factor	Present	Determined	Factor
(. p)	16.0	15.3	1.037	22.2	21.6	1.028
	26.0	25.0	1.040	27.2	25.9	1.048
	31.0	29.9	1.037	52.2	50.4	1.035
	56.0	53.7	1.043	102.2	98.8	1.034
	106	102	1.039		•	_
	206	199.5	1.033			

TABLE	 ACCURACY	AF	METHAN
IABLE	 ACCURACY	ur	PE INCE

Antifreeze-	50% with 0.	75% 0-1-	490 Inhibitor	Water with	1.5% 0	-1-490 Inhibitor
Chlorides:	Present	Found	Percent Error	Present	Found	Percent Error
	6.0	5.9	1.7	22.2	22.4	0.9
	16.0	15.9	0.6	27.2	26.9	1.1
	26.0	25.9	0.4	52.2	52.2	0.0
	31.0	31.0	0.0	102.2	102.3	0.1
	56.0	55.7	0.6		_	
	106.0	105.8	0.2			
	206.0	206.9	0.5			

### DISTRIBUTION LIST FOR AMONS CODE 5026.11.842

Department of Defense	No. of Copies
Armed Services Technical Information Agency Arlington Hall Station Arlington 12, Virginia	10
Department of the Army - Technical Service	
Commanding General	
U.S. Army Materiel Command ATTN: AMCORTB	1
Washington 25, D. C.	·
Continental Army Command	
Department of the Army	3
Fort Monroe, virginia	
Commanding General	
U.S. Army Mobility Command U.S. Army Tank-Automotive Center	
ATTN: Mr. J. P. Jones	1
Mr. V. Pogano	i
Center Line, Michigan	•
Commanding Officer	
U.S. Army Munitions Command	
Frankford Arsenal	
ATTN: SMUFA 1320	1
Library	ī
Philadelphia 37, Pa.	
Commanding Officer	
U.S. Army Materials Research Agency	
Watertown Arsenal	2
ATTN: Technical Information Center	
Watertown 72, Mass.	
Commanding Officer	
Harry Diamond Laboratory	_
ATTN: Library	1
Washir ton 25, D. C.	
Commanding Officer	
U.S. Army Test Activity	
Yuma Test Activity	1
Yuma, Arizona	
Commanding Officer	
U.S. Army Munitions Command	
Picatinny Arsenal	•
ATTN: Mr. J. J. Begley	1
Dover, New Jersey	

## DISTRIBUTION LIST CONTINUED

	No. of Coples
Commanding Officer	
U. S. Army Ballistic Research Laboratories	
ATTN: Mr. W. C. Pless Nr. R. Elchelberger	 
Mr. J. Sperrazza	i
Aberdeen Proving Ground, Maryland	
Technical Library	2
Aberdeen Proving Ground, Maryland	
Department of the Navy	
Department of the Navy	
c/o Navy Lieison	1
Aberdeen Proving Ground, Maryland	
Commender	
U.S. Navel Weapons Laboratory	1
Dahlgren, Virginie :	
Department of the Navy	
Chief, Bureau of Naval Weapons	1
Washington 25, D. C.	
Other Government Agencies	
Scientific and Technical Information Facility	
ATTN: NASA Representative (S-AK/DL)	3
P. G. Box 5700 Bethesda, Maryland	
·	
Office of Technical Services	
Aquisitions Section Department of Commerce	100
Washington 25, D. C.	100
Foreign Address	
Hinist,, of Supply Staff	
British Joint Services Mission	
1800 K Street, N. W.	2
Washington 6, D. C.	
Canadian Army Staff	
ATTN: G50-1 A&R Section	•
2450 Massachusetts Avenue, N. W. Washington 8, D. C.	2
national at at at	

AD No  Coating & Chemical Laboratory, Aberdeen Proving Ground, Md., CCL # 135 - THE DETERMINATION OF CHLORIDE ION CONCENTRA- TION IN INHIBITED ENGINE COOLANTS - Robert Wagner, Rpt No 135, 9 January 1963 9 pgs, ANCHS Code 5026.11.84205, DA Proj No 593-32-007 It is important to determire the concentration of chloride ions in engine coolants, as their presence greatly accelerates corrosion of the system. The presence of mercaptobenzothiazole in inhibited coolants interferes with this determination. A method to determine chlorides in inhibited coolants is	AD No Accession No Costing & Chemical Laboratory, Aberdeen Proving Ground, Nd., CCL # 135 - THE DETERMINATION OF CHLORIDE ION CONCENTRATION IN INHIBITED ENGINE COOLANTS - Rubert Wagner, Rpt No 135, 9 Jamiary 1962 9 pgs, AMCMS Code 5026.11.84205, DA Proj No 593-32-007  It is important to determine the concentration of chloride ions in engine coolants, as their presence greatly accelerates corrosion of the system. The presence of mercaptobenzothiazole in inhibited coolants interferes with this determination. A method to determine chlorides in inhibited coolants is described.
Unclassified	Unclass if ied
Unclass if ied	Unclass i fied
AD NO Accession No Coating & Chemical Laboratory, Aberdeen Proving Ground, Md., CCL # 135 - THE DETERMINATION OF CHLORIDE ION CONCENTRATION IN INHIBITED FINGINE COOLANTS - Robert Magner, Rpt No 135, 9 January 1963 9 pgs, ANCHS Code 5026.11.84205, DA Proj No 593-32-007  It is important to determine the concentration of chloride ions in engine coolants, as their presence greatly accelerates corrosion of the system. The presence of mercaptobenzothiazole in inhibited coolants interferes with this determination. A method to determine chlorides in inhibited coolants is	Coating & Chemical Laboratory, Aberdeen Proving Ground, Md., CCL # 135 - THE DETERMINATION OF CHLORIDE ION CONCENTRATION IN INHIBITED ENGINE COOLANTS - Robert Wagner, Rpt No 135, 9 January 1963 9 pgs, ANCHS Code 5026.11.84205, DA Proj No 593-32-007  It is important to determine the concentration of chloride ions in engine coolants, as their presence greatly accelerates corrosion of the system. The presence of mercaptobenzothiazole in inhibited coolants interferes with this determination. A method to determine chlorides in inhibited coolants is