

AD-A116 790

EIC LABS INC NEWTON MA

F/G 10/3

LITHIUM CYCLING IN POLYMETHOXYMETHANE SOLVENTS.(U)

JUN 82 J S FOODS, J MCVEIGH

N00014-77-C-0155

UNCLASSIFIED

TR-7

MI

1 of 1  
AD A  
116790

END  
DATE  
FILMED  
09-82  
DTIC

12

OFFICE OF NAVAL RESEARCH

Contract No. N00014-77-C-0155

Task No. NR 359-638

TECHNICAL REPORT NO. 7

LITHIUM CYCLING IN POLYMETHOXYMETHANE SOLVENTS

by

J. S. Foos and J. McVeigh

Prepared for Publication

in the

Journal of the Electrochemical Society

EIC Laboratories, Inc.  
67 Chapel Street  
Newton, Massachusetts 02158

June 1982

Reproduction in whole or in part is permitted for  
any purpose of the United States Government

Approved for Public Release; Distribution Unlimited

DTIC  
ELECTE  
JUL 12 1982  
S D D

82 07 12 015

AD A116790

ENC FILE COPY

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM	
1. REPORT NUMBER TECHNICAL REPORT NO. 7	2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER	
4. TITLE (and Subtitle) LITHIUM CYCLING IN POLYMETHOXYMETHANE SOLVENTS		5. TYPE OF REPORT & PERIOD COVERED Technical Report	
		6. PERFORMING ORG. REPORT NUMBER	
7. AUTHOR(s) J. S. Foos and J. McVeigh		8. CONTRACT OR GRANT NUMBER(s) N00014-77-C-0155	
9. PERFORMING ORGANIZATION NAME AND ADDRESS EIC Laboratories, Inc. 67 Chapel Street Newton, Massachusetts 02158		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS NR 359-638	
11. CONTROLLING OFFICE NAME AND ADDRESS Office of Naval Research/Chemistry Program Arlington, Virginia 22217		12. REPORT DATE June 1982	
		13. NUMBER OF PAGES 11	
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)		15. SECURITY CLASS. (of this report) UNCLASSIFIED	
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE	
16. DISTRIBUTION STATEMENT (of this Report)  Approved for Public Release; Distribution Unlimited.		Accession For NTIS GRA&I <input checked="" type="checkbox"/> DTIC TAB <input type="checkbox"/> Unannounced <input type="checkbox"/> Justification	
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		By Distribution/ Availability Codes Dist Avail and/or Special A	
18. SUPPLEMENTARY NOTES  Submitted for Publication in the Journal of the Electrochemical Society.		DATE COPY INSPECTED 3	
19. KEY WORDS (Continue on reverse side if necessary and identify by block number)  Lithium Batteries, Dimethoxymethane, Trimethoxymethane, LiAsF <sub>6</sub> , Cycling Efficiency.			
20. ABSTRACT (Continue on reverse side if necessary and identify by block number)  Solutions of LiAsF <sub>6</sub> in dimethoxymethane (DMM) and trimethoxymethane (TMM) are shown to be conductive and capable of cycling Li in high efficiency in half-cells. Inspection of electrolytes stored at 70°C in the presence and absence of Li indicated that TMM is more stable than DMM. However, DMM cycles Li much better than TMM after storage.			

DD FORM 1473

JAN 73

EDITION OF 1 NOV 65 IS OBSOLETE

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)


## LITHIUM CYCLING IN POLYMETHOXYMETHANE SOLVENTS

J. S. Foos and J. McVeigh  
EIC Laboratories, Inc., 67 Chapel Street, Newton, MA 02158

### Introduction

During the past few years several Li battery electrolytes have been reported which allow the plating and stripping of Li in greater than 95% efficiency at 25°C. Newman reported the use of LiClO<sub>4</sub> in dioxolane in Li/TiS<sub>2</sub> cells (1). The cycling efficiency in these cells is very good but unfortunately they are susceptible to detonation (2). Koch has reported the use of 2-methyltetrahydrofuran (2Me-THF) (3) and diethyl ether blends (4) as solvents for LiAsF<sub>6</sub> in Li half-cells. The conductivity of these electrolytes is low.

The solution of LiAsF<sub>6</sub> in dioxolane is an electrolyte with good conductivity but is reported to polymerize readily (5). Ring strain may contribute to the reactivity of dioxolane. It might be anticipated that the open-chain analogues of dioxolane might be less reactive. Dimethoxymethane (DMM)I and trimethoxymethane (TMM)II were investigated as solvents for possible use with LiAsF<sub>6</sub> in Li batteries.



I



II

We wish to report that these solvents produce conductive solutions with LiAsF<sub>6</sub>, show good stability at 70°C, and cycle Li well in half cell tests.

## Experimental

The solvents, DMM and TMM (trimethyl orthoformate), were obtained from the Aldrich Chemical Company. Before use the solvents were purified first by preliminary drying using  $\text{MgSO}_4$  and/or molecular sieves (3A or 4A) for DMM; and molecular sieves (3A or 4A) only for TMM. Subsequently they were distilled from Na benzophenone ketyl (6). Some difficulty was encountered in forming the blue ketyl in TMM. This was attributed to surface films on the Na which can be disrupted by placing the reaction flask in an ultrasonic bath.

The electrolytes for cycling and storage tests were prepared using  $\text{LiAsF}_6$  (U.S. Steel, as-received) with cooling using Cu shot previously cooled by dry ice. The solvents, if treated with alumina, were passed through a column of activated alumina (Woelm N-Super 1) and the first 10% discarded. Where applicable, pre-electrolyses were done by passing a current ( $1 \text{ mA/cm}^2$ ) between two Li metal electrodes ( $\sim 30 \text{ cm}^2$ ) suspended in the electrolyte (100 ml) for  $\sim 16$  hrs.

Conductivities were obtained using dried distilled DMM and TMM. The conductivities were determined in conductivity cells with cell constants determined using aqueous KCl. An AC conductivity bridge (YSI Model 31) was used to measure the cell resistance. The conductivities were determined at, or corrected to,  $25^\circ\text{C}$  with a precision of  $\sim 5\%$ .

The storage tests were done in screw cap (Teflon-lined) glass vials. These were stored at  $70^\circ\text{C}$ .

The Li cycling was done in prismatic glass cells containing 15-20 ml electrolyte. This experiment, described previously (7), involves making a pre-plate of 4.5 C/cm<sup>2</sup> of Li on a Ni substrate (Ni shim) followed by stripping and then re-plating 1.1 C/cm<sup>2</sup> on the pre-plated Li. The average efficiency per cycle  $\bar{E}$ , is calculated in Eq. (1):

$$E = \frac{Q_s - \frac{Q_{ex}}{n}}{Q_s} \quad (1)$$

where n is the number of apparent "100%" cycles,  $Q_s$  is the charge stripped (1.1 C/cm<sup>2</sup>), and  $Q_{ex}$  is the charge in the excess Li (3.4 C/cm<sup>2</sup>) at the start of the experiment.

Solution preparation and the electrochemical experiments themselves were conducted at room temperature under an Ar atmosphere in a Vacuum-Atmospheres Corporation dry box equipped with a Model HE-493 Dri-Train.

## Results

Conductivity of Electrolytes. In order to minimize electrolyte IR drop, the electrolyte in a battery should show maximum conductivity. The solvents I and II give electrolytic solutions with greater conductivities than most other non-cyclic ethers.

The conductivities of solutions of LiAsF<sub>6</sub> in ethers are generally high as compared to solutions of other salts such as LiClO<sub>4</sub>, LiBF<sub>4</sub>, etc. For instance, the maximum conductivity of LiAsF<sub>6</sub> in THF is 0.017 Ω<sup>-1</sup> cm<sup>-1</sup> (7) as compared to 0.006 and 0.004 for LiClO<sub>4</sub> (8) and LiBF<sub>4</sub> (9), respectively. The ethereal solutions of LiAsF<sub>6</sub> previously known to cycle Li with high efficiency, i.e., 2Me-THF and DEE blends, have maximum specific conductivities in the 0.002-0.004 Ω<sup>-1</sup> cm<sup>-1</sup> range.

Conductivity vs. concentration profiles for  $\text{LiAsF}_6$  in DMM and TMM are shown in Figure 1. The conductivity profiles are typical for solutions of  $\text{LiAsF}_6$  in ethers and show maximum conductivities of  $\sim 0.0065 \Omega^{-1} \text{ cm}^{-1}$  for DMM and  $\sim 0.008 \Omega^{-1} \text{ cm}^{-1}$  for TMM.

Lithium Cycling in Half-Cells. The plating and stripping of Li at  $25^\circ\text{C}$  is a rigorous test of electrolyte stability. Electrolytes were evaluated for half-cell cycling efficiency using electrolytes prepared using distilled solvent (D), distilled solvent treated with alumina (DA), and electrolytes that were additionally pre-electrolyzed (DP).

The freshly plated Li, generated during pre-electrolysis, should be especially reactive. It was hoped that this Li would react with impurities in the electrolyte giving insoluble reaction products and thereby purify the electrolyte. The results for DMM and TMM electrolytes are shown in Table 1. This table shows representative cycling efficiencies which illustrate the effect of different purification on Li cycling. In these tests, both electrolytes show high cycling efficiency.

Electrolyte Stability at  $70^\circ\text{C}$ . The cycling test above allows the evaluation of room temperature stability of the electrolyte towards freshly plated Li over the period of the experiment, one or two days. An accelerated test for long term stability is the storage of electrolytes at  $70^\circ\text{C}$  in the presence and absence of Li. A solvent, 2Me-THF, which has proved useful in  $\text{Li/TiS}_2$  cells shows excellent stability when stored with Li at  $70^\circ\text{C}$  (7).

Stability tests were conducted by storing samples of 1.5M LiAsF<sub>6</sub> in DMM and TMM in the presence and absence of Li at 70°C. The results are shown in Table 2. The TMM appears more stable with no apparent reaction noted at 20 days at 70°C. These tests may be somewhat misleading. Although no reaction was observed visually, the TMM electrolyte stored at 70°C with Li subsequently failed completely to cycle Li. The DMM results were variable, with the results reported typical of several tests. Despite the apparent lack of stability in DMM electrolytes, the samples stored with Li retained moderate cycling ability.

#### Discussion

The conductivity of the electrolytes studied make them interesting candidates for Li battery use. However, the stability of the electrolytes under actual cell conditions is of primary concern. This includes stability towards reduction by Li and to thermal decomposition in the bulk electrolyte. The half-cell cycling results indicate a relatively high degree of stability of electrolyte towards Li. However, this test is somewhat insensitive to electrolyte decomposition due to the large excess of electrolyte present. The variation of the cycling efficiency with purification appears to be reproducible. It is attributed to variations of the levels of impurities. What is not clear is the nature of the impurities and whether they improve half-cell and storage test behavior. It may be that the electrolyte containing only pure solvent and salt would give the best results. On the other hand, perhaps small amounts of impurities may scavenge undesirable reactive intermediates. Differentiating between these possibilities is difficult.



In this work, electrolytes which were optimized in half cell work were chosen for storage tests and cycling after storage. The DMM electrolytes (D and DA) gave similar cycling efficiencies before storage and similar, though decreased, efficiencies after storage. The electrolyte purified with alumina (DA) gave contradictory results in that it appeared more stable than the DMM (D) in the presence of Li and less stable in the absence of Li. The TMM electrolyte also gave contradictory results by showing no apparent reaction in stability tests and yet failing to cycle after storage.

The above observations illustrate the difficulty in evaluating electrolytes for Li batteries half-cells and the appearance of storage tests. Further investigation of these electrolytes in Li/TiS<sub>2</sub> test cells as well as a more thorough chemical analysis of the storage tests is in progress.

We wish to acknowledge the support of the Office of Naval Research for this research.

## References

1. G. H. Newman in Proceedings of the Workshop on Lithium Nonaqueous Battery Electrochemistry, Vol. 80-7, the Electrochemical Society, Pennington, NJ, 143 (1980).
2. G. H. Newman, R. W. Francis, L. H. Gaines and B. M. L. Rao, J. Electrochem. Soc., 127, 2025 (1980).
3. V. R. Koch and J. H. Young, Science, 204, 499 (1979).
4. V. R. Koch, J. L. Goldman, C. J. Mattos and M. Mulvaney, J. Electrochem. Soc. 129, 1 (1982).
5. P. G. Glugla in Proceedings of the Symposia on Power Sources for Bio-medical Implantable Applications and Ambient Temperature Lithium Batteries, B. B. Owens and N. Margalit, eds., Vol. 80-4, The Electrochemical Society, Pennington, NJ, 407 (1980).
6. V. R. Koch, J. Electrochem. Soc., 126, 181 (1979).
7. J. L. Goldman, R. M. Mank, J. H. Young and V. R. Koch, J. Electrochem. Soc., 127, 1461 (1980).
8. P. Jagodzinski and S. Petrucci, J. Phys. Chem., 78, 917 (1974).
9. S. D. James, J. Chem. Eng. Data, 23, 313 (1978).

**FIGURE CAPTION**

**Fig. 1. Conductivity of  $\text{LiAsF}_6$  solutions in DMM and TMM (25°C).**




TABLE 1  
HALF-CELL CYCLING TESTS USING DMM AND TMM ELECTROLYTES

1.5M LiAsF <sub>6</sub> in DMM	(D)	97.3%
	(DA)	97.5%
	(DP)	96.5%
1.5M LiAsF <sub>6</sub> in TMM	(D)	93.2%
	(DP)	95.1%

TABLE 2  
STORAGE TESTS AND CYCLING AFTER STORAGE USING DMM AND TMM  
ELECTROLYTES AT 70°C

<u>Solvent</u>	<u>With Li</u>	<u>Without Li</u>
DMM (D)	Electrolyte clear with a small amount of Li corrosion at 10 days.	Electrolyte clear >10 days then darkened rapidly.
DMM (D)	Cycled after 10 days storage with Li → 87.5%.	
DMM (DA)	Electrolyte clear with a small amount of Li corrosion, > 1 month.	Electrolyte dark at 6 days.
DMM (DA)	Cycled after 10 days storage with Li → 86.9%.	
TMM (D)	No reaction at 20 days.	No reaction at 20 days.
TMM (DP)	Cycled after 14 days with Li (no reaction) → 0%.	

## DISTRIBUTION LIST

Office of Naval Research  
Attn: Code 472  
800 North Quincy Street  
Arlington, VA 22217

ONR Branch Office  
Attn: Dr. George Sandoz  
536 South Clark Street  
Chicago, IL 60605

ONR Area Office  
Attn: Scientific Department  
715 Broadway  
New York, NY 10003

ONR Western Regional Office  
1030 East Green Street  
Pasadena, CA 91106

ONR Eastern/Central Regional Office  
Attn: Dr. L. H. Peebles  
Building 114, Section D  
666 Summer Street  
Boston, MA 02210

Director, Naval Research Laboratory  
Attn: Code 6100  
Washington, DC 20390

The Assistant Secretary  
of the Navy (RE&S)  
Department of the Navy  
Room 4E736, The Pentagon  
Washington, DC 20350

Commander, Naval Air Systems  
Command  
Attn: Code 310C (H. Rosenwasser)  
Department of the Navy  
Washington, DC 20360

Defense Technical Information Ctr  
Building 5, Cameron Station  
Alexandria, VA 22314

Dr. Fred Saalfeld  
Chemistry Division, Code 6100  
Naval Research Laboratory  
Washington, DC 20375

U.S. Army Research Office  
Attn: CRD-AA-IP  
P. O. Box 12211  
Research Triangle Park, NC 27709

Naval Ocean Systems Center  
Attn: Mr. Joe McCartney  
San Diego, CA 92152

Naval Weapons Center  
Attn: Dr. A. B. Amster  
Chemistry Division  
China Lake, CA 93555

Naval Civil Engineering Laboratory  
Attn: Dr. R. W. Drisko  
Port Hueneme, CA 93401

Department of Physics & Chemistry  
Naval Postgraduate School  
Monterey, CA 93940

Dr. A. L. Slafkosky  
Scientific Advisor  
Commandant of the Marine Corps  
(Code RD-1)  
Washington, DC 20380

Office of Naval Research  
Attn: Dr. Richard S. Miller  
800 North Quincy Street  
Arlington, VA 22217

Naval Ship R&D Center  
Attn: Dr. G. Bosmajian  
Applied Chemistry Division  
Annapolis, MD 21401

Naval Ocean Systems Center  
Attn: Dr. S. Yamamoto  
Marine Sciences Division  
San Diego, CA 91232

Mr. John Boyle  
Materials Branch  
Naval Ship Engineering Center  
Philadelphia, PA 19112

Dr. Rudolph J. Marcus  
Office of Naval Research  
Scientific Liaison Group  
American Embassy  
APO San Francisco, CA 96503

Mr. James Kelley  
DTNSRDC Code 2803  
Annapolis, MD 21402

Dr. Paul Delahay  
Department of Chemistry  
New York University  
New York, NY 10003

Dr. E. Yeager  
Department of Chemistry  
Case Western Reserve University  
Cleveland, OH 41106

Dr. D. N. Bennion  
Department of Chemical Engineering  
Brigham Young University  
Provo, UT 84602

Dr. R. A. Marcus  
Department of Chemistry  
California Institute of Technology  
Pasadena, CA 91125

Dr. J. J. Auburn  
Bell Laboratories  
Murray Hill, NJ 07974

Dr. Adam Heller  
Bell Laboratories  
Murray Hill, NJ 07974

Dr. T. Katan  
Lockheed Missiles & Space  
Company, Inc.  
P. O. Box 504  
Sunnyvale, CA 94088

Dr. Joseph Singer  
Code 302/1  
NASA-Lewis Research Center  
21000 Brookpark Road  
Cleveland, OH 44135

Dr. S. B. Brummer  
EIC Laboratories, Inc.  
67 Chapel Street  
Newton, MA 02158

Library  
P. R. Mallory & Company, Inc.  
Northwest Industrial Park  
Burlington, MA 01803

Dr. P. J. Hendra  
Department of Chemistry  
University of Southampton  
Southampton SO9-5NH  
UNITED KINGDOM

Dr. Sam Perone  
Department of Chemistry  
Purdue University  
West Lafayette, IN 47907

Dr. Royce W. Murray  
Department of Chemistry  
University of North Carolina  
Chapel Hill, NC 27514



Naval Ocean Systems Center  
Attn: Technical Library  
San Diego, CA 92152

Dr. C. E. Mueller  
The Electrochemistry Branch  
Materials Division, Research  
& Technology Department  
Naval Surface Weapons Center  
White Oak Laboratory  
Silver Spring, MD 20910

Dr. G. Goodman  
Globe Union, Inc.  
5757 North Green Bay Avenue  
Milwaukee, WI 53201

Dr. J. Boechler  
Electrochimica Corporation  
Attn: Technical Library  
2485 Charleston Road  
Mountain View, CA 94040

Dr. P. P. Schmidt  
Department of Chemistry  
Oakland University  
Rochester, MI 48063

Dr. H. Richtol  
Chemistry Department  
Rensselaer Polytechnic Institute  
Troy, NY 12181

Dr. A. B. Ellis  
Chemistry Department  
University of Wisconsin  
Madison, WI 53706

Dr. M. Wrighton  
Chemistry Department  
Massachusetts Institute of  
Technology  
Cambridge, MA 02139

Larry E. Plew  
Naval Weapons Support Center  
Code 30736, Building 2906  
Crane, IN 47522

Dr. Stanley Ruby  
Department of Energy (STOR)  
600 E Street  
Washington, DC 20545

Dr. Aaron Wold  
Brown University  
Department of Chemistry  
Providence, RI 02192

Dr. R. C. Chudacek  
McGraw-Edison Company  
Edison Battery Division  
P. O. Box 28  
Bloomfield, NJ 07003

Dr. A. J. Bard  
University of Texas  
Department of Chemistry  
Austin, TX 78712

Dr. M. M. Nicholson  
Electronics Research Center  
Rockwell International  
3370 Miraloma Avenue  
Anaheim, CA 92803

Dr. Donald W. Ernst  
Naval Surface Weapons Center  
Code R-33  
White Oak Laboratory  
Silver Spring, MD 20910

Dr. R. P. Van Duyne  
Department of Chemistry  
Northwestern University  
Evanston, IL 60201

Dr. B. Stanley Pons  
Department of Chemistry  
University of Alberta  
Edmonton, Alberta  
CANADA T6G 2G2

Dr. Michael J. Weaver  
Department of Chemistry  
Michigan State University  
East Lansing, MI 48824

Dr. R. David Rauh  
EIC Laboratories, Inc.  
67 Chapel Street  
Newton, MA 02158

Dr. J. David Margerum  
Research Laboratories Division  
Hughes Aircraft Company  
3011 Malibu Canyon Road  
Malibu, CA 90265

Dr. Martin Fleischmann  
Department of Chemistry  
University of Southampton  
Southampton S09 5NH  
UNITED KINGDOM

Dr. Janet Osteryoung  
Department of Chemistry  
State University of New York  
at Buffalo  
Buffalo, NY 14214

Dr. R. A. Osteryoung  
Department of Chemistry  
State University of New York  
at Buffalo  
Buffalo, NY 14214

Mr. James R. Moden  
Naval Underwater Systems Center  
Code 3632  
Newport, RI 02840

Dr. R. Nowak  
Naval Research Laboratory  
Code 6130  
Washington, DC 20375

Dr. John F. Houlihan  
Shenango Valley Campus  
Pennsylvania State University  
Sharon, PA 16146

Dr. M. G. Sceats  
Department of Chemistry  
University of Rochester  
Rochester, NY 14627

Dr. Alan Bewick  
Department of Chemistry  
The University  
Southampton, S09 5NH  
UNITED KINGDOM

Dr. A. Himy  
NAVSEA-5433  
NC No. 4  
2541 Jefferson Davis Highway  
Arlington, VA 20362

Dr. John Kincaid  
Department of the Navy  
Strategic Systems Project Office  
Room 901  
Washington, DC 20376

M. L. Robertson, Manager  
Electrochemical Power Sonics Division  
Naval Weapons Support Center  
Crane, IN 47522

Dr. Elton Cairns  
Energy & Environment Division  
Lawrence Berkeley Laboratory  
University of California  
Berkeley, CA 94720

Dr. Bernard Spielvogel  
U. S. Army Research Office  
P. O. Box 12211  
Research Triangle Park, NC 27709

Dr. Denton Elliott  
Air Force Office of Scientific  
Research  
Building 104  
Bolling Air Force Base  
Washington, DC 20332

8-8  
DTIC