

AD-A152 184

TRANSFORMATION OF NITROGEN OXIDES WHILE SAMPLING  
COMBUSTION PRODUCTS(U) CALIFORNIA UNIV IRVINE  
COMBUSTION LAB J W GROVE ET AL FEB 85 UCI-ARTR-84-8  
AFESC/ESL-TR-84-41 AFOSR-78-3586


1/1

UNCLASSIFIED

F/G 21/2

NL

											END			



MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS-1963-A

2

ESL-TR-84-41

# Transformation of Nitrogen Oxides While Sampling Combustion Products

J.W. GROVE  
G.S. SAMUELSEN

FEBRUARY 1985


FINAL REPORT

SEPTEMBER 1978 - DECEMBER 1983

DTIC  
ELECTE  
APR 4 1985  
S  
B

APPROVED FOR PUBLIC RELEASE; DISTRIBUTION UNLIMITED

AD-A152 184



DTIC FILE COPY



ENGINEERING AND SERVICES LABORATORY  
AIR FORCE ENGINEERING AND SERVICES CENTER  
TYNDALL AIR FORCE BASE, FLORIDA 32403

85 03 18 116

NOTICE

PLEASE DO NOT REQUEST COPIES OF THIS REPORT FROM  
HQ AFESC/RD (ENGINEERING AND SERVICES LABORATORY).  
ADDITIONAL COPIES MAY BE PURCHASED FROM:

NATIONAL TECHNICAL INFORMATION SERVICE  
5285 PORT ROYAL ROAD  
SPRINGFIELD, VIRGINIA 22161

FEDERAL GOVERNMENT AGENCIES AND THEIR CONTRACTORS  
REGISTERED WITH DEFENSE TECHNICAL INFORMATION CENTER  
SHOULD DIRECT REQUESTS FOR COPIES OF THIS REPORT TO:

DEFENSE TECHNICAL INFORMATION CENTER  
CAMERON STATION  
ALEXANDRIA, VIRGINIA 22314

REPORT DOCUMENTATION PAGE				
1a. REPORT SECURITY CLASSIFICATION Unclassified		1b. RESTRICTIVE MARKINGS		
2a. SECURITY CLASSIFICATION AUTHORITY		3. DISTRIBUTION/AVAILABILITY OF REPORT Distribution Unlimited. Approved for Public Release.		
2b. DECLASSIFICATION/DOWNGRADING SCHEDULE				
4. PERFORMING ORGANIZATION REPORT NUMBER(S) UCR-ARTR-84-8		5. MONITORING ORGANIZATION REPORT NUMBER(S) ESL Technical Report 84-41		
6a. NAME OF PERFORMING ORGANIZATION UCI Combustion Laboratory	6b. OFFICE SYMBOL <i>(If applicable)</i>	7a. NAME OF MONITORING ORGANIZATION Department of the Air Force Hg AF Engineering and Services Center/RDVC		
6c. ADDRESS (City, State and ZIP Code) Mechanical Engineering University of California Irvine, California 92717		7b. ADDRESS (City, State and ZIP Code) Tyndall Air Force Base Florida 32403		
8a. NAME OF FUNDING SPONSORING ORGANIZATION Department of the Air Force	8b. OFFICE SYMBOL <i>(If applicable)</i>	9. PROCUREMENT INSTRUMENT IDENTIFICATION NUMBER AFOSR Grant # 78-3586		
8c. ADDRESS (City, State and ZIP Code) Hg AF Engineering and Services Center/RDVC Tyndall Air Force Base, Florida 32403		10. SOURCE OF FUNDING NOS		
		PROGRAM ELEMENT NO 62601F	PROJECT NO 1900	TASK NO 20
				WORK UNIT NO 02
11. TITLE (Include security classification) Transformation of Nitrogen Oxides While Sampling Combustion Products				
12. PERSONAL AUTHOR(S) J.W. Grove and G.S. Samuelson				
13a. TYPE OF REPORT Final	13b. TIME COVERED FROM Sep 1978 to Dec 1983	14. DATE OF REPORT (Yr., Mo., Day) February 1985	15. PAGE COUNT 28	
16. SUPPLEMENTARY NOTATION Availability of this report is specified on reverse of front cover.				
17. COSATI CODES		18. SUBJECT TERMS (Continue on reverse if necessary and identify by block number)		
FIELD	GROUP	SUB GR		
07	01		Exhaust Sampling, Exhaust Composition, Combustion	
21	05			
19. ABSTRACT (Continue on reverse if necessary and identify by block number)  The objective of the program was to assess the condition under which transformations of nitrogen oxides (NO and NO <sub>2</sub> ) may occur in an extractive probe used to sample exhaust gases from combustor sources such as gas turbine engines and boilers. The approach was to use simulated combustion products in a controllable laboratory experiment. Trials were run using 2-meter (79-inches) long, 6.35 mm (0.25-inch) OD tubing. Tubing materials considered included type 316 stainless steel, quartz, inconel, and nickel. Various gaseous compositions, including those representative of gas turbine exhausts, were evaluated for various temperatures over a range (150°C to 400°C) typical of the temperatures experienced by probe materials in practical systems.  NO <sub>x</sub> is conserved in 316 stainless steel and quartz tubes up to 400°C. Above 400°C, NO <sub>x</sub> can be destroyed.				
20. DISTRIBUTION AVAILABILITY OF ABSTRACT UNCLASSIFIED UNLIMITED <input checked="" type="checkbox"/> SAME AS RPT <input checked="" type="checkbox"/> DTIC USERS <input type="checkbox"/>		21. ABSTRACT SECURITY CLASSIFICATION		
22a. NAME OF RESPONSIBLE INDIVIDUAL Maj. F. Thomas Lukozynski		22b. TELEPHONE NUMBER <i>(Include Area Code)</i> (904) 283-4334	22c. OFFICE SYMBOL HQ AFESC/RDVS	

The ratio of  $\text{NO}_2/\text{NO}$  is conserved up to  $300^\circ\text{C}$  in 316 stainless steel and  $400^\circ\text{C}$  in quartz. The present results were not changed appreciably by the presence or absence of water with one notable exception. In the stainless steel, the reactivity of the probe (reduction of  $\text{NO}_2$  to  $\text{NO}$ ) was significantly increased above  $300^\circ\text{C}$  (20- to 85-percent at  $400^\circ\text{C}$ ) when both oxygen and high levels of hydrocarbons were present.

Stainless steel is more rugged than quartz and, as a result, more commonly used as a sampling probe material. The exploration of alternative metallic tube materials, such as nickel and inconel, was not successful in identifying a durable tube material that was less reactive than 316 SS. Both nickel and inconel were more reactive.

Based on the results of this study, quartz is the most desirable material to use for sampling at elevated temperatures. Quartz was inert to all the sample compositions and sample temperatures explored in the present experiment. The one practical exception to the use of quartz is the vulnerability to breakage. Stainless steel tubes with quartz glass linings, available commercially, represent a reasonable solution where sample integrity is a major objective and reasonable handling of the probe can be maintained.

Should quartz or quartz-lined stainless steel not be an option, then type 316 stainless steel is a reasonable alternative. However, if stainless steel is used at temperatures exceeding  $200^\circ\text{C}$ , the tube should be water-cooled to ensure maintenance of sample integrity. Care must be exercised to cool the tube with hot water ( $> 60^\circ\text{C}$ ) to ensure that water in the combustion products does not condense.



TABLE OF CONTENTS

Section	Title	Page
I	INTRODUCTION . . . . .	1
II	EXPERIMENTAL METHODS . . . . .	2
	A. CARRIER GASES. . . . .	2
	B. THE EXPERIMENT . . . . .	2
	1. Gas Preparation. . . . .	2
	2. Probe Exposure . . . . .	5
	3. Analysis . . . . .	5
III	RESULTS. . . . .	6
	A. TEST MATRIX. . . . .	6
	B. PARAMETERS . . . . .	6
	1. Probe Exposure Cycles. . . . .	6
	2. Probe Preconditioning. . . . .	6
	3. Carrier Compositions . . . . .	10
	4. Presence of Water. . . . .	10
	5. Probe Material . . . . .	10
IV	CONCLUSIONS. . . . .	14
	REFERENCES . . . . .	15

LIST OF FIGURES

Figure	Title	Page
1	Experimental System . . . . .	4
2	Sequential Exposure Cycles. . . . .	8
3	Effects of Carrier Composition. . . . .	9
4	Earlier Results (Reference 4) . . . . .	11
5	TURBINE Carrier . . . . .	12
6	Effects of Water. . . . .	13
7	Effects of Various Materials. . . . .	13

LIST OF TABLES

Table	Title	Page
1	NO Sampling Carrier Gas Composition . . . . .	3
2	Probe Types and Carrier Compositions Tested . . . . .	7

## SECTION 1

### INTRODUCTION

To assess the conditions under which transformations of nitrogen oxides (NO and NO<sub>2</sub>) may occur in a gaseous sample probe, a controllable laboratory experiment was designed and used in an earlier study to systematically establish the conditions under which NO and NO<sub>2</sub> could be transformed and the extent of transformation (References 1, 2, 3, and 4). Under an AFOSR program at the UCI Combustion Laboratory (Grant 78-3586), the Environics Division of the Air Force Engineering and Services Center (AFESC/RDV) provided supplemental funding to modify the experiment to (1) include water vapor in the simulated combustion products, (2) provide more precise control over the temperature and history of the pollutant mixture prior to sampling, and (3) simulate gas turbine exhaust products as well as reacting zone gases, automobile exhausts, and boiler flue gases.

The experiment was successfully modified and operated. Various compositions of simulated exhaust gases, including those representative of gas turbine exhausts, were run through sample probes of varying materials and analyzed for nitrogen oxide transformations. This analysis was performed for various probe temperatures over a range (150°C to 400°C) typical of the temperatures experienced by probe materials in practical systems.

Trials were run using 2-meter (79-inches) long, 6.35 mm (0.25-inch) OD tubing, and performed with and without water addition. Quartz and stainless steel (type 316) were the principal materials evaluated although Inconel-600 and Nickel-200 were considered as well. Type 316 stainless steel (316 SS) is the material commonly used for sampling purposes. Tubing stock and fittings are readily available, 316 SS is durable yet easy to bend during fabrication, and the stainless quality is resistant to corrosion. However, this resistance does not preclude surface reactions that could alter the composition of a sample. Quartz tubing, in contrast, is inert to surface attack and, as a result, is attractive for sampling. However, the vulnerability of quartz to breakage renders the material impractical except for the most controlled conditions. To assess whether durable, metallic tubes are available which are less reactive than 316 SS to sample composition transformation, two nickel-containing tube materials were selected: a nickel tube (Nickel-200) and an alloy of nickel (Inconel-600). An investigation of stainless steel composition indicated that the nickel content may be associated with an increase in resistivity to transformation (Reference 3).

## SECTION II

### EXPERIMENTAL METHODS

#### A. CARRIER GASES

Carrier gases representative of boiler and automotive exhaust, as well as combustor reaction zones, are herein referred to as STANDARD carriers; those representative of turbine jet engines are referred to as the carrier TURBINE. Compositions and concentrations of the carriers, presented in Table 1, were established, based upon surveys of practical devices (References 1, 2, 3, and 4). All STANDARD carrier gases (exclusive of water and propylene) were mixed and supplied in gas cylinders by a commercial vendor. Propylene and water, if selected, were added during the experiment. The TURBINE carrier gas was also supplied by a commercial vendor except for the water, methanol, and propanol, each of which was added in the conduct of the experiment. The baseline composition was selected, based on exploratory tests, as the condition for which NO and NO<sub>2</sub> transformation was most likely.

#### B. THE EXPERIMENT

The experimental system is shown in Figure 1. The experiment is performed in three steps: gas preparation, probe exposure (with sampling before and after the exposure), and analysis.

##### 1. Gas Preparation

The appropriate carrier gas composition is selected by means of a toggle switch located on the control panel. Upstream carrier gas pressures are maintained constant to generate a steady flow of 7 l/min. The bulk of the flow is bubbled through three 500 ml fritted glass water towers to ensure saturation if water addition ("wet trial") is to be performed. The temperature of the water in the towers is set and maintained constant for each trial to achieve the desired water concentration. For a dry trial, the carrier flow is routed around the water towers. For the TURBINE tests, a portion of the carrier is routed through 1-liter Erlenmeyer flasks used to house liquid methanol and propanol.

Enroute to the furnace from the water towers, heating tape is wrapped around the Teflon<sup>®</sup> tubing to prevent premature water condensation. In a Lindberg Model #51828 furnace, the carrier gas is circulated until it reaches the set furnace temperature. At this point, the carrier stream enters a mixing venturi - where the pollutant gases (NO, NO<sub>2</sub>, and C<sub>3</sub>H<sub>6</sub> if selected) are introduced in the proper amounts from high-concentration sources by means of flow restrictors. A sample (3 l/min) is extracted immediately after mixing is completed. (This sample location is referred to as SP2.) A flow of 4 l/min is run through the probe to be tested. At the end of the probe, another 3 l/min sample is extracted at sample point SP3, leaving 1 l/min to vent.

Temperatures are monitored at SP2, SP3, in the furnace, and just downstream of the water towers; pressures are monitored at SP2, SP3, and just upstream of the water, methanol/propanol addition system. In addition, the carrier gas flow rate is monitored just upstream of the water/methanol/propanol addition system.

TABLE 1. NO SAMPLING CARRIER GAS COMPOSITION

Carrier	Composition					
	CO <sub>2</sub> %	O <sub>2</sub> %	H <sub>2</sub> O %	HC ppm	NO ppm	NO <sub>2</sub> ppm
STANDARD	12	5	0, 14	0	500	75
	12	5	0, 14	500 propylene	500	75
	12	0	0, 14	500 propylene	500	75*
	12	0	0, 14	0	500	75
TURBINE	4	14	0, 5	18 methane 0.5 butane 34 ethylene 12 propylene 2.5 I-butene 30 methanol 3 propanol	500	75

\* Baseline composition (0-percent O<sub>2</sub>, 500 ppm HC, 0-percent water)




Figure 1. Experimental System

The samples from SP2 and SP3 are immediately cooled by water jackets in a specially designed water-cooled quartz extractor to 60°C, and transported through the furnace wall and into a Blue M oven maintained at 60°C. The oven houses various solenoids as well as a carbon NO<sub>2</sub> → NO converter. Monitored temperatures include that of the oven, of the cooling water at SP2, SP3, and at the mixing venturi, and of the converter. The NO<sub>x</sub> converter jacket temperature is controlled by a constant input voltage from a variac, and the cooling water flow rate is monitored by a rotameter just upstream of the Blue M oven.

## 2. Probe Exposure

Instrumentation used to analyze the samples includes a TECO Model 10 AR Chemiluminescent NO-NO<sub>2</sub>-NO<sub>x</sub> Analyzer, a Beckman Model 951 NO/NO<sub>x</sub> Analyzer, and a Beckman Model 590 HC/CO Analyzer. From the control panel, the SP2 and SP3 samples can be routed, by means of a solenoid off-on switch, to the TECO or to the Beckman 951. In addition, the TECO sample can be routed through or around the converter. By the use of metering valves and rotameters (located on the control panel) as well as by vents, proper flows through the probe and to the instruments are maintained regardless of the sample path. For the trials in which propylene is introduced, a small portion of the Beckman 951 sample is extracted and routed to the Beckman 590. Water is condensed out of the samples before transportation to the analyzing instruments by means of ice baths.

## 3. Analysis

The experiment is run in the following manner: with the appropriate carrier gas selected, the desired concentrations, if any, of water and methanol/propanol are added, and the NO, NO<sub>2</sub> and C<sub>3</sub>H<sub>6</sub> (if selected) are introduced at 55°C to the carrier stream at the venturi port. The temperatures of the cooling water at SP2, SP3, and at the mixing venturi, of the oven, of the converter, and of the gas just downstream of the water towers are noted. The furnace is set at 150°C and, when this temperature is achieved, the temperature of the furnace, and the temperatures and pressures of SP2 and SP3 are recorded. The following data are collected: A TECO analysis of the SP2 sample with the converter off; TECO analysis of the SP3 sample with the converter off; Beckman 951 analysis of the SP2 sample, TECO analysis of the SP2 sample with the converter on; and TFDO analysis of the SP3 sample with the converter on. The furnace temperature is then incremented 50°C (up to 400°C) and the readings above are repeated. At least four successive probe trials are necessary for the probe response to stabilize.

## SECTION III

### RESULTS

#### A. TEST MATRIX

The combinations of sample probe materials and carrier gas compositions are presented in Table 2. The parameters evaluated were probe exposure cycles, probe preconditioning, carrier composition, presence of water, and probe material.

#### B. PARAMETERS

##### 1. Probe Exposure Cycles

The probes tested are repeatedly cycled through the temperature range described above until a steady-state response is achieved. The chemical transformation observed for all tests conducted is the reduction of  $\text{NO}_2$  to  $\text{NO}$ . "Reactivity" is associated with the change of  $\text{NO}/\text{NO}_2$  concentrations from the probe inlet (SP2) to the probe outlet (SP3). If  $\text{NO}_2$  reduction is experienced in a particular trial, the probe is said to be reactive, with reactivity varying from low to high depending on the extent of  $\text{NO}_2$  reduction and the temperature at which it first occurs. The concentration of  $\text{NO}_x$  ( $\text{NO} + \text{NO}_2$ ) is also monitored and found to be conserved in all the tests reported here although in previous work, as noted below, destruction of  $\text{NO}_x$  was observed at the elevated test temperatures.

An example of sequential exposure cycles of a 316 stainless steel probe is presented in Figure 2a for the baseline case in the STANDARD matrix. The initial reactivity of the probe is very high (Cycle 1) with an 80-percent reduction of  $\text{NO}_2$  to  $\text{NO}$  and the first evidence of change at  $250^\circ\text{C}$ . By the fifth cycle, the  $\text{NO}_2$  reduction stabilizes to approximately 40 percent, and the first evidence of change occurs at  $350^\circ\text{C}$ . This behavior is typical of all the metal probes tested. Generally, three to five cycles are required for a repeatable response to be achieved. In contrast, quartz exhibits no change from that measured for the first cycle (Figure 2b).

##### 2. Probe Conditioning


For the results reported below, the probes tested were tested as received from the supplier. However, preliminary tests were conducted on 316 stainless steel to evaluate the effect of washing the probes prior to testing. The probes were first washed with trichloroethylene, rinsed with methanol, and dried at room temperature. Probes washed in this fashion proved to be more reactive. Extensive discussions with manufacturers of stainless steel tubes lead to the conclusion that this washing procedure removes residual dirt and grease from the inner tube surface, thereby exposing more sites to contribute to the initial reactivity. The decision to use probes as received (rather than washed) for the principal tests was predicated on the likelihood that those probes used in practical systems are installed as supplied.

TABLE 2. PROBE TYPES AND CARRIER COMPOSITIONS TESTED

Probe Type	Case	Carrier							
		STANDARD						TURBINE	
		O <sub>2</sub> , %		HC, ppm		Water, %		Water, %	
		0	5	0	500	0	14	0	5
316 SS, or Quartz	1	•		•		•			
	2	•		•			•		
	3		•	•		•			
	4		•	•			•		
	5	B <sup>a</sup>			B	B			
	6	•			•		•		
	7		•		•	•			
	8		•		•		•		
	9							•	
	10								•
Inconel-600, or Nickel-200	11	B			B	B			

<sup>a</sup> Baseline composition

a) 316 Stainless Steel Probe



b) Quartz Probe




Figure 2. Sequential Exposure Cycles

### 3. Carrier Composition

The composition of the carrier gas was found to be a major factor in establishing the reactivity of the 316 stainless steel. The results for the STANDARD carrier (Table 1) are summarized in Figure 3a. The reactivity is highest for the baseline case, lower for the case where both oxygen and propylene are present, and inconsequential in the absence of the propylene (for both 0 or 5 percent oxygen). In contrast to the 316 stainless steel, the quartz tube is virtually nonreactive for all STANDARD carrier compositions (Figure 3b). It is noteworthy that the 316 stainless steel and quartz reactivities are less than those observed and reported from the earlier experiment (Reference 4), an example of which is presented in Figure 4. Two factors lead to the higher reactivities in the previous work. First, the temperature was not controlled as well as in the present experiment. The probe was heated in a Lindberg tube furnace rather than in the current box furnace. As a result, the probe experienced uneven heating. An investigation of the heating variation revealed that, at a 400°C set point, the probe could locally heat to 600°C at locations where the tube was in the near vicinity of the heated filament. The design of the present experiment ensured that the temperature of the probe was maintained isothermal at the set point. Second, the sample extracted at SP2 and SP3 was not immediately cooled in the previous experiment and reaction could persist in the sampling tube. In the present experiment, the design of the sample ports included water-cooling to immediately quench the reaction.

The results for the TURBINE carrier are presented in Figure 5. The results are similar to the STANDARD carrier where both oxygen and hydrocarbon are present, albeit in differing amounts. The first transformation observed occurs at 300°C and reaches a 45-percent reduction of NO<sub>2</sub> at 400°C in 316 stainless steel.


### 4. Presence of Water

The results reported above were obtained dry (i.e., 0-percent H<sub>2</sub>O). To assess the effect of water, trials were also conducted with the water concentrations listed in Table 1, 14 percent H<sub>2</sub>O for the STANDARD carriers, and 5 percent H<sub>2</sub>O for the TURBINE carrier. The presence of water had no significant impact on reactivity for the STANDARD carriers in 316 stainless steel except for the case where both oxygen (5 percent) and hydrocarbons (500 ppm C<sub>3</sub>H<sub>6</sub>) are present. Here, the presence of water substantially increased the reactivity (Figure 6), from 20-percent to 85-percent reduction of NO<sub>2</sub> at 400°C. The impact of water in the 316 stainless steel on the TURBINE carrier, which has a higher oxygen (14 percent) and lower hydrocarbon content (~ 80 ppm), was not significant. In quartz, the water had no impact. The quartz was virtually passive for all carriers tested.

### 5. Probe Materials

In addition to the 316 stainless steel, various metallic materials were tested to determine if available alternatives to quartz would suppress the reduction of NO<sub>2</sub> at elevated temperatures. Both nickel and inconel tubes were tested, with negative results (Figure 7). Both materials exhibited substantially higher reactivity than the 316 stainless steel.

a) 316 Stainless Steel Probe



b) Quartz Probe





Figure 3. Effect of Carrier Composition

a) 316 Stainless Steel Probe



b) Quartz Probe





Figure 4. Earlier Results (Reference 4)

a) 316 Stainless Steel Probe



b) Quartz Probe




Figure 5. TURBINE Carrier




Figure 6. Effect of Water




Figure 7. Effect of Various Materials

## SECTION IV

### CONCLUSIONS

$\text{NO}_x$  is conserved in 316 stainless steel and quartz tubes up to 400°C. Above 400°C,  $\text{NO}_x$  can be destroyed.

The ratio of  $\text{NO}_2/\text{NO}$  is conserved up to 300°C in 316 stainless steel and 400°C in quartz. The present results were not changed appreciably by the presence or absence of water with one notable exception. In the stainless steel, the reactivity of the probe (reduction of  $\text{NO}_2$  to  $\text{NO}$ ) was significantly increased above 300°C (20- to 85-percent at 400°C) when both oxygen and hydrocarbons were present in the STANDARD CARRIER.

Stainless steel is more rugged than quartz and, as a result, more commonly used as a sampling probe material. The exploration of alternative metallic tube materials, such as nickel and inconel, was not successful in identifying a durable tube material that was less reactive than 316 SS. Both nickel and inconel were more reactive.

Based on the results of this study, quartz is clearly the most desirable material to use for sampling at elevated temperatures. Quartz was inert to all the sample compositions and sample temperatures explored in the present experiment. The one practical exception to the use of quartz is the vulnerability to breakage. Stainless steel tubes with quartz glass linings, available commercially, represent a reasonable solution where sample integrity is a major objective and reasonable handling of the probe can be maintained.

Should quartz or quartz-lined stainless steel not be an option, then type 316 stainless steel is a reasonable alternative. However, if stainless steel is used at temperatures exceeding 200°C, the tube should be water-cooled to ensure maintenance of sample integrity. Care must be exercised to cool the tube with hot water (> 60°C) to ensure that water in the combustion products does not condense.

#### REFERENCES

1. Benson, R.C., Samuelsen, G.S., and Peck, R.E., "Oxides of Nitrogen Transformations While Sampling Combustion Products Containing Carbon Monoxide," WSS/CI 76-11, 1976 Spring Meeting of the Western States Section, The Combustion Institute, Salt Lake City, 1976.
2. Benson, R.C., and Samuelsen, G.S., "Oxides of Nitrogen Transformation While Sampling Combustion Products Containing Carbon Monoxide, Hydrogen, and Hydrocarbons," WSS/CI 77-7, Spring Meeting of the Western States Section, The Combustion Institute, Seattle, 1977.
3. Samuelsen, G.S., and Harman, J.N., "Chemical Transformations of Nitrogen Oxides While Sampling Combustion Products," APCA Journal, Vol. 27, No. 7, July, p. 648, 1977.
4. Samuelsen, G.S., and Benson, R.C., "Chemical Transformations of Nitrogen Oxides While Sampling Combustion Products," Grosjean, D. (Ed.), Nitrogenous Air Pollutants -- Chemical and Biological Implications, Ann Arbor Science Publishers, Inc., Ann Arbor, p. 65, 1979.
5. Samuelsen, G.S., Hamberg, R.M., and Osborn, J.K., Composition and Concentration of Hydrocarbon Species Emitted from Gas Turbine Combustors, UCI Combustion Laboratory Report ARTR 78-3, Mechanical Engineering, University of California, Irvine, CA, 1978.

**END**

**FILMED**

4-85

**DTIC**