AD-A198 125 EVALUATION OF A HAND-HELD FRICTIONAL STRAIN GAUGE(U) AERONAUTICAL RESEARCH LARS HELBOURNE (AUSTMALIA) HG GILLAGON ET AL. DEC 87 ARL-STRUC-IN-476 F/G 14/2 1/1 UNCLASSIFIED NEL.



OTIC_ELE_LUES (4)

ARL-STRUC-TM-476

AR-004-469

AD-A198 125



DEPARTMENT OF DEFENCE DEFENCE SCIENCE AND TECHNOLOGY ORGANISATION AERONAUTICAL RESEARCH LABORATORY

MELBOURNE, VICTORIA

Aircraft Structures Technical Memorandum 476


EVALUATION OF A SAND HELD PRICTIONAL STRAIN GAUGE (U)

ky M.G. Scirisca and J.G. Spacrow



Approved for Public Release.





AR-004-569 55 - **6**3494 94

J. 1 . .

DEPARTMENT OF DEFENCE DEFENCE SCIENCE AND TECHNOLOGY ORGANISATION AERONAUTICAL RESEARCH LABORATORY

Aircraft Structures Technical Memorandum 476

EVALUATION OF A HAND - HELD FRICTIONAL STRAIN GAUGE (U)

bу

M.G. Stimson and J.G. Sparrow

SUMMARY

A system has been implemented at ARL for obtaining strain amplitudes using a commercially available hand applied strain gauge. The gauge measures strain when applied by hand to a cyclically loaded flat surface with the correct normal force to ensure that slipping does not occur. A gauge holder is supplied to transmit the normal force through the gauge to the test piece.

This document describes the tests done to demonstrate the system capabilities and calibrate the gauge. It was found that accuracy and repeatability were comparable with bonded strain gauges for loading frequencies from 0.1 to 25 Hz. Similar results were found when random loading was applied with excellent response observed up to 100 Hz. Strain amplitudes up to ± 0.2% elongation were successfully measured and it was shown that the surface need not be very clean for correct performance at lower strains.



(C) COMMONWEALTH OF AUSTRALIA 1987

POSTAL ADDRESS: Director, Aeronautical Research Laboratory, P.O. Box 4331, Melbourne, Victoria, 3001, Australia

CONTENTS

Section	Page No.
SUMMARY	
1. INTRODUCTION	1
2. THE INSTRUMENT	1
3. THE MEASUREMENT SYSTEM	3
4. RESULTS	5
4.1 Instron Experiments.	5
4.2 MTS Experiments.	11
4.3 Random Load Experiments.	14
6. CONCLUSION	17
ACKNOWLEDGEMENTS	18
REFERENCES	18
APPENDIX	19
DISTRIBUTION	
DOCUMENT CONTROL DATA	Accessor For NTIS consult DTIC Title United to
	Justo
DTIC COPY INSPECTED	B. per JC



Acces on Fur
MTIS COLUMN
DTIC TAN
Usar no experience
Janto .
oper JC
Acres Services
Det No. 1
A-1

4. INTRODUCTION

The Aeronautical Research Laboratories (ARL) Structures Division has acquired a commercially available instrument for obtaining strain values from a cyclically loaded flat surface. This strain gauge has the advantage over a conventional bonded gauge in that it can be applied with little or no preparation time.

This advantage makes it useful in conjunction with the SPATE 8000 thermal stress pattern imager which is usually calibrated by obtaining a cyclic strain reading from within the field of view of the article under test. Use of a conventional bonded gauge on the article necessarily obscures some area within the field of view.

Experiments were performed to show that an electrical signal linearly dependent on the strain amplitude could be obtained. The accuracy and repeatability of this signal was checked for different frequencies and effects of surface cleanliness.

Keywork, CANADA. JES

2. THE INSTRUMENT

The instrument is a 10mm gauge length strain gauge mounted on a pad which is held in a Frictional Gauge Holder (FGH-1) manufactured by Tokyo Sokki Kenkyujo Co. Ltd. (TML). The TML designation for the gauge is CBF-6. The configuration is shown in Figure 1. The "hand-held" strain gauge (HHSG) is a typical 120 Ω , copper-nickel foil gauge bonded to a rubber rectangular backing pad. The emery powder cemented over the gaugeprovides a high coefficient of friction. The higher the coefficient of friction the greater the cyclic strains that can be transmitted when a force normal to the surface is applied through the handle and spring plunger. Strains are completely transmitted up until there is slipping between specimen surface and gauge. The manufacturer [1] specifies \pm 0.1% strain to be the limit of accurate strain measurement.

Consistency of the normal force and hence, the maximum tangential reaction, is achieved by steadily maintaining the red line on the handle within the white band around the stem as shown in Figure 1. This results in a normal force of between 28 and 39 newtons.

It was sometimes convenient to provide this small force by wrapping rubber bands around the specimen and the FGH-1. However, excellent strain signal stability could be achieved by hand.

The emery surface and gauge assembly was found to be easily damaged with resulting degradation of performance. Hence, reasonable care must be taken in handling the instrument.




FIG. 1. THE INSTRUMENT

3. MEASUREMENT SYSTEM

The data acquisition equipment consisted of a SOLARTRON 1250 Frequency Response Analyser (FRA), a testing machine load cell and a strain gauge amplifier with power source. A schematic digram of the system is shown in Figure 2.

The CBF-6 gauge was connected to the amplifier in the standard Wheatstone bridge arrangement for bonded strain gauges. This involves 3 other 120 Ω dummy gauges used as resistors. The Wheatstone bridge output was boosted by approximately 3 dB and connected to channel 1 of the FRA.

The analysis carried out by the FRA was merely an integration over a number of cycles of the signal being received at the loading frequency. Synchronisation of the analyser with the FRA crystal oscillator, which was providing the loading reference signal, ensured only signals at that frequency were integrated and displayed. The FRA provided this clean sinusoidal driving signal to the loading machines since it was found that the non-crystal oscillators in the machine function generators could not show the required frequency stability.

The FRA also displayed the phase of the HHSG and the load cell relative to the driving signal it was providing. The difference between these angles is the lag between the load cell and the HHSG which includes any effect from the amplifier. It is not necessary to record the phase angle to use the HHSG, but it was recorded during this evaluation to confirm that no resonances occurred under different uniform cyclic loads and frequencies.

Random loading was applied to the specimen by feeding amplified white noise from a HP 3552A Spectrum Analyser (SA) to the Materials Testing System Corporation (MTS) testing machine control unit. The rms value of the applied load was controlled by the MTS span control knob. However, the numerical value of the load was not explicitly related to this control setting because of the random driving signal.

The load cell and amplified HHSG spectra were displayed on the screen of the SA and dumped to a HP 7090A Measurement Plotting System. This effectively showed the response of the HHSG to the load being applied. The SA was also able to obtain and plot the magnitude and phase of the transfer function between the load cell and the HHSG




FIG. 2 SYSTEM DIAGRAM.

4. RESULTS

4.1 Instron Experiments

The first successful use of the HHSG was with a flat specimen of aluminium alloy (2024-T4) loaded by the Instron 250 kN capacity servo-hydraulic testing machine.

The FRA generator signal directly controlled both the amplitude and mean load. Mean stress was constant, with 700 mV of DC offset producing 65.2 MPa in the specimen.

Strain amplitude range for these tests was from \pm 130 microstrain to \pm 1007 microstrain whilst frequencies of 0.1, 1.0 and 5.0 Hz were used. For one of the runs the amplitude was constant whilst the frequency was stepped up from 0.1 Hz to 25 Hz. In each run a note was made of the HHSG and load cell rms voltages displayed on the FRA.

The run performed at 5.0 Hz with a clean specimen surface was taken as the calibration run for the work done in the INSTRON 250 kN machine. Table 1 shows the predicted values of strain amplitude and the signal achieved from the HHSG in columns 3 and 4.

Since the digital display of load as percent of capacity on the INSTRON provided only 2 decimal places, a linear regression of indicated load against the selected FRA generator amplitude was performed. The equation of the resulting line is given in Table 1, Note 1. This enabled a reduction in the rounding errors for new values of applied cyclic load obtained with that equation. These values, shown in column 2, were then easily converted to strains since the specimen was under uniaxial tension – tension.

Regression of column 3 data with column 4 gave the following equation for obtaining applied strain from HHSG reading.

$$\Delta Strain = 1.089 \times R + 22.184 \tag{1}$$

where R = HHSG reading of rms millivolts

 Δ Strain = half peak to peak measured strain in microstrain

The calibration line represented by this equation can be seen in Figure 3.

Using the above calibration, Δ Strain values were obtained from measured voltages for another run performed at 1.0 Hz and compared with the values of Δ Strain actually applied. The comparison is shown in Table 2 and in Figure 4. Both these figures show very good linearity to the limits of accuracy of the experiments. Also, by obtaining a slope of 45 degrees in Figure 4 from the calibrated measured strains versus the applied strains, we see that the same calibration line equation as the 5.0 Hz run applies. This evidence indicates frequency independence and excellent repeatability.

Also, amplitude increasing runs similar to those above were performed at different frequencies, such as 7.0 Hz and 20.0 Hz.

The effect of frequency was investigated by performing a run where the frequency was incremented from 0.1 Hz to 25.0 Hz whilst the amplitude control was left untouched. Inevitably, the load response of the servo-hydraulic INSTRON machine dropped off with increasing frequency. However, as shown in Figure 5, the ratio of measured to applied cyclic strain remains constant as loading frequency is increased.

As before, measured HHSG signal was converted to strain using equation (1) and the predicted strain found from the applied load.

TABLE 1. Hand-Held Gauge Calibration Data

Specimen:

2024 aluminium alloy of rectangular cross-

section.

Machine:

INSTRON 250 kN electro-hydraulic.

Frequency:

5.0 Hz

FRA integration time: 10 sec.

FRA generator bias:

700 mV (mean load = 17.5 kN)

FRA Generator Output	Load Cell Indicated Amplitidue ⁽¹⁾	Calculated Strain Amplitidue ⁽³⁾	Raw HHG Amplitude
(mV) RMS	(kN) ⁽²⁾	(με) (2)	(mV) RMS
100	3.09	192	159.2
200	5,97	371	314.9
300	8.85	550	488.1
400	11.73	728	660.3
500	14.61	907	804.0
400	11.73	728	651.8
300	8.85	550	481.3
200	5.97	371	313.6
100	3.09	192	158.8

Notes:

1. Load cell indicated amplitude, (Y), in column 2 obtained by regression of raw values with FRA generator output, (X).

$$Y = 2.88 \times 10^{-2} X + 0.210$$

- These cyclically varying quantities are measured as half the peak to peak value.
- 3. Specimen area = 230 mm²
 Young's modulus = 70.2 x 10⁹ Pa.

TABLE 2. Comparision of applied Strains with HHSG Calibrated Strains

Specimen:

2024 aluminium rectangular cross-section

Machine:

INSTRON 250 kN electro-hydraulic.

Frequency:

1.0 Hz

FRA integration time: 10 sec.

FRA generator bias:

700m V

Regreassed	Calculated	Calibrated	
Indicated	Applied	HHSG Strain	
Load	Strain	Amplitude	
(kN) (2)	(_{µE}) (2)	(µE)	
2.113 3.871 5.629 7.386 9.114 10.902 12.660 14.418 16.175 14.418	131 240 350 459 566 677 786 896 1005	134 244 353 463 571 682 792 899 1008	
10.902	677	679	
7.386	459	464	
3.971	241	245	

Notes:


1. Regressed indicated load obtained from equation:

Load = 0.0352 x FRA voltage + 0.355

- These cyclically varying quantities are measured as half the peak to peak value. FRA voltage is in mV (RMS)
- 3. HHSG signal (mV), converted to strains ($\mu\varepsilon$), using the calibration equation:

Strain = HHSG signal x 1.089 + 22.184.

4. Specimen area = 230 mm². Young's modulus = 70.2 x 10 9 Pa.



HHSG output amplitude (mV)

FIG. 3. HHSG CALIBRATION LINE FOR INSTRON 250 kN MACHINE AT 5.0 Hz




FIG. 4. HAND-HELD GAUGE STRAIN OUTPUT VS APPLIED STRAIN 9




FIG. 5. FREQUENCY EFFECTS

4.2 MTS Experiments

Testing machine availability problems meant experiments continued some time later on a different machine. The specimen was again a 2024 aluminium alloy dog bone and was loaded through the same gripping system as in the INSTRON experiments.

The difference between the clean surface (Table 3 and Figure 6), and the greased surface (Table 4 and Figure 7) was so small they needed to be plotted on different graphs for clarity.

In order to investigate the surface condition effects, SHELL "ALVANA" type light grease was applied. The results presented here are for runs with only a thin smear of grease.

At amplitude levels above 1800 microstrain the signal immediately after application of the HHSG is up to 8% less than the calculated applied strain amplitude. During several periods of integration, of 10 seconds each, the signal climbed with decreasing rapidity until it stabilizes at a value which is only slightly less than could be expected from the experimental errors. As can be seen from Figures 6 and 7 the stabilised readings did not differ from the correct value by more than 10 mV in 500 mV or 2%.

This phenomenon was present when the specimen was clean, only becoming more pronounced once several smears of grease were applied. This means that a small amount of grease on the surface does not significantly affect the gauge response. More grease was applied for later runs but the change in signal did not increase so those results are not presented.

Since low initial readings for Δ strain only appeared at high strain we surmise that slipping is occurring which is causing small temperature rise. A temperature rise at the gauge will cause a proportional increase in strain reading due to the temperature sensitivity of the gauge. The above explanation of this phenomenon also accords with the observed decrease in the rate of signal change as the interface between the gauge and surface achieves heat flow equilibrium.

These tests did not allow an investigation of higher strain amplitudes because the specimens available were too large for the dynamic capacity of the MTS machine.

For these MTS experiments both the load cell and HHSG phase lag relative to the generator driving signal were noted from the FRA display panel. For the 5.0 Hz runs (both clean and greased) the phase lag of the HHSG from the load cell was less than 1 degree and decreased at larger load amplitudes. Phase lag of both transducers from the FRA was significantly greater at 20.0 Hz than at 5.0 Hz, but the HHSG lagged the load by only 2.0 to 3.0 degrees.

The results for the 20.0 Hz runs are not presented here since they showed no new effects compared to those at 5.0 Hz. Also, the MTS maximum load decreases to approximately \pm 35 kN at 20.0 Hz which eliminated the area of real interest.

TABLE 3. CLEAN SURFACE CALIBRATION DATA

Specimen : BP46BC2 Machine : MTS 50 kN Material: 2024 - T4 aluminium alloy Loading Frequency: 5.0 Hz


Indicated Load	Calculated Strain	Measured H.H.G.
Amplitude	Amplitude	Signal
half peak - peak (kN)	half peak - peak (με)	RMS (mV)
2.48	321	83.2
4.94	639	164.7
7.40	956	243.5
9.88	1277	318.7
12.37	1598	400.5
14.79	1912	460.0
17.28 "	2233	475.0 529.0 540.0
14.79	1912	467.3
9.84	1272	321.0
4.93	637	163.2

N.B. A similar run was performed at 20 Hz. Mowever, machine capacity was reached at 1587 $\,\mu\varepsilon$

TABLE 4. GREASED SURFACE CALIBRATION DATA

Specimen: BP46BC2 Machine: MTS 50 kN Material: 2024 - T4 aluminium alloy Loading Frequency: 5.0 Hz

Indicated Load Amplitude	Calculated Strain Amplitude	Measured H.H.G. Signal
half peak - peak (kN)	half peak - peak (με)	RMS (mV)
2.40	310	79.3
4.88 7.44	630 961	161.1 242.0
9 .89	1278	320.0
12.41 14.83	1604 1916	397.6 469.0
н	n	470.0
17.28	2234	508.5 540.2



CLEAN SURFACE, ALUMINIUM SPECIMEN CALIBRATION LINE FOR 5.0 Hz FIG. 6.




FIG. 7. GREASED SURFACE, ALUMINIUM SPECIMEN CALIBRATION LINE FOR 5.0 $\rm Hz$ 13

4.3 Random Loading Experiments

Two runs were performed with the HP Spectrum Analyzer (SA) providing the white noise driving signal as described in Section 3. Only one set of results is presented here in Figures 8 and 9 for frequencies from 0 up to 100.0 Hz. There are two input channels on the SA. The channel connected to the load cell had a sensitivity of 3.0 volts with 10 mV per division of the display screen. Channel B connected to the amplifier for the HHSG was set to 0.3 volts sensitivity and 1.0 mV per division.

Both the spectra of Figure 8 and the transfer function graph of Figure 9 were constructed from 16 rms averages of the incoming data with a Hanning passband shape selected. The phase difference graph, (load - HHSG), was displayed at 50 degrees per division.

Figure 8 shows that a small load amplitude was applied so that the MTS machine could cope with the highest frequencies in the random noise supplied. The machine can normally only manage 35 kN at 20.0 Hz with uniform cyclic loading.

A comparison of the spectra shows clearly that the HHSG is faithfully responding to the applied load until over 100.0 Hz. This is confirmed by the uniform transfer function. The peak at the centre is possibly an effect of the small 50.0 Hz mains supply noise which is known to be present in the load cell output. A small increase in the phase difference occurs over the measured range.

The Spectrum Analyser is able to show values of spectral amplitude, transfer function amplitude or phase as a marker is moved along the frequency axis of the display screen. With this feature it is possible to calibrate the HHSG as was done for the uniform cyclic loading tests earlier.




FIG. 8. RANDOM LOADING SPECTRA OF HHG AND LOAD CELL




FIG. 9. LOAD CELL TO HHG TRANSFER FUNCTIONS

5. CONCLUSION

The experiments performed to date verify that the Hand-Held Strain Gauge system works well for strains less than 2000 microstrain. This is approximately half of the yield strain for the aluminium alloy used. At and above that level, slipping of the gauge on the surface results in under reading of the applied strain. Frictional heating due to this slipping, however, is thought to counteract this effect giving a reduced error in the HHSG signal after it has steadied.

At amplitude levels above 1800 microstrain the signal immediately after application of the HHSG is significantly less than predicted due to relative slipping. It increases with decreasing rapidity until it stabilizes at a value which is only slightly less than could be expected from the experimental errors. However, this effect does limit the maximum strain amplitude at which accurate readings can be maintained to 2000 microstrain

The surface cleanliness has been shown to have only a small effect on the performance by increasing the departure from linear response which the gauge shows at higher strain amplitudes. The surface does not, however, have to be scrupulously clean to achieve accurate results since it was only after the application of several thin smeared layers of grease that this performance degradation was noticed.

Frequency does not appear to affect the gauge significantly although the MTS testing machine was not able to provide the higher loads at higher frequencies required to fully test this aspect.

This evaluation has demonstrated that the HHSG is expected to be very useful during fatigue tests because accurate, quick and inexpensive strain readings can be taken from many varied locations on the structure. Stress concentrations and positions for fixed strain gauges can now be determined experimentally in the preliminary stages of a test.

The random loading sequence experiments demonstrated that the HHSG responds very well up to at least 100.0 Hz. This should be adequate for use in providing the reference signal to SPATE for a planned investigation as to whether that instrument can be extended to deal with random loading rather than purely uniform cycling. The only proviso is that the strain levels be low enough to be in the linear response region.

ACKNOWLEDGEMENTS

The authors thank the Structures Experimentation Group technical staff involved with this project for the high standard of operation of the experimental equipment. In particular we would like to mention Brian Quinn, Leo Mirabella and Roy Bailey.

David Smith and Philip Ferrarotto are gratefully acknowledged for their professional electrical expertise applied to the development of the HHSG circuits.

REFERENCES

1. TML, "TML Strain Gauges Catalogue", TML pamphlet E-101N. Tokyo, Tokyo Sokki Kenkyujo Co. Ltd., pages 4, 5 and 16.

APPENDIX

HHSG to Amplifier Connections




Figure 10. Hand-Held Strain Gauge Connections

Amplifier Gain Determination

Without calibration resistor the FLUKE volt meter displayed $V_{in} = 1.56 \text{ mV}$ across terminals "B" and "C" and amplifier output was $V_{out} = 1.893 \text{ V}$.

With the calibration resistor in parallel with the HHSG, the simulated strain from this is given by;

$$R_{col} = \frac{R_g}{K \, \epsilon \, BF} - R_g$$

where

 $R_{cal} = \text{calibration resistance}$

BF = Bridge factor = 1.

 $R_g = \text{resistance of individual dummy gauges} = 120 \text{ ohm}$

K = gauge factor = 2.06

 $\epsilon =$ applied Δ strain

For a typical applied strain of 1000 microstrain we obtain $R_{rel} = 58.13$ kohm. Simulating this with 58.2 kohm resistance in parallel with the HHSG, we measured the voltages mentioned above to be $V_{in} = 0.35$ mV and $V_{out} = 3.383$ V. Therefore,

Amplifier Gain Factor =
$$log_{10} \left(\frac{\Delta V_{ont}}{\Delta V_{in}} \right)$$

= 3.09 dB

DISTRIBUTION

AUSTRALIA

Department of Defence

Defence Central

Chief Defence Scientist

Assist Chief Defence Scientist, Operations (shared copy)

Assist Chief Defence Scientist, Policy (shared copy)

Director, Departmental Publications

Counsellor, Defence Science (London) (Doc Data Sheet Only)

Counsellor, Defence Science (Washington) (Doc Data Sheet Only)

S.A. to Thailand MRD (Doc Data Sheet Only)

S.A. to DRC (Kuala Lumpur) (Doc Data Sheet Only)

OIC TRS, Defence Central Library

Document Exchange Centre, DISB (18 copies)

Joint Intelligence Organisation

Librarian H. Block, Victoria Barracks, Melbourne

Director General - Army Development (NSO) (4 copies)

Aeronautical Research Laboratory

Director

Library

Divisional File - Structures

Authors: M. Stimson (3 copies)

J. Sparrow

S. Dunn

D.A. Smith

P. Ferrarotto

Materials Research Laboratory

Director/Library

Defence Science & Technology Organisation - Salisbury

Library

Navy Office

Navy Scientific Adviser (Doc Data Sheet Only)

Army Office

Scientific Adviser - Army (Doc Data Sheet Only)

Air Force Office

Air Force Scientific Adviser (Doc Data Sheet Only)

Universities and Colleges

Library, Australian Defence Force Academy

SPARES (10 copies)
TOTAL (50 copies)

AL 149 REVISED DECEMBER 87

DEPARTMENT OF DEFENCE

DOCUMENT CONTROL DATA

PAGE CLASSIFICATION UNCLASSI		
PRIVACY MARKING		

D	OCOMENT CONTROL L	JATA	PRIVACY MARKING		
18. AR MUNER AR-004-569	sb. ESTABLISHENT MUNEER ARL-STRUC-TM-476	2. DECEMENT	MBER 1987		3. TASK MUNBER DST-87/038
4. 117.2 EVALUATION OF A HAND-HELD FRICTIONAL STRAIN GAUGE		PLACE APPRO	PRIATE CLASSIFICAT ECRET (S). CONFIDEN UNCLASSIFIED (U)	TIAL (C).	8. No. PAGES 21
		BOCUMENT	TITLE	ABSTRACT	7. No. REFS.
B. AUTHOR (S) M.G. STIMSON J.G. SPARROW		9. BOWNSRAGII	ng/deliriting inst	RUCTIONS	
10. CORPORATE AUTHOR AND	ACCRESS	11. OFFICE/P	DEITION RESPONSIBL	E FOR	
	RESEARCH LABORATORY MELBOURNE VIC. 3001	SPONSOR SECURITY _ DOMNGRADIO APPROVAL _	<u>-</u>	 	
12. SECONDARY DISTRIBUTION (OF THIS DOCUMENT) Approved for public release. OVERSEAS EMBURIES OUTSIDE STATED LIMITATIONS SHOULD BE REFERRED THROUGH ASDIS. DEFENCE INFORMATION SERVICES BRANCH DEPARTMENT OF DEFENCE, CAMPBELL PARK, CAMPERNA, ACT 2601					
No limitations.	DE AMMOUNCED IN CATALOGUES AND AMA	ACHESS SERVICE	S AVAILABLE TO		
136. CITATION FOR OTHER	PURPOSES (IE. CASUAL ANNOUNCEMENT) MAY BE	UNMESTRICTED OR	X	FOR 13e.
14. DESCRIPTORS Strain gauges 15. OROA SUBJECT CATEGORIES 00890					
st. METHIGHT A system has been implemented at ARL for obtaining strain amplitudes using a commercially available hand applied strain gauge. The gauge measures strain when applied by hand to a cyclically loaded flat surface with the correct normal force to ensure that slipping does not occur. A gauge holder is supplied to transmit the normal force through the gauge to the test piece.					
capabilities an	document describes the d calibrate the gaugwere comparable wit m 0.1 to 25 Hz. Similar	e. It with bonde	vas found 1 d strain g	that ac auges	ccuracy and for loading

PAGE CLASSIFICATION
UNCLASSIFIED

PRIVACY MARKING

THIS PAGE IS TO BE USED TO RECORD INFORMATION WHICH IS REQUIRED BY THE ESTABLISHMENT FOR ITS OWN USE BUT WHICH WILL NOT BE ADDED TO THE DISTIS DATA UNLESS SPECIFICALLY REQUESTED.

18. ABSTRACT (CONT.)				
was applied with excellent response observed up to 100 Hz. Strain amplitudes up to \pm 0.2% elongation were successfully measured and it was shown that the surface need not be very clean for correct performance at lower strains.				
17. IMPRINT				
AERONAUTICAL RESEAR	CH LABORATOR	Y, MELBOURNE		
18. DOCUMENT SERIES AND MUNICER AIRCRAFT STRUCTURES TECHNICAL MEMORANDUM 476	19. COST COO€ 27 1165	20. TYPE OF REPORT AND PERIOD COVERED		
21. COMPUTER PROGRAMS USED				
		}		
		ì		
22. ESTABLISHMENT FILE REF. (S)				
23. ACCITICNAL INFORMATION (AS REMIETED)				

END DATE FILMED 8