

# NAVAL POSTGRADUATE SCHOOL MONTEREY, CALIFORNIA



19960801 076 THESIS

**HEAT TRANSFER STUDIES AND FLOW  
VISUALIZATION OF A RECTANGULAR  
CHANNEL WITH AN OFFSET-PLATE-FIN  
ARRAY**

by

Carlos M. Suarez

March 1996

Thesis Advisor:

M. D. Kelleher

Approved for public release; distribution is unlimited.

DTC QUALITY INSPECTED 1

| REPORT DOCUMENTATION PAGE  |  |   | Form Approved OMB No. 0704-0188  |  |
|--|--|---|----------------------------------|--|
| Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instruction, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188) Washington DC 20503.  |  |   |                                  |  |
| 1. AGENCY USE ONLY (Leave blank)   | 2. REPORT DATE<br>March 1996                             | 3. REPORT TYPE AND DATES COVERED<br>Master's Thesis     |                                  |  |
| 4. TITLE AND SUBTITLE Heat Transfer Studies and Flow Visualization of a Rectangular Channel with an Offset-Plate-Fin Array.  |  | 5. FUNDING NUMBERS                                      |                                  |  |
| 6. AUTHOR(S) Carlos M. Suarez  |  |   |                                  |  |
| 7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)<br>Naval Postgraduate School<br>Monterey CA 93943-5000  |  | 8. PERFORMING ORGANIZATION REPORT NUMBER                |                                  |  |
| 9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)  |  | 10. SPONSORING/MONITORING AGENCY REPORT NUMBER          |                                  |  |
| 11. SUPPLEMENTARY NOTES The views expressed in this thesis are those of the author and do not reflect the official policy or position of the Department of Defense or the U.S. Government.   |  |   |                                  |  |
| 12a. DISTRIBUTION/AVAILABILITY STATEMENT<br>Approved for public release; distribution is unlimited.  |  |   | 12b. DISTRIBUTION CODE           |  |
| 13. ABSTRACT (maximum 200 words)<br>The heat transfer characteristics and flow visualization of a 10X scale version of internal offset-fin plate array within the liquid flow-through module for electronics cooling were investigated experimentally using water as a cooling fluid. By varying power input settings and coolant flow rates, the heat transfer effect from the plate array to the coolant water was investigated. Additionally thermochromic liquid crystals were spray-painted onto the plate to determine the temperature distribution within the heat transfer surface, as compared to the readings from the attached thermocouples. Finally a flow visualization using the dye-injection technique was to study the flow patterns of the coolant through the fin array. |  |   |                                  |  |
| 14. SUBJECT TERMS Flow Visualization, Offset Plate-Fin Array, Electronic Cooling   |  |   | 15. NUMBER OF PAGES              |  |
|  |  |   | 16. PRICE CODE                   |  |
| 17. SECURITY CLASSIFICATION OF REPORT<br>Unclassified  | 18. SECURITY CLASSIFICATION OF THIS PAGE<br>Unclassified | 19. SECURITY CLASSIFICATION OF ABSTRACT<br>Unclassified | 20. LIMITATION OF ABSTRACT<br>UL |  |

NSN 7540-01-280-5500

Standard Form 298 (Rev. 2-89)  
Prescribed by ANSI Std. Z39-18 298-102



Approved for public release; distribution is unlimited.

**HEAT TRANSFER STUDIES AND FLOW VISUALIZATION OF A  
RECTANGULAR CHANNEL WITH AN OFFSET-PLATE-FIN ARRAY**

**Carlos M. Suarez**  
Lieutenant, United States Navy  
B.S., United States Naval Academy, 1987


Submitted in partial fulfillment  
of the requirements for the degree of

**MASTER OF SCIENCE IN MECHANICAL ENGINEERING**

from the


**NAVAL POSTGRADUATE SCHOOL  
March 1996**

Author:

  
Carlos M. Suarez

Approved by:

  
Matthew D. Kelleher, Thesis Advisor

  
Terry McNelley, Chairman  
Department of Mechanical Engineering



## **ABSTRACT**

The heat transfer characteristics and flow visualization of a 10X scale version of internal offset-fin plate array within the liquid flow-through module for electronics cooling were investigated experimentally using water as a cooling fluid. By varying power input settings and coolant flow rates, the heat transfer effect from the plate array to the coolant water was investigated. Additionally thermochromic liquid crystals were spray-painted onto the plate to determine the temperature distribution within the heat transfer surface, as compared to the readings from the attached thermocouples. Finally a flow visualization using the dye-injection technique was to study the flow patterns of the coolant through the fin array.



## TABLE OF CONTENTS

|   |    |
|---|----|
| I. INTRODUCTION .....                   | 1  |
| A. ELECTRONIC COOLING .....             | 1  |
| 1. Cooling Requirements .....           | 1  |
| 2. Offset Plate Finned Arrays .....     | 4  |
| B. PREVIOUS RESEARCH .....              | 8  |
| C. OBJECTIVES OF PRESENT STUDY .....    | 11 |
| II. EXPERIMENTAL APPARATUS .....        | 13 |
| A. TEST SECTION .....                   | 13 |
| 1. Base Plate and Fin Assembly .....    | 13 |
| 2. Plexiglass Cover .....               | 16 |
| 3. Inlets and Outlets .....             | 16 |
| 4. Flow Straightener Sub-Assembly ..... | 16 |
| 5. Miscellaneous Inlets. ....           | 16 |
| 6. Temperature Instrumentation .....    | 17 |
| 7. Final Assembly .....                 | 18 |
| B. SUPPORT SYSTEMS .....                | 18 |
| 1. Data Acquisition System .....        | 18 |
| 2. Power Distribution System .....      | 19 |
| 3. Fluid Circulation System .....       | 21 |
| 4. Dye-Injection System .....           | 21 |
| C. EXPERIMENTAL PROCEDURE .....         | 23 |
| III. RESULTS .....                      | 25 |
| A. HEAT TRANSFER STUDIES .....          | 25 |
| B. HEAT TRANSFER RESULTS .....          | 30 |
| C. THERMOCHROMIC LIQUID CRYSTALS .....  | 35 |
| D. FLOW VISUALIZATION .....             | 36 |



|   |     |
|---|-----|
| IV. CONCLUSIONS . . . . .                           | 39  |
| A. HEAT TRANSFER STUDIES . . . . .                  | 39  |
| B. TEMPERATURE DISTRIBUTION . . . . .               | 39  |
| C. FLOW VISUALIZATION . . . . .                     | 40  |
| V. RECOMMENDATIONS . . . . .                        | 43  |
| APPENDIX A. UNCERTAINTY ANALYSIS . . . . .          | 45  |
| 1. Reynolds Number Uncertainty . . . . .            | 45  |
| 2. Colburn j Factor Uncertainty . . . . .           | 47  |
| APPENDIX B. SAMPLE CALCULATIONS . . . . .           | 49  |
| 1. Characteristic Dimension . . . . .               | 49  |
| 2. Water Properties . . . . .                       | 49  |
| 3. Reynolds Number . . . . .                        | 50  |
| 4. Nusselt Number . . . . .                         | 50  |
| 5. Colburn j Factor . . . . .                       | 50  |
| APPENDIX C. HEAT TRANSFER DATA COLLECTION . . . . . | 51  |
| A. Centerline Temperature Distribution . . . . .    | 53  |
| B. Thermocouple Data . . . . .                      | 77  |
| C. Colburn j Factor . . . . .                       | 120 |
| LIST OF REFERENCES . . . . .                        | 123 |
| INITIAL DISTRIBUTION LIST . . . . .                 | 125 |

## FORWARD

I wish to thank the following people for their continued assistance in helping me complete this thesis. First of all to my family who suffered through its completion, especially to my wife for her love and dedication. Second to LT. Bill Plott, LT. Don Avenger and LT Phil Pall who helped me through NPS. Finally to Dr Kelleher and CDR Gray, who saw me through the ordeal.

## I. INTRODUCTION

### A. ELECTRONIC COOLING

Electronic components have continued a rapid pace of increasing capability and decreasing size. With each increase in capability, there is a corresponding dramatic increase in the power density of the electronic chip. Therefore, designers are faced with the need to develop more efficient heat exchangers to cool electronic packages. Furthermore for avionic and shipboard applications, weight savings is also a key criterion.

#### 1. Cooling Requirements


Electronic designers are restricted by two major constraints. First, for reliable operation of an electronic chip, the chip junction temperature typically must remain below  $85^{\circ}\text{C}$ . This is a material limitation to ensure efficient transfer of binary data along the chip's electronic circuits [Ref 1]. Second, advances in micro-miniaturization continue to increase the power densities of electronic chips. Integrated circuit chips have heat dissipation requirements of up to  $40\text{ W/cm}^2$ . Researchers are focusing on cooling the next generation of very-large scale integrated chips with a heat dissipation of  $200\text{ W/cm}^2$  [Ref 2]. There have been several approaches to enhance removing the heat generated by electronic components. These include heat sinks, forced convection air cooling, conduction cooling, and direct liquid immersion cooling. This study investigates the heat transfer effects of forced convection cooling a plate-fin-array which is conducting heat away from a mounted circuit card.

The U.S. Navy is particularly concerned with the use of printed circuit board modules, to ease troubleshooting and repair of electronic systems. A particular concern in military applications is how to achieve increased cooling capacity while decreasing system weight. A standard military circuit module is the Format E, Standard Electronics Module, (SEM-E), MIL-STD-1389. Presently the SEM-E card is limited to a heat input of forty watts from a printed circuit board populated with chips, weighing under two pounds. A typical one-tier Integrated Rack loaded with SEM-E cards weighs

approximately 70 pounds. By increasing the electronic cooling capacity, the military can take advantage of higher density chips, without the liability of increased overall weight. The Standard Hardware Acquisition and Reliability Program (SHARP) is evaluating an advanced electronic cooling system at the Crane Division of the Naval Surface Warfare Center. The desired end is to effectively cool a 42-pound enclosure with 30 modules dissipating an average of 200 watts per card. To accomplish this task, a commercially available liquid flow-through-module (FTM) is being tested. [Ref. 3]

Compact heat exchangers are often used in industry. By definition, these heat exchangers have a large surface-area-to-volume ratio. The use of extended surfaces into the flow of the coolant provides additional surface area for heat transfer to take place. Fins enhance the heat transfer from the module surface to the coolant. These heat exchangers, seen in Figure (1), fall into three categories: offset fin, louver fin and parallel louver fin. The offset fin exchanger, the most common type, is the focus of this study.

The liquid FTM internally combines two thermal design concepts. First, three internal passages within the FTM direct the flow of coolant. These internal flow passages have internal fins. As stated previously, the advantage of the offset fin array is the increased heat transfer gained from the periodic interruption of the thermal boundary layer. [Ref. 5] Designed as a compact heat exchanger, the fin structure increases the heat transfer surface area inside the volume of the FTM. Second, the fins also increase the convective coefficient by disrupting the growth of thermal boundary layers on the surface [Ref. 2].



**Figure 1.** From Ref. 5, Enhancement geometries for compact heat exchangers, a) Offset-strip fin, b) Louver fin, c.) Louver fins on flat tube.


## **2. Offset Plate Finned Arrays**

The fin array can be either internal or external. In this specific case, the fin array is internal in a flow-through-module (FTM) through which the coolant is pumped. Heat is conducted from the electronic circuit board from the circuit board to the module, sometimes using a heat sink. Figure (2) shows the internal flow path of coolant through the module. Each of the three internal passages contains an internal fin-array. These fins on the module's interior, as seen in Figure (3), enhance convective heat transfer to the coolant. The modular arrangement allows for a more self-contained coolant system, to avoid contamination and to ease the replacement of malfunctioning circuit board modules. [Ref. 4]

The offset fin plate heat exchanger is characterized by the geometry of its fins. An alternating interval pattern interrupts the fluid flow stream. It is important to note that the repeated interruption of the velocity and thermal boundary layers by each succeeding row of fins enhances heat transfer [Ref. 5]. Unfortunately the very geometry of enhanced heat transfer surfaces increases the number of dimensional variables. Modeling of the complex channel flow has been challenging investigators for several decades. Weiting developed the primary correlation for offset strip fin geometry in 1975. His empirical solution to describe heat transfer required a different constant for the Reynolds number exponent in the laminar and turbulent regions. This causes inaccuracies in predicting heat transfer in the transition region. [Ref. 5]

The geometry of the offset fin array has the following characteristic lengths: fin length ( $l$ ), height ( $h$ ), thickness ( $t$ ) and spacing or pitch ( $s$ ). Figure (4) shows the unit cell as defined by H. M. Joshi and R. Webb [Ref. 7]. The offset is the lateral displacement between the trailing edge of one fin to the next row's forward fin edge. Normally the next row's offset is half the fin spacing, or in the center of the previous row.


It was discovered that the ratio between fin spacing and fin length determines the amount of turbulence behind a fin [Refs 6-9]. The variation of the  $s/l$  ratio changes the frequency of the vortices within the wake flow. Unfortunately the friction and form drag of the fins causes increased turbulence that results in a pressure drop [Ref. 7]. Form drag can be reduced by using slender fins, to diminish the fin thickness's effect on momentum and heat transfer [Ref. 8]. If an optimum  $s/l$  ratio can be computed through a correlation, a subsequent optimization in required pumping power may result.



Module Thickness: 0.1 inch  
Faceplate Thickness: 0.02 inch  
Faceplate Material: 6061 Alum.


Figure 2. From Ref. 4, p. 2, the internal flow path of coolant through the FTM. Note the three separate internal passages which contain the fin arrays.





Lance Length: 0.125 inch  
Fin Density: 20 Fins/inch  
Fin Height: 0.06 inch  
Fin Thickness: 0.006 inch  
Fin Material: 3003 Alum. Alloy

**Figure 3.** From Ref 4, p. 3, Fin Pattern for test FTM. These are the original dimensions on which the model was based. The lance length is the fin length.



**Figure 4.** From Ref. 11, Unit cell dimensions of offset fin plate array. Height is in the normal direction.

## **B. PREVIOUS RESEARCH**


Weiting's study focused on the heat transfer characteristics of air. Several studies have focused on refining predictive correlations for transitional flow [Ref. 8]. Results from flow visualization of plexiglass fins of various geometries within a water channel helped develop a criterion for transition to turbulence [Ref. 7]. The effect of fin pitch or spacing on the flow characteristics was extensively studied in Japan [Ref. 9]. Numerical solutions for two dimensional arrays for laminar flow and accounting for fin thickness, have been developed [Ref. 10].

It was Joshi and Webb who conducted the research which developed a numerical solution to the Nusselt (Nu) and the friction factor (f) for a laminar flow and a semi-empirical solution to the turbulent region. Through experimentation on a scaled up model, they formulated a method to predict transition to turbulence using a wake width based Reynolds number,  $Re_w$ . The wake width was defined as the fin thickness plus twice the momentum thickness at the trailing edge of the fin [Ref. 7]. Since the offset fin is common geometry for heat exchangers, an empirical solution could be optimized to determine the best fin dimension ratio for a desired heat transfer rate using various fluids.

Research into the optimal fin dimensions continued following the empirical correlations of Weiting. He had used an aspect ratio relating flow passage width and height. The plain longitudinal fin and the offset fin geometry were compared to learn the heat transfer rate of a fin in higher Prandtl number fluids. Fluids like Fluorinert FC-77 ( $Pr = 25$ ) were compared to water using correlations by Kays and Webb-Joshi. [Ref. 2]

Several authorities have reviewed the body of published research to create an accurate bibliography. Manglik and Bergles presented a compilation of current empirical data, correlations and qualitative observations up to 1987 [Ref. 8]. Webb updated this bibliography in 1994 through a review of various advances in modeling enhancement mechanisms to predict the effect of geometric variables and fluid properties [Ref 5].

Manglik and Bergles also presented the expected flow patterns observed in flow visualization experiments, reproduced in Figure (5). As also by Xi, et. al. they showed there are four distinct flow patterns. Pattern (a) in Figure (5) shows a smooth, laminar flow. Oscillations begin at the upstream edge of the second fin, then progress towards the trailing edge of the first fin as flow velocity increases, as seen in Pattern (b) and (c). Finally vortices develop off the trailing edge of the first fin at the highest flow rates as seen in Pattern (d). [Ref. 8]



**Figure 5.** From Ref. 8, Flow Patterns observed in visualization experiments. Pattern (a) is a smooth, laminar flow. Oscillations increase as flow velocity increases in patterns (b) and (c). Pattern (d) has vortices off the trailing edge at the highest flow rate.

### **C. OBJECTIVES OF PRESENT STUDY**

This study is a continuation of an experiment designed to investigate the heat removal capacity of a scaled-up version of the SEM-E sized flow-through module. Water as the cooling fluid was passed over a electrically heated plate with an offset-finned array. The surface of the array was coated with thermochromic liquid crystals to detect variations in the temperature distribution across the plate and fins. Flow visualization to confirm previous research was to be accomplished by dye injection. [Refs. 7-9] By varying the coolant flow rate through the fin passages and the power input, the effect of the Colburn  $j$  factor was also investigated.



## **II. EXPERIMENTAL APPARATUS**

Since this is a continuation of a previous study, the experimental system was refurbished and adapted to fit the new requirements. The apparatus included a test section, data acquisition system, and a fluid circulation system. The author acknowledges the work of Lt. Jeffrey Masterson, who constructed the test section. This chapter borrows heavily from Masterson's thesis to provide a clear description and diagrams on of how the subsystems were constructed and used for this study [Ref 11, pp 9-15].

### **A. TEST SECTION**

#### **1. Base Plate and Fin Assembly**

The base plate and fin assembly is a 10X scale model of the horizontal passages found within a liquid flow-through-module. Dividing the array into fin rows allowed the base and fins row to be milled from a solid piece, without the need to weld the fin onto the base plate. Seen in Figure (6), this was done by cutting 2.54 cm (1.0") thick aluminum 6061 alloy plate into 31.75 mm wide strips. These strips were then milled to the width of the plate. The fins were cut 15.24 mm deep into the aluminum strips using a specially made 11.76 mm diameter end mill. The base thickness was maintained at 10.16 mm. An offset of 6.64 mm was cut into one end. When this offset was alternated, it created the offset pattern of succeeding fin rows. Finally on each end, an additional 12.7 mm offset of base plate thickness was milled to serve as the lip for the plexiglass cover. [Ref 11]


The inlet and outlet plenum was milled from two pieces of a 10.7 mm (.5") aluminum 6061 alloy plate. These were milled down to the base plate thickness of 10.16 mm.[Ref 11]

Holes were then drilled in the plate's lengthwise direction through each fin row and plenum piece. Two threaded rods hold the plate assembly together. Rubber gasket was placed between the first row and the inlet plenum sections, and between the last row and outlet plenum sections. This was to reduce longitudinal conduction losses from the finned section into the plenums. Final assembly included the use of a bead of silicone rubber coating between each fin section to prevent leakage. [Ref. 11]

Prior usage left some hard water deposits on the plate. The plate was cleaned using glass beads under a sandblaster hood. The plate surface was then prepared for coating with thermochromic liquid crystals. This was a two step process. First, a commercially prepared, water-resistant, black base paint formulated for thermochromic crystals was spray-painted onto the surface with two thin coats. Then two coats of water resistant thermochromic liquid crystals was spray-painted onto the plate. Special care was taken to coat the fin faces without causing drips or pools.

Thermochromic liquid crystals react to temperature changes by changing color. The crystals are colorless until the red start temperature is reached. Then the color will respond over a set bandwidth by passing through the visible spectrum from red to blue with increasing temperature. [Ref. 12] The crystals chosen for this study had a red start temperature of 30 °C and a fifteen-degree bandwidth. Response was tested by electrically heating the plate in air to observe uniformity of color over the entire plate.





**Figure 6.** Finned Section Design, adapted from Ref 11, p.20.

## **2. Plexiglass Cover**

Using the assembled plate as a template, a cover for the base and fin array assembly was fashioned using 12.7 mm (.5") thick plexiglass sheet. The sides were milled to the height of the fins (15.24 mm). The top was cut to the dimensions of the base plate, 654 mm by 260.5 mm [Ref. 11]. The sides were attached to the top piece using acrylic cement and secured with quarter-inch set screws. Since leakage was noted in prior runs, a bead of RTV was run along the joint of the side pieces and top and in each corner. The plexiglass cover was designed to fit securely over the finned array in order to impede flow from crossing over the top of the fins.

## **3. Inlets and Outlets**

Three inlets and three outlets were drilled into the axial ends of the plexiglass cover. A 3.175 mm (1/8") pipe thread was drilled and tapped into the plexiglass wall from which a 6.35 mm (1/4") Tygon tube adaptor was mounted on the outside. Valves were placed on the two outer outlets so that they could be closed when operating the test section as needed. One inlet and outlet were aligned on the longitudinal axis of the test plate. The two outer inlets and outlets were placed 379 mm from the outer edges. [Ref. 11]

## **4. Flow Straightener Sub-Assembly**

To provide a uniform flow velocity profile, a flow straightener was devised using 38.1 mm (1.5") long straws and a plastic mesh. The mesh was to distribute the fluid flow evenly to the bank of straws that would direct the flow longitudinally. This component was placed 28 mm (1.1") away from the edge of the first fin row and 20 mm (0.8") from the inlet wall.

## **5. Miscellaneous Inlets**

Pressure measurements were not taken in this study. For the previous study, four pressure taps with valves were installed on the longitudinal centerline of the plexiglass cover to monitor pressure drops. These penetrated the plexiglass with 1.588 mm (1/16") holes penetrating the plexiglass. Two inner taps were removed and filled in with RTV

to prevent obscuring the flow visualization experiments. The outer taps, along with the outer outlets, served to eliminate entrapped air when filling the test section with liquid.

For the requirements of this study injection points and temperature probe points were drilled into the plexiglass cover. Five dye injection points were placed just after the flow straightener assembly in the inlet plenum portion of the test section. These were also 1.588 mm (1/16") holes that penetrated the plexiglass. As with the pressure tap a larger well had been then drilled centered on the smaller hole. This 3.175 mm (1/8") well was hand tapped to mount a quicklock adaptor. The dye injection assembly will be described in a later section. A 1.588 mm (1/16") OD stainless steel tubing was passed through the adaptor into the interior of the assembly.

Two temperature probe 1.588 mm (1/16") holes were placed on the centerline in the inlet and outlet plenum region of the plexiglass cover. This was deburred by hand to ensure uniformity, then filled with RTV. A five-mil Copper-Constantan thermocouple wire was feed through the hole before the setting of the RTV.

## **6. Temperature Instrumentation**

On the bottom of the base plate fin array assembly, Copper-Constantan (T-type) cement-on thermocouples were mounted. Flat ribbon thermocouples were chosen to provide better surface contact. Placement is as seen in Figure (7). Since the thermocouples were firmly mounted and covered by a resistance heater pad, they could not be calibrated to a zero reference point. The thermocouples were mounted using a high thermal conductivity epoxy (Omegabond 101). To reduce thermal contact resistance, a small amount of thermally conductive paste was applied to the junction of each sensor. [Ref 11]

An electrical resistance heater pad was glued onto the bottom of the plate, covering most of the thermocouple junctions. The pad covered the finned area section except 9.525 mm at each end and 3.24 mm on the sides. Some bubbling and separation were noted, but the pad was not replaced, in order not to disturb the thermocouples.

## **7. Final Assembly**

RTV sealed the base plate and fin array to the plexiglass cover. A gasket was not used since the sidewalls were not milled down to accept the use of gasket material and prevent flow over the tops of the fins. Machine setscrews were threaded to tighten the aluminum plate to the plexiglass cover. A plywood and foam rubber platform served as the base for the assembly. Additional foam rubber insulation was fitted around the sides and top to reduce heat losses to ambient atmosphere. Tygon tubing connected the fluid circulation system. The thermocouples were connected to the data acquisition system.

## **B. SUPPORT SYSTEMS**

The support systems were identical to that used by Masterson in his thesis. Figure (8) is the overall system schematic of experimental equipment.

### **1. Data Acquisition System**

Temperature and voltage measurements were made by a computer driven data acquisition system consisting of an HP 9000 computer controlling an HP 3852 Data Acquisition/Control unit. Two 24-channel, thermocouple compensated, high-speed multiplexed boards measured the thermocouple junction temperatures. A third 24-channel high speed multiplexed board monitored DC voltages from the flow meter, power supply and precision resistor. The HP computer was linked via an RS-232 port to an IBM compatible PC desktop, which stored the data for later computation and display.

Visual data was recorded using a Canon AE-1 35 mm camera, with two lenses: 28 mm 1:2.8 wide angle and 50 mm 1:1.8 portrait. A polarization filter reduced the reflection of light from the plexiglass into the lens. Magnification filters provided the 1x, 3x, and 7x photographs. For the dye-injection phase of the study, a video record was made with a SONY 8 mm video camera.

## 2. Power Distribution System

A KEPCO 0-100 V, 0-5 A power supply provided DC power to the MINCO foil backed patch. As described earlier, the heater pad was adhered to the bottom of the plate with pressure sensitive epoxy. A linoleum roller was used to ensure uniform adhesion. The heater pad was 25.4 cm by 30.48 cm, resulting in a 1116 square cm heating area, with a measured total resistance of  $11.2 \pm 1.1 \Omega$ . The power supply output DC voltage was monitored along with the voltage drop across a precision resistor in series with the heater. The precision resistor was originally a 30-watt  $.1 \pm 0.001 \Omega$  resistor. Since the thermochromic crystals responded only at high power inputs, a 250-watt  $2 \pm 0.01 \Omega$  was substituted.

Power to the heater was determined using the following relationship, where  $V_{\text{heater}}$  is the measured DC voltage across the heater, and  $V_{\text{resistor}}$  the voltage drop across the precision resistor with resistance R.

$$Power = V_{\text{heater}} I_{\text{heater}} \quad \text{Eqn. 2.1}$$

$$I_{\text{heater}} = I_{\text{resistor}} = \frac{V_{\text{resistor}}}{R} \quad \text{Eqn. 2.2}$$




Figure 7. Test Section Top View, adapted from Ref 11. Dimensions, in millimeters, are A: 89 mm, B: 654 mm, C: 261 mm, D: 32 mm.

### **3. Fluid Circulation System**

A regulated constant temperature bath was maintained by an ENDOCAL RTE-5 heater/refrigeration unit. This unit also provided a positive pressure fluid surge volume to a Cole-Parmer positive displacement gear type pump driven by a variable speed motor. An Omega FTB-102 turbine flow meter that used an AC-to-DC signal converter measured the fluid flow rates. Flow meter calibration consisted of a comparison of the average voltage output to the average time to collect a specific volume of water. The flow was then divided by a manifold into three flow paths: recirculation to the bath, centerline inlet, and the outer inlets coupled using a Tee-joint. A thermocouple was inserted into the center of the centerline inlet tubing by using a Tee-joint placed 2.54 cm (1") from the inlet. [Ref 11]

### **4. Dye-Injection System**

Five taps were drilled into the plexiglass cover as described previously. The 1.588 mm (1/16") OD stainless steel surgical tubing was cut into 50 mm sections. The ends smoothed and shaped to a conic point using a motorized hand tool with a grinding stone. Each section was bent into a 90-degree bend with a turn radius of 4R, approximately the radius of a pencil. The tubing was passed through the quicklock adaptor before assembling the cover. Five 190 mm long tubes connected the adapters on the cover to a manifold. A small syringe served as an ink reservoir and provided positive pressure. The ink, printer's black, was hand injected into the flow at the different injection points.




Figure 8. Overall Schematic of Experimental Apparatus, adapted from Ref 11.



### C. EXPERIMENTAL PROCEDURE

The study was divided into three phases. Phase I was to recalibrate the test rig and to recreate Masterson's thesis experimental results. Phase II included the collection of new heat transfer data, and to study the response of the thermochromic liquid crystals. Flow visualization was phase III. Ink streaklines were injected into the flow to study the flow pattern through the array.

Data collection occurred at six different power settings. The flow velocity was varied by Reynolds numbers ranging from 10 to 1000. Initially a low power input was chosen to determine whether the thermocouples responded. Several refinements to the data collection programs had to be incorporated. In particular, the data collection program was coded to send a series of instantaneous readings from both the thermocouples and flowmeter to an ASCII file for further processing. These fields were then read into a spreadsheet to determine the statistical average, mean, standard deviation and variance. Depending on the power input, the plate took about 25 to 45 minutes to reach a steady state average temperature. Therefore before taking a data run the plate was allowed to sit approximately 45 minutes before the first run. An power input ceiling of 275 watts was chosen due to precision resistor limitations. The bath temperature was maintained at 20 degrees Celsius, to mark a noted difference between inlet temperature and plate temperature.

Flow velocity was limited by the maximum pressure the plate assembly's sealant could withstand. While the pump attained a maximum capacity of 75 ml/sec, the plate assembly seals were effective only up to 53 ml/sec. Pump cavitation severely affected heat transfer measurements at high flow rates. Increasing the height of the reservoir above the pump suction decreased the incidence of cavitation only slightly.

In Phase II, it was difficult to see a response with the thermochromic crystals. To achieve any results, the bath temperature was elevated to the start temperature of the crystals. Using a high heat power input setting, the fluid flow would be varied from zero flow to approximately 60 ml/sec. When a temperature response by the liquid crystals was noted, a photograph was made. Red and blue filters were interchanged to enhance

any minute change in temperature not distinguishable to the naked eye.

For the Phase III visualization, power input to the plate was minimal. The desire was to maintain the plate at a uniform temperature, but avoid any response by the liquid crystals. The liquid crystals would sometimes turn from chalky white to dark blue-black before the red start temperature, which obscured the streaklines. Fluid flow velocity was incrementally increased from zero to 70.8 ml/sec. Converted, the fin thickness Reynolds number ranged from one to 317. Still photographs and video tape ere made of the streaklines of the fluid flow through the fin array.

### III. RESULTS

#### A. HEAT TRANSFER STUDIES

Two different Reynolds number were defined for the fluid flow analysis. The primary Reynolds number, Equation (3.1), is based on the hydraulic diameter. This is the common Reynolds number used in the heat transfer calculations. Referring to Figure (3), the hydraulic diameter, Equation (3.2), relates the cross-sectional area of a duct to its heat transfer area. Minimal cross-sectional area, in Equation. 3.3, is the fin height times the channel width. The characteristic length is the ratio,  $(A/l)$ , or the heat transfer area (A) per unit channel length (l). Since the plexiglass cover is not considered a heat transfer surface, the channel length was modeled in Equation (3.4) as an uncovered channel, and includes the blunt edges of the fins in the preceding and succeeding rows [Ref 11, p.22].

$$Re_D = \frac{\rho v \cdot D_h}{\mu} \quad \text{Eqn. 3.1}$$

$$D_h = \frac{4 \cdot \frac{A_c}{l}}{\frac{A}{l}} \quad \text{Eqn. 3.2}$$

$$A_c = s \cdot h \quad \text{Eqn. 3.3}$$

$$A = s \cdot l + 2 \cdot h \cdot l + 2 \cdot t \cdot h \quad \text{Eqn. 3.4}$$

The velocity of the fluid flow through the channels is calculated by Equation (3.5) using the volumetric flow rate as measured from the flow meter. This would be the average velocity for a fully developed flow into the free frontal area of the first row.

The free flow area ( $A_f$ ) is the minimal cross section area of the unit channel times the number of channels ( $M$ ) in the array. There are 19 and one half channels along the first fin row.

$$v = \frac{Q}{A_f} \quad \text{Eqn. 3.5}$$

$$A_f = M \cdot A_c \quad \text{Eqn. 3.6}$$

To calculate the flow rate through the flow meter a linear relationship between the output voltage from the flow meter and a sampling of timed measurements was determined. When the linear regression line was compared to a cubic and a parabolic spline interpolation curves were in close agreement to the linear regression solution.

The second Reynolds number investigated was based on the fin thickness ( $t$ ) as the characteristic length. This relationship was defined as:

$$Re_t = \frac{t \cdot U_o \cdot \rho}{\mu} \quad \text{Eqn. 3.7}$$

where  $U_o$  is the average velocity in the test section inlet. The fin thickness Reynolds number was calculated to compare flow visualization results with a previous study by Xi, et al. [Ref. 9] The uniform velocity was also the flow rate through the flow meter divided by the frontal free area of the first fin row.

Fluid properties were determined using the fluid temperature (Eqn. 3.8) averaged between the plate average temperature and the fluid inlet temperature. The thermal fluid properties were linearly interpolated over the range from 20° C to 40° C from saturated water tables [Ref. 13]. The fluid inlet temperature was monitored in two locations, in the center of the centerline inlet tubing and in the centerline of the inlet plenum. The plate average temperature was the average temperature of the fifteen thermocouples used in the centerline array.

$$T_f = \frac{T_{avg} + T_{inlet}}{2} \quad \text{Eqn. 3.8}$$

$$T_{plate} = \frac{\sum_0^N T(i)}{N} \quad \text{Eqn. 3.9}$$

Power into the plate was determined using Equations (2.1) and (2.2). Both the voltage across the heater terminals and the current into the heater were measured. Since the heater dimensions remained constant, the heat flux was easily calculated. As the plate's total heat transfer capability was the focus of this phase of the study, the average Nusselt number was calculated by Equation (3.10).

$$q'' = \frac{Power}{A_{heater}} \quad \text{Eqn. 3.10}$$

$$N_{avg} = \frac{h \cdot L}{k_f} = \frac{q'' \cdot D_h}{k_f \cdot (T_{avg} - T_{inlet})} \quad \text{Eqn. 3.11}$$

An experimental Colburn j Factor was calculated to relate the plate's dimensionless heat transfer coefficient to the Reynolds number. This was then compared to correlations devised by Weiting [Ref. 6], Manglik and Bergles [Ref. 8] and Joshi and Webb [Ref. 7].

$$j = \frac{N_{avg}}{Re_D \cdot Pr^{\frac{1}{3}}} \quad \text{Eqn. 3.12}$$

The following correlations predict the heat transfer as a function of fin geometry ratios and fluid flow velocity through the fins. Weiting's correlation was for a fin in air. He considered the correlation to be accurate within  $\pm 10\%$ , though some points deviated by forty percent [Ref. 8]. Furthermore, he questioned the "applicability of the correlations to fluids outside the gas Prandtl range [Ref. 6]." For Reynolds numbers in the laminar range, he stated that the Colburn  $j$  factor was only a function of Reynolds number and the flow passage aspect ratio or the ratio of fin length to hydraulic diameter [Ref. 6].

For  $Re_D \leq 1000$ :

$$j = 0.483 \cdot \left(\frac{l}{D_h}\right)^{-0.162} \cdot \left(\frac{s}{h}\right)^{-0.184} \cdot Re_D^{-0.536} \quad \text{Eqn. 3.13}$$

In the turbulent region, the ratio of fin thickness to hydraulic diameter is significant [Ref. 6].

$Re_D \geq 2000$ :

$$j = 0.242 \cdot \left(\frac{l}{D_h}\right)^{-0.322} \cdot \left(\frac{t}{D_h}\right)^{-0.089} \cdot Re_D^{-0.368} \quad \text{Eqn. 3.14}$$

where,

$$D_h = \frac{2sh}{s+h} \quad \text{Eqn. 3.15}$$

Manglik and Bergles in their review of past analytical models noted a need for a single predictive equation (Eqn. 3.16) for the Colburn j factor as a function of Reynolds number from the laminar region through the fully turbulent region. They held their model to be accurate within  $\pm 20\%$ . [Ref. 8].

$$j = 0.6522 \cdot Re_D^{-0.5403} \cdot \left(\frac{s}{h}\right)^{-0.1541} \cdot \left(\frac{l}{l}\right)^{-0.1499} \cdot \left(\frac{t}{s}\right)^{-0.0678} \quad \text{Eqn. 3.16}$$

H. M. Joshi and R. Webb developed Equations (3.17) and (3.18) to predict the heat transfer coefficient within the transition region until fully developed turbulence [Ref. 7]. They estimated their correlation to be accurate within  $\pm 20\%$ .

For  $Re_D \leq 1000$ :

$$j = 0.53 \cdot Re_D^{-0.50} \cdot \left(\frac{l}{D_h}\right)^{-0.15} \cdot \left(\frac{s}{h}\right)^{-0.02} \quad \text{Eqn. 3.17}$$

$Re_D \geq Re_D + 1000$ :

$$j = 0.21 \cdot Re_D^{-0.40} \cdot \left(\frac{l}{D_h}\right)^{-0.24} \cdot \left(\frac{t}{D_h}\right)^{0.02} \quad \text{Eqn. 3.18}$$

These predictive correlations were compared to the experimental value for the Colburn j Factor. These values were plotted on a semi-log chart, presented in Figure (9). The experimental data from Masterson's thesis were included for comparison. From the

combination of the current data with Masterson's, a fitted linear relationship was developed. An uncertainty analysis for the Colburn j Factor is shown in Appendix A for the 275 watt power setting at 20 % flowrate.

## **B. HEAT TRANSFER RESULTS**

Two variables were chosen for data collection. These were fluid flow rate and the power input to the heater. The flow rate was varied so that the Reynolds number varied from 100 to 1000; the power input, from 100 to 275 watts. Using a spreadsheet, the arithmetic average, median, standard deviation and a variance was calculated for the approximately sixty-six data points. A sample calculation is presented in Appendix B for the 275 watt power setting at 20% flowrate. From these numerical computations, the plate average temperature, fluid temperature, flow rate and heat flux were determined. Appendix C contains the mean data for each run, with accompanying centerline distribution graphs.

Table (I) contains the final Colburn j factors as calculated using Equations (2.1 - 2.2) and Equations (3.1 to 3.12). Masterson's data is listed in Table (II) [Ref. 11]. The Colburn j factors listed in Tables (I) and (II) were then combined and plotted on the same graph, Figure (9). Masterson's data, labeled O, fell consistently above the predicted j factors, while the current data, labeled X, lands below. Plotting the zone of accuracy as published by Weiting [Ref. 6], Manglik and Bergles [Ref. 8], and Joshi and Webb [Ref. 7] show the experimental data to be just on the outer edges of accuracy.

The plate average temperature was skewed low. A linear regression of the temperature readings from thermocouples labeled 101 to 113 was made to improve the accuracy of the temperature average. Since the thermocouples were placed between the bottom of the plate and the thermofoil heater, the proximity of the thermocouple junction to the electrical resistor wires in the pad may have caused peak temperature readings. Thermocouples 103, 111 and 112 had consistently high temperature values, so were discounted in the linear regression computation.

Excessive leakage from the side of the assembly at high flow rates prevented obtaining any meaningful data at Reynolds numbers higher than  $Re = 1000$ . The best



heat transfer results were at the higher power input to the heater strip, as expected. The 250W and 275 W test runs yielded more comprehensible data. These runs were repeated three times with similar results. Towards the end of the heat transfer experimental phase the first thermocouple along the centerline, 101, ceased functioning. This was compensated by averaging the side thermocouples, 402 and 403, and substituting that value into the linear regression for centerline temperature.

| Re  | $q''$ (W/m <sup>2</sup> ) | $\delta T$ (°C) | Nu <sub>AVG</sub> | j     |
|-----|---------------------------|-----------------|-------------------|-------|
| 950 | 3522                      | 4.8             | 14.1              | .0086 |
| 811 | 3228                      | 3.3             | 36.9              | .0187 |
| 676 | 1904                      | 2.2             | 17.1              | .0137 |
| 616 | 2720                      | 1.6             | 33.3              | .0314 |
| 613 | 3522                      | 1.8             | 36.4              | .0351 |
| 603 | 1878                      | 1.8             | 20.0              | .0180 |
| 584 | 3527                      | 2.1             | 32.2              | .0323 |
| 567 | 1890                      | 2.4             | 15.6              | .0149 |
| 565 | 3526                      | 1.9             | 35.8              | .0374 |
| 560 | 3524                      | 1.8             | 37.6              | .0396 |
| 559 | 3524                      | 1.8             | 37.0              | .0390 |
| 542 | 3227                      | 3.3             | 36.9              | .0280 |
| 499 | 3227                      | 3.3             | 36.9              | .0304 |
| 458 | 2720                      | 17.9            | 3.0               | .0038 |
| 455 | 3228                      | 1.9             | 32.4              | .0413 |
| 438 | 2720                      | 17.5            | 3.0               | .0040 |
| 39  | 2719                      | 17.9            | 3.0               | .0439 |

Table I. Experimental Data from Horizontal Test Section.

| Re  | $q''$ (W/m <sup>2</sup> ) | $\delta T$ (°C) | Nu <sub>AVG</sub> | j        |
|-----|---------------------------|-----------------|-------------------|----------|
| 211 | 2485                      | 6.0             | 11.2              | .027     |
| 224 | 2025                      | 6.4             | 8.7               | .020     |
| 245 | 3495                      | 9.7             | 9.8               | 0.021    |
| 263 | 2485                      | 6.0             | 11.3              | 0.022    |
| 295 | 1960                      | 5.2             | 10.2              | 0.018    |
| 305 | 2485                      | 5.8             | 11.6              | 0.020    |
| 322 | 3495                      | 9.6             | 9.8               | 0.016    |
| 380 | 3505                      | 7.9             | 11.9              | 0.017    |
| 441 | 3505                      | 7.8             | 12.1              | 0.015    |
| 518 | 3510                      | 7.5             | 12.6              | 0.013    |
| 563 | 3505                      | 7.4             | 12.7              | 0.012    |
| 623 | 3505                      | 7.3             | 12.8              | 0.011    |
| 674 | 3505                      | 7.6             | 12.4              | 0.010.01 |
| 731 | 3515                      | 8.0             | 11.7              | 0.009    |
| 770 | 3515                      | 6.9             | 13.6              | 0.010    |

Table II. Horizontal Test Section Data, From Ref. [11].




Figure 9. Colburn j Factor versus Reynolds.

### C. THERMOCHROMIC LIQUID CRYSTALS

Spray-coating the plate to monitor the change in transverse and longitudinal temperatures was unsuccessful. Even though water-resistant paints were used, the crystals proved unresponsive under water. Prior test runs using air passing over the heated plate showed temperature response. The plate, with the plexiglass cover off, when heated in air to approximately  $38^{\circ}\text{C}$  changed to an even dark green color. A small fan, approximately one-third the plate width, then directed air down the plate's centerline. A color change to red (approximately  $30^{\circ}\text{C}$ ) and black (below  $30^{\circ}\text{C}$ ) was noted in the front central region of the plate. Transversely, the color change was abrupt, where the air flow's edge was formed by the fins. Gradually the color returned to dark green down the centerline of the plate.

This suggests that the flow of air cooled the plate until the forced air dissipated. The fins served to guide the air downstream, and blocked the air from crossing over to another channel. This also suggests the effectiveness of the thermofoil heater pad in providing uniform heating. When heated in still air, the plate showed a solid band on one side of the plate. After reaching steady state as indicated by the thermocouples, the plate was of uniform color. The red start of the crystals corresponded to  $30.5^{\circ}\text{C}$  average plate temperature.

Unfortunately these results were not to be duplicated when water passed through the array. When the plate was at low power settings, there was no change in the plate's appearance. At moderate power settings while the fluid inlet temperature was at ambient, the fins and plate bottom seemed coated with a chalky white gel. This cleared when the inlet temperature was raised to above the red start temperature of the crystals. Some crystals began to respond when the fluid temperature was raised to  $40^{\circ}\text{C}$  and the power input to the plate was maximized.

To salvage the results of this phase of the study, the plate was disassembled. A thin sheet of Mylar impregnated by the thermochromic crystals with a range of  $30^{\circ}$  to  $35^{\circ}\text{C}$  was placed on top of the fins. The plate was again heated and tested in air. Thin slices of deep blue were seen where the fin tips contacted the sheet. The remainder of the

sheet was light green. As air was forced through the fins the thin slices turned green and the open region turned red to black. The effect was noted in the first three rows until the air dissipated.

When the plate was reassembled and water used as the coolant, there was better response. Entrapped air between the sheet and the plexiglass cover prevented any meaningful data concerning the water temperature and heat transfer coefficients. The sheet did indicate a temperature difference between the centerline and edge temperatures.

The best response was at the highest power setting tested, 275 watts. Flow was within the 400 Reynolds number. When the plate reached steady state, the center front and middle regions were visually light green and red. This corresponds to a surface temperature of approximately  $31^{\circ}\text{C}$ . The edges of the test assembly were a deep blue suggesting that the water was at a higher temperature than the centerline. The sheet made a rapid change to deep blue along the centerline at the fifteenth row, about three-quarters down the plate. When the flow was increased to  $Re_D \approx 600$ , the cooler region extended toward the end of the plate; at lower flow rates, it became shorter.

#### **D. FLOW VISUALIZATION**

Blue printer's ink injected into the fluid prior to the first fin's leading edge. This provided a flow visualization. The plate was unheated, to allow the clearest background for the ink trail. Flow was varied in five equal steps from zero to 50% power, equating to Reynolds range of 100 to 2200. This corresponds to a fin thickness Reynolds number range of 50 to 220. Photographic stills and video was taken at each flow setting. The angle of the injection tubing to the flow was also changed to place the ink streak at the fin edge and in the center of the channel.

When the ink streak was introduced at the leading edge of the fin at low flow rates, the ink followed the side of the fin. The ink did not rise perceptibly from the level of injection, about half the fin height. The ink then curled around the trailing edge of the fin, to its center. From this point, the flow carried the ink straight back through the center of the open channel until reaching the leading fin edge of the next row. After being deflected by the laminar boundary layer forming on the fin, the pattern repeated

itself. This lasted throughout the first five rows of the fin array under observation.

At slightly higher fluid velocities, the flow began to waver slightly inside the third fin row. After passing the third row, the streaklines produced a more severe wavy pattern. Mixing was readily recognizable in rows four and five. Regular vortices and a turbulent wake were evident at the highest velocities. Separation with a turbulent wake was readily evident at  $Re_t \approx 170$ . This corresponds to the findings of Ref. (9).





## **IV. CONCLUSIONS**

### **A. HEAT TRANSFER STUDIES**

The experimental values come to close agreement to the predicted values. When coupled with Masterson's results, the fitted curve falls within the lower bounds of the Joshi-Webb correlation. There are some incongruities between the two data sets as seen in Figure (9). This graph shows the data from Masterson was consistently lower than predicted values. This study's current data was higher, but over a shorter range. The differences are readily explained by the inability to duplicate the previous study's data collection technique. Both exhibited the same asymptotic behavior of the predicted curve.

### **B. TEMPERATURE DISTRIBUTION**

Since the liquid crystals did not perform as expected, very little can be gleaned as to the transverse temperature distribution. However, it is evident that the flow was not uniform across the width of plate. The visual evidence that more heat was being transferred to the fluid at the edges than the center. The effect of the channel wall may disrupt the mixing effects of the array in the centerline. Finally, the technique used to apply encapsulated crystals needed improvement, so that the crystals may be used at a solid-liquid interface.


The photographic record was inconclusive. There was some practical knowledge gained from the attempt to collect data. A more sophisticated method should be devised to include the use of thermographic films or digital recorders. The black paint backdrop also proved not conducive to clear photographs. This was especially true in the next portion of the study, flow visualization.

### C. FLOW VISUALIZATION


The dye injection, while crude, effectively showed agreement with Xi, etal. The flow was fully turbulent behavior occurred at  $Re_t = 170$ . This equates to  $Re_D = 2000$ . Transition occurred approximately at  $Re_D = 890$ . Early transition to turbulence may have been a function of the following factors:

- scoring and burrs on the fin sides from the milling process.
- the rubber gasket between the first row and inlet plenum acting as a trip wire.
- roughness on the array's surface stemming from the spray-coating of the liquid crystals.
- vortices introduced by the flow straightener assembly.


Figure (10) is from Xi, etal. The observed flow patterns are from visual observations as recorded by photographs and video camcorder. It is difficult to reproduce the corkscrew effect seen in the midmost fin rows. Pattern (a) is at low flow rates, and is laminar as predicted. Patterns (b), (c) and (d) show increasing turbulent flow. Finally pattern (e) is fully turbulent flow.




(a)  $Re < 80$



(b)  $80 < Re < 100$



(c)  $100 < Re < 130$



(d)  $130 < Re < 170$



(e)  $Re > 170$

Figure 10. Flow patterns transcribed from visual observations based on format used in Ref. 9.



## **V. RECOMMENDATIONS**

In any continuation of this study, the following additional work is recommended.

- Redesign and manufacture a new removable cover for the plate fin array. The use of an O-ring seal or other type of gasketing will be essential if PAO or other dielectric fluids are to be used.
- Attach the liquid crystal impregnated Mylar sheet on the plexiglass cover itself. The plexiglass cover should have a frame to allow changing the sheet to investigated a different temperature range.
- Investigate the use of spray-coating liquid crystals with a lower redstart temperature. One focus would be whether the crystals have a quick enough response time to notice any local temperature variations caused by the turbulence.
- Conduct the experiment using heated air as the working fluid to investigate the local temperature changes in the fin channel and fin surfaces at each row.
- Further consolidate the research to correlate data from the heat transfer studies on the external Flow-through-module assembly.



## APPENDIX A. UNCERTAINTY ANALYSIS

An uncertainty analysis is provided to evaluate the accuracy of the data collected. The uncertainty function,  $F = F(X_1, X_2, X_3)$ , where  $X_i$  are the independent measurements is calculated by:

$$\delta F = \sqrt{\left(\frac{\partial F}{\partial X_1} \cdot \delta X_1\right)^2 + \left(\frac{\partial F}{\partial X_2} \cdot \delta X_2\right)^2 + \left(\frac{\partial F}{\partial X_3} \cdot \delta X_3\right)^2}$$

Eqn. A.1

For  $F = C X_1^a X_2^b X_3^c$ , uncertainty takes the following form:

$$\frac{\delta F}{F} = \sqrt{\left(a \cdot \frac{\delta X_1}{X_1}\right)^2 + \left(b \cdot \frac{\delta X_2}{X_2}\right)^2 + \left(c \cdot \frac{\delta X_3}{X_3}\right)^2}$$

Eqn. A.2.

### 1. Reynolds Number Uncertainty

$$Re_D = \frac{\rho v D_h}{\mu}$$

Eqn 3.1

here

$$\frac{\delta Re}{Re} = \sqrt{\left(\frac{\delta v}{v}\right)^2 + \left(\frac{\delta D_h}{D_h}\right)^2}$$

and

$$\frac{\delta D_h}{D_h} = \sqrt{\left(\frac{\delta A_c}{A_c}\right)^2 + \left(\frac{\delta\left(\frac{A}{l}\right)}{\frac{A}{l}}\right)^2}$$

The geometric dimensions and fluid thermal properties with uncertainty of measurement.

#### Plate Dimensions

#### Uncertainty

$$A_c = 0.0001792 \text{ m}^2$$

$$A = 0.001387 \text{ m}^2$$

$$l = 0.03175 \text{ m}$$

$$\delta l = 0.5 \text{ mm}$$

$$s = 0.01175 \text{ m}$$

$$\delta s = 0.5 \text{ mm}$$

$$t = 0.00152 \text{ m}$$

$$\delta t = 0.5 \text{ mm}$$

$$h = 0.01524 \text{ m}$$

$$\delta h = 0.5 \text{ mm}$$

#### Fluid Properties [Ref. 13]

$$\delta v = 0.004 \text{ m/s}$$

$$\rho = 993.8 \text{ kg/m}^3$$

$$T_f = 308.4 \text{ K}$$

$$k_f = 0.6254 \text{ watt/m}^\circ\text{K}$$

$$\mu = 718.7 \times 10^{-6} \text{ N}^\circ\text{sec/m}^2$$

#### Calculated Uncertainties

$$\delta A_c = 9.62 \text{ E-06 m}$$

$$\delta A = 0.0005 \text{ m}$$

$$\delta(A/l) = 707 \text{ E-06 m}$$

$$\delta D_h = 920 \text{ E-06 m}$$

$$D_h = .0164 \text{ m}$$

Substituting into above yields

$$Re_D = 123 \pm 9$$



Therefore the uncertainty  $\delta Re/Re = 0.073$  or 7.3%.

## 2. Colburn j Factor Uncertainty

$$j = \frac{N_{AVG}}{Re_D \cdot Pr^{\frac{1}{3}}}$$

and

$$\frac{\delta j}{j} = \sqrt{\left(\frac{\delta N}{N}\right)^2 + \left(\frac{\delta Re}{Re}\right)^2}$$

where

$$N_{AVG} = \frac{q'' \cdot D_h}{k_f \cdot (T_{avg} - T_{inlet})}$$

and

$$q'' = \frac{Power}{A_H}$$

$$A_h = W \cdot L$$

$$Power = V_{heater} \cdot \left(\frac{V_{resistor}}{R}\right)$$

$$W = 0.0254 \text{ m}$$

$$\delta W = 0.0005 \text{ m}$$

$$L = 0.0305 \text{ m}$$

$$\delta L = 0.0005 \text{ m}$$

$$T_{\text{AVG}} = 32.12^{\circ} \text{ C}$$

$$\delta A_H = 0.012 \text{ m}^2$$

$$T_{\text{Inlet}} = 34.34^{\circ} \text{ C}$$

$$\delta T = 0.034^{\circ} \text{ C}$$

$$\Delta T = 1.78 \pm 0.034^{\circ} \text{ C}$$

$$A_H = 0.07742 \pm .012 \text{ m}^2$$

$$\text{Power} = 272.7 \pm .001144 \text{ W}$$

$$q'' = 3522 \pm 0.095 \text{ W/m}^2$$

$$\text{Re} = 613 \pm 43.5$$

$$\text{Pr} = 4.860$$

Therefore,

$$\text{Nu}_{\text{AVG}} = 51.87 \pm 3.1$$

$$j = 0.03506 \pm 0.00324$$

The uncertainty  $\delta j/j = 0.0924$  or 9.2%. This is well within the 10% accuracy range predicted by both the Joshi-Webb and Weiting correlations.

## APPENDIX B. SAMPLE CALCULATIONS

The following calculation is for the following setpoint.

$$Q = (V_1 - 0.392) \times 166.11$$

$$\text{Power} = 272.68 \text{ watts}$$

$$T_{\text{AVG}} = 36.12^\circ \text{ C}$$

$$T_{\text{Inlet}} = 34.34^\circ \text{ C}$$

### 1. Characteristic Dimension

$$A_c = s \cdot h = (11.75 \text{ mm})(15.24 \text{ mm})$$

$$A_c = 179.1 \text{ mm}^2$$

$$A = s \cdot l + 2 \cdot h \cdot l + 2 \cdot t \cdot h$$

$$A = (11.75 \text{ mm})(31.75 \text{ mm}) + 2 \cdot (15.24 \text{ mm})(31.75 \text{ mm}) \\ + 2 \cdot (1.52 \text{ mm})(15.24 \text{ mm})$$

$$A = 1387.1 \text{ mm}^2$$

$$A/l = (1387.1 \text{ mm}^2)/(31.75 \text{ mm}) = 43.69 \text{ mm}$$

$$A_f = M \cdot A_c = (19.5)(179.1 \text{ mm}^2)$$

$$A_f = 3492.4 \text{ mm}^2$$

$$D_h = 4 \cdot A_c / (A/l) = 4 \cdot (179.1 \text{ mm}) / (1387.1 \text{ mm} / 31.75 \text{ mm})$$

$$D_h = 16.39 \text{ mm}$$

### 2. Water Properties

$$T_f = (T_{\text{AVG}} + T_{\text{Inlet}})/2 = (36.12 + 34.34)/2 + 273.15 \text{ K}$$

$$T_f = 308.2 \text{ K}$$

Using Table A.6 [Ref. 13]

$$\rho = 993.8 \text{ kg/m}^3$$

$$k_f = 0.6254 \text{ watt/m} \cdot \text{K}$$

$$\mu = 718.7 \times 10^{-6} \text{ N} \cdot \text{sec/m}^2$$

$$\Delta T = T_{\text{AVG}} - T_{\text{Inlet}} = 36.12 - 34.24 = 1.78 \text{ K}$$

### 3. Reynolds Number

$$\begin{aligned} \text{Re}_D &= \rho v D_h / \mu \\ &= \frac{(993.8 \text{ kg/m}^3)(5.428 \text{ E-03 m/sec})(0.01639 \text{ m})}{(718.7 \text{ E-06 N sec/m}^2)} \\ &= 123.1 \end{aligned}$$

### 4. Nusselt Number

$$\begin{aligned} q'' &= \text{Power}/A_h = (272.68 \text{ watt})/(774.2 \text{ cm}^2) \\ q'' &= 0.352 \text{ watt/cm}^2 \\ \text{Nu}_{\text{AVG}} &= q'' * D_h / (k_f * \Delta T) \\ \text{Nu}_{\text{AVG}} &= (0.352 \text{ watt/cm}^2)(0.01639 \text{ m}) / (0.6254 \text{ watt/m K})(1.78 \text{ K}) \\ &= 51.87 \end{aligned}$$

### 5. Colburn j Factor

$$\begin{aligned} j &= \text{Nu}_{\text{AVG}} / (\text{Re}_D \text{ Pr}^{1/4}) = (51.87) / (123.1)(4.808)^{1/4} \\ j &= 0.250 \end{aligned}$$

## **APPENDIX C. HEAT TRANSFER DATA COLLECTION**

### **A. Centerline Temperature Distribution**

#### **1. Figures 11 through 32.**

Centerline Temperature distribution graphs for each power setting and flow rate.

### **B. Thermocouple Data**

#### **1. Figures 33 through 53.**

Thermocouple data collected at each power setting and flowrate. This data was placed on a spreadsheet to determine average, maximum, minimum, standard deviation and variance for each thermocouple.

### **C. Colburn j Factor**

#### **1. Spreadsheet for Colburn j Factor**

Using the equations shown in chapters two and three the following are the results used to plot the Colburn j Factor graph, Figure 9.



**Centerline Temperature Distribution**  
**Figures 11 through 32**

# Centerline Temperature Distribution

100 Watt Input at 10% Pump Setting




Figure 11. 100 Watts Heat Input at 10% Flow Rate



# Centerline Temperature Distribution

150 Watt Input at 0% Pump Setting




Figure 12. 150 Watts Heat Input at 0% Flow Rate

# Centerline Temperature Distribution 150 Watt Input at 10% Pump Setting




Figure 13. 150 Watts Heat Input at 10% Flow Rate

# Centerline Temperature Distribution

150 Watt Input at 10% Pump Setting




Figure 14. 150 Watts Heat Input at 20% Flow Rate

# Centerline Temperature Distribution

210 Watt Input at 0% Pump Setting




Figure 15. 210 Watts Heat Input at 0% Flow Rate

# Centerline Temperature Distribution

210 Watt Input at 15% Pump Setting




Figure 16. 210 Watts Heat Input at 15% Flow Rate

# Centerline Temperature Distribution 210 Watt Input at 15% Pump Setting




Figure 17. 210 Watts Heat Input at 15% Flow Rate

# Centerline Temperature Distribution 210 Watt Input at 15% Pump Setting




Figure 18. 210 Watts Heat Input at 15% Flow Rate

# Comparison of Three Data Runs




Figure 19. 210 Watts Heat Input at 15% Flow Rate



# Centerline Temperature Distribution

210 Watt Input at 20% Pump Setting




Figure 20. 210 Watts Heat Input at 20% Flow Rate

# Centerline Temperature Distribution

210 Watt Input at 25% Pump Setting




Figure 21. 210 Watts Heat Input at 25% Flow Rate

# Centerline Temperature Distribution 250 Watt Input at 15% Pump Setting




Figure 22. 250 Watts Heat Input at 15% Flow Rate




Figure 23. 250 Watts Heat Input at 20% Flow Rate

# Centerline Temperature Distribution 250 Watt Input at 25% Pump Setting




Figure 24. 250 Watts Heat Input at 25% Flow Rate




Figure 25. 275 Watts Heat Input at 15% Flow Rate




Figure 26. 275 Watts Heat Input at 15% Flow Rate




Figure 27. 275 Watts Heat Input at 15% Flow Rate



# Centerline Temperature Distribution 275 Watt Input at 20% Pump Setting




Figure 28. 275 Watts Heat Input at 20% Flow Rate

# Centerline Temperature Distribution

275 Watt Input at 20% Pump Setting




Figure 29. 275 Watts Heat Input at 20% Flow Rate




Figure 30. 275 Watts Heat Input at 25% Flow Rate

# Centerline Temperature Distribution

275 Watt Input at 30% Pump Setting




Figure 31. 275 Watts Heat Input at 30% Flow Rate




Figure 32. 275 Watts Heat Input at 40% Flow Rate



**Thermocouple Data**  
**Figures 33 through 53**

| <b>Pump Setting</b>  | <b>10</b>             |                       |                       |                        |                        |
|----------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>T.C.</u></b>   | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| 100                  | 22.189                | 22.297                | 21.950                | 0.1111                 | 0.0123                 |
| 101                  | 20.045                | 20.116                | 20.007                | 0.0234                 | 0.0005                 |
| 102                  | 22.908                | 23.045                | 22.727                | 0.1047                 | 0.0110                 |
| 103                  | 29.819                | 29.963                | 29.688                | 0.0721                 | 0.0052                 |
| 104                  | 23.653                | 23.811                | 23.486                | 0.0851                 | 0.0072                 |
| 105                  | 24.636                | 24.957                | 24.387                | 0.1384                 | 0.0192                 |
| 106                  | 24.360                | 24.558                | 24.031                | 0.1223                 | 0.0149                 |
| 107                  | 23.440                | 23.636                | 22.796                | 0.2123                 | 0.0451                 |
| 108                  | 22.969                | 23.272                | 22.572                | 0.2230                 | 0.0497                 |
| 109                  | 29.629                | 29.822                | 29.567                | 0.0895                 | 0.0080                 |
| 110                  | 23.543                | 23.611                | 23.426                | 0.0435                 | 0.0019                 |
| 111                  | 30.997                | 31.083                | 30.921                | 0.0453                 | 0.0021                 |
| 112                  | 29.919                | 30.001                | 29.872                | 0.0250                 | 0.0006                 |
| 113                  | 24.272                | 24.330                | 24.180                | 0.0398                 | 0.0016                 |
| 114                  | 22.921                | 23.021                | 22.785                | 0.0445                 | 0.0020                 |
| 115-Inlet Pipe       | 20.732                | 21.962                | 20.420                | 0.5620                 | 0.3159                 |
| 116 - Zero Reference | 0.376                 | 0.459                 | 0.266                 | 0.0410                 | 0.0017                 |
| 117 - Outlet Plenum  | 21.877                | 21.950                | 21.800                | 0.0336                 | 0.0011                 |
| 118 - Inlet Plenum   | 17.237                | 17.438                | 16.721                | 0.1787                 | 0.0319                 |
| <b><u>T.C.</u></b>   | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| 400                  | 16.465                | 16.525                | 16.402                | 0.0274                 | 0.0007                 |
| 401                  | 22.016                | 22.185                | 21.816                | 0.1085                 | 0.0118                 |
| 402                  | 21.979                | 22.140                | 21.791                | 0.1070                 | 0.0114                 |
| 403                  | 24.916                | 25.010                | 24.761                | 0.0692                 | 0.0048                 |
| 404                  | 24.974                | 25.089                | 24.787                | 0.0866                 | 0.0075                 |
| 405                  | 30.292                | 30.456                | 30.126                | 0.0927                 | 0.0086                 |
| 406                  | 24.390                | 24.532                | 24.254                | 0.0783                 | 0.0061                 |
| 407                  | 26.882                | 26.940                | 26.771                | 0.0458                 | 0.0021                 |
| 408                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| 409                  | 25.134                | 25.284                | 25.064                | 0.0498                 | 0.0025                 |
| 410                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| 411                  | 22.629                | 22.759                | 22.380                | 0.0542                 | 0.0029                 |
| 412                  | 22.840                | 22.965                | 22.807                | 0.0303                 | 0.0009                 |

Figure 33. 100 Watts Heat Input at 10% Flow Rate



|                                    |                        |        |            |        |        |
|------------------------------------|------------------------|--------|------------|--------|--------|
| <b>413</b>                         | 22.408                 | 22.580 | 22.290     | 0.0605 | 0.0037 |
| <b>414 - Bath Temp</b>             | 16.913                 | 17.283 | 16.218     | 0.2711 | 0.0735 |
| <b>415 - Replaced 410</b>          | 17.706                 | 17.772 | 17.621     | 0.0349 | 0.0012 |
| <b>416 - Zero Reference</b>        | 0.192                  | 0.473  | -0.196     | 0.1240 | 0.0154 |
| <b>417 - Top of Plate</b>          | 22.260                 | 22.315 | 22.186     | 0.0326 | 0.0011 |
| <b>418 - Ambient Air</b>           | 21.471                 | 21.703 | 21.213     | 0.1389 | 0.0193 |
| <b>419 - Bottom Insulation</b>     | 28.469                 | 28.603 | 27.926     | 0.1994 | 0.0398 |
|                                    |                        |        |            |        |        |
| <b>421 - Side Insulation</b>       | 15.815                 | 16.082 | 15.589     | 0.1014 | 0.0103 |
| <b>422 - Plate Top (over 417)</b>  | 16.879                 | 16.905 | 16.852     | 0.0114 | 0.0001 |
| <b>423 - Side of Plate</b>         | 19.660                 | 19.718 | 19.612     | 0.0303 | 0.0009 |
|                                    |                        |        |            |        |        |
| <b>V1 - Flow Meter VDC</b>         | 0.554                  | 0.571  | 0.547      | 0.0045 | 0.0000 |
| <b>V2 - Precision Resistor VDC</b> | 0.300                  | 0.300  | 0.300      | 0.0000 | 0.0000 |
| <b>V3 - Heater Terminals Vdc</b>   | 33.358                 | 33.358 | 33.358     | 0.0001 | 0.0000 |
|                                    |                        |        |            |        |        |
| <b>Bath Temp (F), (C)</b>          | 22.000                 |        |            |        |        |
| <b>Sampling Time</b>               | 0.162                  | 0.179  | 0.155      | 0.0045 | 0.0000 |
| <b>Power (watts)</b>               | 99.141                 | 99.154 | 99.096     | 0.0152 | 0.0002 |
| <b>Flow Rate (mL/sec)</b>          | 26.929                 | 29.721 | 25.668     |        |        |
|                                    | Plate Mean Temperature |        |            |        |        |
| <b>Centerline Mean Temp</b>        | 25.222                 |        |            |        |        |
| <b>Standard Deviation</b>          | 3.262                  |        | Delta Temp | 3.2224 |        |
| <b>Variance</b>                    | 10.639                 |        |            |        |        |
| <b>Centerline Maximum Temp</b>     | 30.997                 | 31.083 | 30.921     | 0.2230 | 0.0497 |
| <b>Centerline Minimum Temp</b>     | 20.045                 | 20.116 | 20.007     | 0.0234 | 0.0005 |
| <b>Centerline Delta Temp</b>       | 10.952                 | 10.967 | 10.914     | 0.1996 | 0.0492 |

Figure 33. 100 Watts Heat Input at 10% Flow Rate

| <b>Pump Setting</b>  | <b>10</b>             |                       |                       |                        |                        |
|----------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>T.C.</u></b>   | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| 100                  | 23.150                | 23.191                | 23.117                | 0.0160                 | 0.0003                 |
| 101                  | 24.348                | 24.377                | 24.322                | 0.0115                 | 0.0001                 |
| 102                  | 24.497                | 24.565                | 24.470                | 0.0167                 | 0.0003                 |
| 103                  | 30.520                | 30.561                | 30.479                | 0.0183                 | 0.0003                 |
| 104                  | 24.741                | 24.889                | 24.679                | 0.0446                 | 0.0020                 |
| 105                  | 22.919                | 22.979                | 22.857                | 0.0326                 | 0.0011                 |
| 106                  | 25.335                | 25.356                | 25.304                | 0.0116                 | 0.0001                 |
| 107                  | 24.796                | 24.819                | 24.771                | 0.0115                 | 0.0001                 |
| 108                  | 24.745                | 24.775                | 24.657                | 0.0185                 | 0.0003                 |
| 109                  | 25.962                | 26.008                | 25.929                | 0.0133                 | 0.0002                 |
| 110                  | 25.254                | 25.279                | 25.231                | 0.0131                 | 0.0002                 |
| 111                  | 28.670                | 28.698                | 28.633                | 0.0135                 | 0.0002                 |
| 112                  | 31.666                | 31.688                | 31.639                | 0.0132                 | 0.0002                 |
| 113                  | 25.669                | 25.745                | 25.637                | 0.0244                 | 0.0006                 |
| 114                  | 24.751                | 24.791                | 24.721                | 0.0139                 | 0.0002                 |
| 115-Inlet Pipe       | 22.729                | 22.762                | 22.705                | 0.0127                 | 0.0002                 |
| 116 - Zero Reference | 0.125                 | 0.183                 | 0.071                 | 0.0251                 | 0.0006                 |
| 117 - Outlet Plenum  | 22.473                | 22.520                | 22.428                | 0.0188                 | 0.0004                 |
| 118 - Inlet Plenum   | 18.972                | 19.049                | 18.780                | 0.0565                 | 0.0032                 |
| <b><u>T.C.</u></b>   | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| 400                  | 18.452                | 18.717                | 18.335                | 0.0739                 | 0.0055                 |
| 401                  | 23.271                | 23.326                | 23.226                | 0.0218                 | 0.0005                 |
| 402                  | 23.029                | 23.057                | 23.009                | 0.0101                 | 0.0001                 |
| 403                  | 26.171                | 26.209                | 26.149                | 0.0103                 | 0.0001                 |
| 404                  | 26.980                | 27.009                | 26.955                | 0.0107                 | 0.0001                 |
| 405                  | 29.332                | 29.355                | 29.297                | 0.0121                 | 0.0001                 |
| 406                  | 25.108                | 25.139                | 25.076                | 0.0114                 | 0.0001                 |
| 407                  | 26.716                | 26.755                | 26.688                | 0.0128                 | 0.0002                 |
| 408                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| 409                  | 27.903                | 27.934                | 27.867                | 0.0134                 | 0.0002                 |
| 410                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| 411                  | 23.730                | 23.883                | 23.683                | 0.0295                 | 0.0009                 |
| 412                  | 23.923                | 23.948                | 23.875                | 0.0137                 | 0.0002                 |

Figure 34. 150 Watts Heat Input at 0% Flow Rate

|                                    |         |         |                   |        |        |
|------------------------------------|---------|---------|-------------------|--------|--------|
| <b>413</b>                         | 23.801  | 23.844  | 23.763            | 0.0159 | 0.0003 |
| <b>414 - Bath Temp</b>             | 18.822  | 19.458  | 17.848            | 0.3641 | 0.1326 |
| <b>415 - Replaced 410</b>          | 26.520  | 26.556  | 26.479            | 0.0157 | 0.0002 |
| <b>416 - Zero Reference</b>        | 0.010   | 0.110   | -0.165            | 0.0687 | 0.0047 |
| <b>417 - Top of Plate</b>          | 23.466  | 23.559  | 23.381            | 0.0394 | 0.0016 |
| <b>418 - Ambient Air</b>           | 16.773  | 16.848  | 16.714            | 0.0335 | 0.0011 |
| <b>419 - Bottom Insulation</b>     | 29.959  | 29.985  | 29.934            | 0.0113 | 0.0001 |
|                                    |         |         |                   |        |        |
| <b>421 - Side Insulation</b>       | 18.678  | 18.876  | 18.493            | 0.1079 | 0.0116 |
| <b>422 - Plate Top (over 417)</b>  | 16.739  | 16.810  | 16.646            | 0.0391 | 0.0015 |
| <b>423 - Side of Plate</b>         | 21.812  | 22.054  | 21.553            | 0.1048 | 0.0110 |
|                                    |         |         |                   |        |        |
| <b>V1 - Flow Meter Vdc</b>         | 0.436   | 0.459   | 0.418             | 0.0107 | 0.0001 |
| <b>V2 - Precision Resistor Vdc</b> | 0.363   | 0.364   | 0.363             | 0.0003 | 0.0000 |
| <b>V3 - Heater Terminals Vdc</b>   | 40.656  | 40.656  | 40.656            | 0.0001 | 0.0000 |
|                                    |         |         |                   |        |        |
| <b>Bath Temp (C)</b>               | 22.200  |         |                   |        |        |
| <b>Sampling Time</b>               | 0.044   | 0.066   | 0.026             | 0.0107 | 0.0001 |
| <b>Power (watts)</b>               | 146.158 | 146.466 | 145.938           | 0.1258 | 0.0158 |
| <b>Flow Rate (mL/sec)</b>          | 7.272   | 11.041  | 4.259             |        |        |
| <b>Plate Mean Temperature</b>      |         |         |                   |        |        |
| <b>Centerline Mean Temp</b>        | 25.991  |         |                   |        |        |
| <b>Standard Deviation</b>          | 2.412   |         | <b>Delta Temp</b> | 3.7909 |        |
| <b>Variance</b>                    | 5.816   |         |                   |        |        |
| <b>Centerline Maximum Temp</b>     | 31.666  | 31.688  | 31.639            | 0.0446 | 0.0020 |
| <b>Centerline Minimum Temp</b>     | 22.919  | 22.979  | 22.857            | 0.0115 | 0.0001 |
| <b>Centerline Delta Temp</b>       | 8.746   | 8.710   | 8.781             | 0.0332 | 0.0019 |

Figure 34. 150 Watts Heat Input at 0% Flow Rate

| <b>Pump Setting</b>         | <b>10</b>             |                       |                       |                        |                        |
|-----------------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>100</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>101</b>                  | 24.355                | 24.397                | 24.310                | 0.0187                 | 0.0003                 |
| <b>102</b>                  | 24.475                | 24.521                | 24.427                | 0.0191                 | 0.0004                 |
| <b>103</b>                  | 30.565                | 30.596                | 30.509                | 0.0177                 | 0.0003                 |
| <b>104</b>                  | 24.800                | 24.937                | 24.747                | 0.0388                 | 0.0015                 |
| <b>105</b>                  | 23.150                | 23.209                | 23.081                | 0.0284                 | 0.0008                 |
| <b>106</b>                  | 25.319                | 25.354                | 25.291                | 0.0137                 | 0.0002                 |
| <b>107</b>                  | 24.752                | 24.803                | 24.717                | 0.0141                 | 0.0002                 |
| <b>108</b>                  | 24.710                | 24.739                | 24.677                | 0.0140                 | 0.0002                 |
| <b>109</b>                  | 25.944                | 25.977                | 25.914                | 0.0146                 | 0.0002                 |
| <b>110</b>                  | 25.028                | 25.207                | 24.935                | 0.0624                 | 0.0039                 |
| <b>111</b>                  | 28.713                | 28.776                | 28.614                | 0.0307                 | 0.0009                 |
| <b>112</b>                  | 31.581                | 31.616                | 31.536                | 0.0166                 | 0.0003                 |
| <b>113</b>                  | 25.610                | 25.660                | 25.522                | 0.0345                 | 0.0012                 |
| <b>114</b>                  | 24.708                | 24.749                | 24.674                | 0.0139                 | 0.0002                 |
| <b>115-Inlet Pipe</b>       | 22.759                | 22.825                | 22.701                | 0.0240                 | 0.0006                 |
| <b>116 - Zero Reference</b> | 0.159                 | 0.241                 | 0.077                 | 0.0291                 | 0.0008                 |
| <b>117 - Outlet Plenum</b>  | 22.517                | 22.565                | 22.449                | 0.0292                 | 0.0009                 |
| <b>118 - Inlet Plenum</b>   | 19.167                | 19.527                | 18.188                | 0.2969                 | 0.0882                 |
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>400</b>                  | 18.676                | 18.829                | 18.556                | 0.0638                 | 0.0041                 |
| <b>401</b>                  | 23.219                | 23.246                | 23.188                | 0.0103                 | 0.0001                 |
| <b>402</b>                  | 23.007                | 23.030                | 22.988                | 0.0102                 | 0.0001                 |
| <b>403</b>                  | 26.230                | 26.267                | 26.187                | 0.0187                 | 0.0004                 |
| <b>404</b>                  | 26.976                | 27.016                | 26.944                | 0.0155                 | 0.0002                 |
| <b>405</b>                  | 29.362                | 29.433                | 29.290                | 0.0241                 | 0.0006                 |
| <b>406</b>                  | 25.073                | 25.108                | 25.008                | 0.0174                 | 0.0003                 |
| <b>407</b>                  | 26.649                | 26.688                | 26.616                | 0.0130                 | 0.0002                 |
| <b>408</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>409</b>                  | 27.862                | 27.896                | 27.835                | 0.0108                 | 0.0001                 |
| <b>410</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>411</b>                  | 23.677                | 23.702                | 23.645                | 0.0120                 | 0.0001                 |
| <b>412</b>                  | 23.874                | 23.913                | 23.823                | 0.0122                 | 0.0001                 |

Figure 35. 150 Watts Heat Input at 10% Flow Rate

|                                    |            |             |            |        |        |
|------------------------------------|------------|-------------|------------|--------|--------|
| <b>413</b>                         | 23.760     | 23.803      | 23.698     | 0.0159 | 0.0003 |
| <b>414 - Bath Temp</b>             | 18.775     | 19.434      | 17.622     | 0.4124 | 0.1701 |
| <b>415 - Replaced 410</b>          | 26.520     | 26.610      | 26.432     | 0.0443 | 0.0020 |
| <b>416 - Zero Reference</b>        | 0.061      | 0.274       | -0.101     | 0.0549 | 0.0030 |
| <b>417 - Top of Plate</b>          | 23.377     | 23.478      | 23.321     | 0.0307 | 0.0009 |
| <b>418 - Ambient Air</b>           | 16.990     | 17.088      | 16.927     | 0.0464 | 0.0022 |
| <b>419 - Bottom Insulation</b>     | 29.973     | 30.002      | 29.919     | 0.0190 | 0.0004 |
|                                    |            |             |            |        |        |
| <b>421 - Side Insulation</b>       | 18.527     | 18.750      | 18.330     | 0.1009 | 0.0102 |
| <b>422 - Plate Top (over 417)</b>  | 17.168     | 17.254      | 17.086     | 0.0500 | 0.0025 |
| <b>423 - Side of Plate</b>         | 22.006     | 22.178      | 21.748     | 0.1086 | 0.0118 |
|                                    |            |             |            |        |        |
| <b>V1 - Flow Meter Vdc</b>         | 0.558      | 0.567       | 0.550      | 0.0039 | 0.0000 |
| <b>V2 - Precision Resistor Vdc</b> | 0.364      | 0.364       | 0.363      | 0.0004 | 0.0000 |
| <b>V3 - Heater Terminals Vdc</b>   | 40.657     | 40.657      | 40.657     | 0.0001 | 0.0000 |
|                                    |            |             |            |        |        |
| <b>Bath Temp (C)</b>               | 22.100     |             |            |        |        |
| <b>Sampling Time</b>               | 0.166      | 0.175       | 0.158      | 0.0039 | 0.0000 |
| <b>Power (watts)</b>               | 146.353    | 146.589     | 145.951    | 0.1512 | 0.0229 |
| <b>Flow Rate (mL/sec)</b>          | 27.604     | 29.099      | 26.290     |        |        |
|                                    | Plate Mean | Temperature |            |        |        |
| <b>Centerline Mean Temp</b>        | 25.979     |             |            |        |        |
| <b>Standard Deviation</b>          | 2.396      |             | Delta Temp | 3.8793 |        |
| <b>Variance</b>                    | 5.742      |             |            |        |        |
| <b>Centerline Maximum Temp</b>     | 31.581     | 31.616      | 31.536     | 0.0624 | 0.0039 |
| <b>Centerline Minimum Temp</b>     | 23.150     | 23.209      | 23.081     | 0.0137 | 0.0002 |
| <b>Centerline Delta Temp</b>       | 8.432      | 8.407       | 8.455      | 0.0487 | 0.0037 |

Figure 35. 150 Watts Heat Input at 10% Flow Rate

| <b>Pump Setting</b>  | <b>20</b>             |                       |                       |                        |                        |
|----------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>T.C.</u></b>   | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| 100                  | 23.150                | 23.191                | 23.117                | 0.0160                 | 0.0003                 |
| 101                  | 24.348                | 24.377                | 24.322                | 0.0115                 | 0.0001                 |
| 102                  | 24.497                | 24.565                | 24.470                | 0.0167                 | 0.0003                 |
| 103                  | 30.520                | 30.561                | 30.479                | 0.0183                 | 0.0003                 |
| 104                  | 24.741                | 24.889                | 24.679                | 0.0446                 | 0.0020                 |
| 105                  | 22.919                | 22.979                | 22.857                | 0.0326                 | 0.0011                 |
| 106                  | 25.335                | 25.356                | 25.304                | 0.0116                 | 0.0001                 |
| 107                  | 24.796                | 24.819                | 24.771                | 0.0115                 | 0.0001                 |
| 108                  | 24.745                | 24.775                | 24.657                | 0.0185                 | 0.0003                 |
| 109                  | 25.962                | 26.008                | 25.929                | 0.0133                 | 0.0002                 |
| 110                  | 25.254                | 25.279                | 25.231                | 0.0131                 | 0.0002                 |
| 111                  | 28.670                | 28.698                | 28.633                | 0.0135                 | 0.0002                 |
| 112                  | 31.666                | 31.688                | 31.639                | 0.0132                 | 0.0002                 |
| 113                  | 25.669                | 25.745                | 25.637                | 0.0244                 | 0.0006                 |
| 114                  | 24.751                | 24.791                | 24.721                | 0.0139                 | 0.0002                 |
| 115-Inlet Pipe       | 22.729                | 22.762                | 22.705                | 0.0127                 | 0.0002                 |
| 116 - Zero Reference | 0.125                 | 0.183                 | 0.071                 | 0.0251                 | 0.0006                 |
| 117 - Outlet Plenum  | 22.473                | 22.520                | 22.428                | 0.0188                 | 0.0004                 |
| 118 - Inlet Plenum   | 18.972                | 19.049                | 18.780                | 0.0565                 | 0.0032                 |
| <b><u>T.C.</u></b>   | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| 400                  | 18.452                | 18.717                | 18.335                | 0.0739                 | 0.0055                 |
| 401                  | 23.271                | 23.326                | 23.226                | 0.0218                 | 0.0005                 |
| 402                  | 23.029                | 23.057                | 23.009                | 0.0101                 | 0.0001                 |
| 403                  | 26.171                | 26.209                | 26.149                | 0.0103                 | 0.0001                 |
| 404                  | 26.980                | 27.009                | 26.955                | 0.0107                 | 0.0001                 |
| 405                  | 29.332                | 29.355                | 29.297                | 0.0121                 | 0.0001                 |
| 406                  | 25.108                | 25.139                | 25.076                | 0.0114                 | 0.0001                 |
| 407                  | 26.716                | 26.755                | 26.688                | 0.0128                 | 0.0002                 |
| 408                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| 409                  | 27.903                | 27.934                | 27.867                | 0.0134                 | 0.0002                 |
| 410                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| 411                  | 23.730                | 23.883                | 23.683                | 0.0295                 | 0.0009                 |
| 412                  | 23.923                | 23.948                | 23.875                | 0.0137                 | 0.0002                 |

Figure 36. 150 Watts Heat Input at 20% Flow Rate

|                                    |                        |          |            |        |        |
|------------------------------------|------------------------|----------|------------|--------|--------|
| <b>413</b>                         | 23.801                 | 23.844   | 23.763     | 0.0159 | 0.0003 |
| <b>414 - Bath Temp</b>             | 18.822                 | 19.458   | 17.848     | 0.3641 | 0.1326 |
| <b>415 - Replaced 410</b>          | 26.520                 | 26.556   | 26.479     | 0.0157 | 0.0002 |
| <b>416 - Zero Reference</b>        | 0.010                  | 0.110    | -0.165     | 0.0687 | 0.0047 |
| <b>417 - Top of Plate</b>          | 23.466                 | 23.559   | 23.381     | 0.0394 | 0.0016 |
| <b>418 - Ambient Air</b>           | 16.773                 | 16.848   | 16.714     | 0.0335 | 0.0011 |
| <b>419 - Bottom Insulation</b>     | 29.959                 | 29.985   | 29.934     | 0.0113 | 0.0001 |
|                                    |                        |          |            |        |        |
| <b>421 - Side Insulation</b>       | 18.678                 | 18.876   | 18.493     | 0.1079 | 0.0116 |
| <b>422 - Plate Top (over 417)</b>  | 16.739                 | 16.810   | 16.646     | 0.0391 | 0.0015 |
| <b>423 - Side of Plate</b>         | 21.812                 | 22.054   | 21.553     | 0.1048 | 0.0110 |
|                                    |                        |          |            |        |        |
| <b>V1 - Flow Meter Vdc</b>         | 0.436                  | 0.459    | 0.418      | 0.0107 | 0.0001 |
| <b>V2 - Precision Resistor Vdc</b> | 0.363                  | 0.364    | 0.363      | 0.0003 | 0.0000 |
| <b>V3 - Heater Terminals Vdc</b>   | 40.656                 | 40.656   | 40.656     | 0.0001 | 0.0000 |
|                                    |                        |          |            |        |        |
| <b>Bath Temp (C)</b>               | 22.100                 |          |            |        |        |
| <b>Sampling Time</b>               | 0.044                  | 0.066    | 0.026      | 0.0107 | 0.0001 |
| <b>Power (watts)</b>               | 146.158                | 146.466  | 145.938    | 0.1258 | 0.0158 |
| <b>Flow Rate (mL/sec)</b>          | 7.271677               | 11.041   | 4.25906    |        |        |
|                                    | Plate Mean Temperature |          |            |        |        |
| <b>Centerline Mean Temp</b>        | 25.991                 |          |            |        |        |
| <b>Standard Deviation</b>          | 2.412                  |          | Delta Temp | 3.8909 |        |
| <b>Variance</b>                    | 5.816                  |          |            |        |        |
| <b>Centerline Maximum Temp</b>     | 31.66576               | 31.68848 | 31.63867   | 0.0446 | 0.0020 |
| <b>Centerline Minimum Temp</b>     | 22.72873               | 22.76172 | 22.70508   | 0.0115 | 0.0001 |
| <b>Centerline Delta Temp</b>       | 8.937034               | 8.92676  | 8.93359    | 0.0331 | 0.0019 |

Figure 36. 150 Watts Heat Input at 20% Flow Rate

| <b>Pump Setting</b>         | <b>0</b>              |                       |                       |                        |                        |
|-----------------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>100</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>101</b>                  | 33.291                | 33.850                | 33.224                | 0.0741                 | 0.0055                 |
| <b>102</b>                  | 32.980                | 33.084                | 32.644                | 0.0572                 | 0.0033                 |
| <b>103</b>                  | 37.292                | 37.349                | 37.126                | 0.0349                 | 0.0012                 |
| <b>104</b>                  | 33.521                | 33.606                | 33.439                | 0.0340                 | 0.0012                 |
| <b>105</b>                  | 32.899                | 32.995                | 32.784                | 0.0335                 | 0.0011                 |
| <b>106</b>                  | 33.745                | 33.830                | 33.679                | 0.0310                 | 0.0010                 |
| <b>107</b>                  | 33.320                | 33.452                | 33.252                | 0.0335                 | 0.0011                 |
| <b>108</b>                  | 33.482                | 33.635                | 33.379                | 0.0450                 | 0.0020                 |
| <b>109</b>                  | 34.098                | 34.193                | 33.950                | 0.0361                 | 0.0013                 |
| <b>110</b>                  | 33.677                | 33.750                | 33.525                | 0.0385                 | 0.0015                 |
| <b>111</b>                  | 40.537                | 40.604                | 40.351                | 0.0376                 | 0.0014                 |
| <b>112</b>                  | 39.887                | 39.962                | 39.807                | 0.0328                 | 0.0011                 |
| <b>113</b>                  | 34.421                | 36.041                | 34.278                | 0.2163                 | 0.0468                 |
| <b>114</b>                  | 31.718                | 31.873                | 31.398                | 0.0573                 | 0.0033                 |
| <b>115-Inlet Pipe</b>       | 31.821                | 31.978                | 31.694                | 0.0513                 | 0.0026                 |
| <b>116 - Zero Reference</b> | -0.068                | 0.125                 | -0.159                | 0.0465                 | 0.0022                 |
| <b>117 - Outlet Plenum</b>  | 32.132                | 32.182                | 32.068                | 0.0202                 | 0.0004                 |
| <b>118 - Inlet Plenum</b>   | 18.761                | 19.359                | 17.330                | 0.3906                 | 0.1525                 |
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>400</b>                  | 19.457                | 19.622                | 19.366                | 0.0509                 | 0.0026                 |
| <b>401</b>                  | 32.461                | 32.604                | 32.376                | 0.0429                 | 0.0018                 |
| <b>402</b>                  | 32.092                | 32.132                | 32.060                | 0.0142                 | 0.0002                 |
| <b>403</b>                  | 33.817                | 33.921                | 33.740                | 0.0292                 | 0.0009                 |
| <b>404</b>                  | 34.608                | 34.699                | 34.465                | 0.0345                 | 0.0012                 |
| <b>405</b>                  | 35.772                | 35.874                | 35.661                | 0.0472                 | 0.0022                 |
| <b>406</b>                  | 33.341                | 33.471                | 33.240                | 0.0415                 | 0.0017                 |
| <b>407</b>                  | 34.521                | 34.684                | 34.419                | 0.0418                 | 0.0018                 |
| <b>408</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>409</b>                  | 34.641                | 34.709                | 34.530                | 0.0324                 | 0.0011                 |
| <b>410</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>411</b>                  | 32.403                | 32.507                | 32.252                | 0.0535                 | 0.0029                 |
| <b>412</b>                  | 32.378                | 32.445                | 32.296                | 0.0358                 | 0.0013                 |

Figure 37. 210 Watts Heat Input at 0% Flow Rate



|                             |            |             |            |        |        |
|-----------------------------|------------|-------------|------------|--------|--------|
| 413                         | 32.415     | 32.466      | 32.348     | 0.0316 | 0.0010 |
| 414 - Bath Temp             | 19.711     | 20.490      | 18.434     | 0.4190 | 0.1756 |
| 415 - Replaced 410          | 35.696     | 35.935      | 35.486     | 0.1308 | 0.0171 |
| 416 - Zero Reference        | -0.019     | 0.407       | -0.301     | 0.1035 | 0.0107 |
| 417 - Top of Plate          | 32.441     | 32.550      | 32.296     | 0.0474 | 0.0022 |
| 418 - Ambient Air           | 16.976     | 17.066      | 16.850     | 0.0421 | 0.0018 |
| 419 - Bottom Insulation     | 35.156     | 35.264      | 35.013     | 0.0489 | 0.0024 |
|                             | N/A        | N/A         | N/A        | N/A    | N/A    |
| 421 - Side Insulation       | 18.686     | 18.786      | 18.629     | 0.0309 | 0.0010 |
| 422 - Plate Top (over 417)  | 18.142     | 18.239      | 18.063     | 0.0412 | 0.0017 |
| 423 - Side of Plate         | 29.625     | 29.773      | 29.496     | 0.0654 | 0.0043 |
|                             |            |             |            |        |        |
| V1 - Flow Meter Vdc         | 0.392      | 0.403       | 0.391      | 0.0015 | 0.0000 |
| V2 - Precision Resistor Vdc | 31.853     | 31.853      | 31.853     | 0.0001 | 0.0000 |
| V3 - Heater Terminals Vdc   | 68.077     | 68.077      | 68.076     | 0.0002 | 0.0000 |
|                             |            |             |            |        |        |
| Bath Temp (C)               | 32.2       |             |            |        |        |
| Sampling Time               | 0.000      | 0.011       | 0.000      | 0.0014 | 0.0000 |
| Power (watts)               | 210.529    | 210.531     | 210.526    | 0.0011 | 0.0000 |
| Flow Rate (mL/sec)          | -0.08185   | 1.828539    | -0.13887   |        |        |
|                             | Plate Mean | Temperature |            |        |        |
| Centerline Mean Temp        | 34.633     |             |            |        |        |
| Standard Deviation          | 2.562      |             | Delta Temp | 2.4335 |        |
| Variance                    | 6.563      |             |            |        |        |
| Centerline Maximum Temp     | 40.537     | 40.604      | 40.351     | 0.2163 | 0.0468 |
| Centerline Minimum Temp     | 31.718     | 31.873      | 31.398     | 0.0310 | 0.0010 |
| Centerline Delta Temp       | 8.819      | 8.731       | 8.952      | 0.1853 | 0.0458 |

Figure 37. 210 Watts Heat Input at 0% Flow Rate

| <b>Pump Setting</b>         | <b>15</b>             |                       | <b>Run One</b>        |                        |                        |
|-----------------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>100</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>101</b>                  | 30.422                | 30.773                | 29.979                | 0.2158                 | 0.0466                 |
| <b>102</b>                  | 33.061                | 33.125                | 33.000                | 0.0242                 | 0.0006                 |
| <b>103</b>                  | 36.486                | 37.887                | 36.014                | 0.6340                 | 0.4019                 |
| <b>104</b>                  | 33.366                | 33.501                | 33.133                | 0.0779                 | 0.0061                 |
| <b>105</b>                  | 32.888                | 32.989                | 32.737                | 0.0422                 | 0.0018                 |
| <b>106</b>                  | 33.509                | 33.716                | 32.813                | 0.1810                 | 0.0328                 |
| <b>107</b>                  | 33.480                | 33.629                | 33.324                | 0.0946                 | 0.0089                 |
| <b>108</b>                  | 33.496                | 33.622                | 33.419                | 0.0482                 | 0.0023                 |
| <b>109</b>                  | 34.198                | 34.310                | 34.092                | 0.0559                 | 0.0031                 |
| <b>110</b>                  | 33.555                | 33.733                | 33.436                | 0.0775                 | 0.0060                 |
| <b>111</b>                  | 39.833                | 40.063                | 39.748                | 0.0763                 | 0.0058                 |
| <b>112</b>                  | 35.831                | 36.691                | 35.667                | 0.2411                 | 0.0581                 |
| <b>113</b>                  | 34.137                | 34.200                | 34.053                | 0.0383                 | 0.0015                 |
| <b>114</b>                  | 33.221                | 33.329                | 33.167                | 0.0290                 | 0.0008                 |
| <b>115-Inlet Pipe</b>       | 32.240                | 32.287                | 32.201                | 0.0196                 | 0.0004                 |
| <b>116 - Zero Reference</b> | 0.026                 | 0.047                 | 0.005                 | 0.0089                 | 0.0001                 |
| <b>117 - Outlet Plenum</b>  | 32.256                | 32.295                | 32.209                | 0.0238                 | 0.0006                 |
| <b>118 - Inlet Plenum</b>   | 18.961                | 19.945                | 17.523                | 0.5167                 | 0.2670                 |
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>400</b>                  | 32.324                | 32.351                | 32.303                | 0.0114                 | 0.0001                 |
| <b>401</b>                  | 32.877                | 32.943                | 32.673                | 0.0424                 | 0.0018                 |
| <b>402</b>                  | 32.324                | 32.359                | 32.257                | 0.0235                 | 0.0006                 |
| <b>403</b>                  | 34.032                | 34.307                | 33.936                | 0.0880                 | 0.0078                 |
| <b>404</b>                  | 34.842                | 35.059                | 34.739                | 0.0960                 | 0.0092                 |
| <b>405</b>                  | 37.046                | 37.171                | 36.971                | 0.0530                 | 0.0028                 |
| <b>406</b>                  | 34.023                | 34.091                | 33.957                | 0.0373                 | 0.0014                 |
| <b>407</b>                  | 35.017                | 35.240                | 34.674                | 0.1402                 | 0.0196                 |
| <b>408</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>409</b>                  | 35.144                | 35.261                | 35.047                | 0.0580                 | 0.0034                 |
| <b>410</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>411</b>                  | 32.615                | 32.644                | 32.587                | 0.0160                 | 0.0003                 |
| <b>412</b>                  | 32.535                | 32.569                | 32.493                | 0.0219                 | 0.0005                 |

Figure 38. 210 Watts Heat Input at 15% Flow Rate

|                                    |                        |         |            |        |        |
|------------------------------------|------------------------|---------|------------|--------|--------|
| <b>413</b>                         | 32.588                 | 32.625  | 32.540     | 0.0222 | 0.0005 |
| <b>414 - Bath Temp</b>             | 19.597                 | 20.279  | 18.966     | 0.2929 | 0.0858 |
| <b>415 - Replaced 410</b>          | 35.802                 | 36.018  | 35.712     | 0.0677 | 0.0046 |
| <b>416 - Zero Reference</b>        | 0.073                  | 0.209   | -0.108     | 0.0761 | 0.0058 |
| <b>417 - Top of Plate</b>          | 32.403                 | 32.647  | 32.249     | 0.0930 | 0.0087 |
| <b>418 - Ambient Air</b>           | 17.341                 | 17.448  | 17.275     | 0.0492 | 0.0024 |
| <b>419 - Bottom Insulation</b>     | 33.499                 | 35.630  | 32.068     | 0.8786 | 0.7720 |
|                                    |                        |         |            |        |        |
| <b>421 - Side Insulation</b>       | 18.927                 | 19.046  | 18.815     | 0.0726 | 0.0053 |
| <b>422 - Plate Top (over 417)</b>  | 16.959                 | 17.008  | 16.914     | 0.0216 | 0.0005 |
| <b>423 - Side of Plate</b>         | 25.322                 | 25.813  | 25.103     | 0.1683 | 0.0283 |
|                                    |                        |         |            |        |        |
| <b>V1 - Flow Meter Vdc</b>         | 0.539                  | 0.569   | 0.490      | 0.0326 | 0.0011 |
| <b>V2 - Precision Resistor Vdc</b> | 31.853                 | 31.854  | 31.852     | 0.0004 | 0.0000 |
| <b>V3 - Heater Terminals Vdc</b>   | 68.084                 | 68.084  | 68.084     | 0.0001 | 0.0000 |
|                                    |                        |         |            |        |        |
| <b>Bath Temp (C)</b>               | 32.2                   |         |            |        |        |
| <b>Sampling Time</b>               | 0.147                  | 0.177   | 0.098      | 0.0326 | 0.0011 |
| <b>Power (watts)</b>               | 214.723                | 214.727 | 214.717    | 0.0026 | 0.0000 |
| <b>Flow Rate (mL/sec)</b>          | 24.423                 | 29.377  | 16.204     |        |        |
|                                    | Plate Mean Temperature |         |            |        |        |
| <b>Centerline Mean Temp</b>        | 34.106                 |         |            |        |        |
| <b>Standard Deviation</b>          | 2.076                  |         | Delta Temp | 1.9060 |        |
| <b>Variance</b>                    | 4.311                  |         |            |        |        |
| <b>Centerline Maximum Temp</b>     | 39.833                 | 40.063  | 39.748     | 0.6340 | 0.4019 |
| <b>Centerline Minimum Temp</b>     | 30.422                 | 30.773  | 29.979     | 0.0242 | 0.0006 |
| <b>Centerline Delta Temp</b>       | 9.412                  | 9.289   | 9.769      | 0.6098 | 0.4013 |

Figure 38. 210 Watts Heat Input at 15% Flow Rate

| <b>Pump Setting</b>         | <b>15</b>             |                       | <b>Run Two</b>        |                        |                        |
|-----------------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>100</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>101</b>                  | 31.791                | 33.015                | 30.069                | 1.1683                 | 1.3649                 |
| <b>102</b>                  | 33.143                | 33.207                | 33.084                | 0.0245                 | 0.0006                 |
| <b>103</b>                  | 36.298                | 36.834                | 36.108                | 0.1880                 | 0.0353                 |
| <b>104</b>                  | 33.414                | 33.455                | 33.257                | 0.0264                 | 0.0007                 |
| <b>105</b>                  | 32.937                | 33.094                | 32.476                | 0.0857                 | 0.0073                 |
| <b>106</b>                  | 33.435                | 33.655                | 33.158                | 0.1185                 | 0.0140                 |
| <b>107</b>                  | 33.530                | 33.650                | 33.413                | 0.0447                 | 0.0020                 |
| <b>108</b>                  | 33.576                | 33.624                | 33.497                | 0.0196                 | 0.0004                 |
| <b>109</b>                  | 34.298                | 34.350                | 34.226                | 0.0261                 | 0.0007                 |
| <b>110</b>                  | 33.726                | 33.850                | 33.574                | 0.0732                 | 0.0054                 |
| <b>111</b>                  | 39.786                | 39.873                | 39.751                | 0.0214                 | 0.0005                 |
| <b>112</b>                  | 35.164                | 35.284                | 35.109                | 0.0305                 | 0.0009                 |
| <b>113</b>                  | 34.393                | 34.471                | 34.296                | 0.0328                 | 0.0011                 |
| <b>114</b>                  | 33.431                | 33.659                | 33.321                | 0.0858                 | 0.0074                 |
| <b>115-Inlet Pipe</b>       | 32.323                | 32.363                | 32.237                | 0.0209                 | 0.0004                 |
| <b>116 - Zero Reference</b> | 0.125                 | 0.194                 | -0.213                | 0.0527                 | 0.0028                 |
| <b>117 - Outlet Plenum</b>  | 32.316                | 32.408                | 32.261                | 0.0288                 | 0.0008                 |
| <b>118 - Inlet Plenum</b>   | 18.917                | 20.193                | 17.357                | 0.6689                 | 0.4474                 |
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>400</b>                  | 22.125                | 32.553                | 18.891                | 5.4980                 | 30.2276                |
| <b>401</b>                  | 33.029                | 33.684                | 32.736                | 0.2420                 | 0.0586                 |
| <b>402</b>                  | 32.377                | 32.419                | 32.324                | 0.0225                 | 0.0005                 |
| <b>403</b>                  | 34.033                | 34.079                | 33.975                | 0.0193                 | 0.0004                 |
| <b>404</b>                  | 34.846                | 34.920                | 34.750                | 0.0421                 | 0.0018                 |
| <b>405</b>                  | 36.468                | 36.929                | 35.859                | 0.3648                 | 0.1330                 |
| <b>406</b>                  | 34.004                | 34.076                | 33.913                | 0.0409                 | 0.0017                 |
| <b>407</b>                  | 34.972                | 35.152                | 34.732                | 0.0854                 | 0.0073                 |
| <b>408</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>409</b>                  | 34.761                | 34.908                | 34.571                | 0.0784                 | 0.0062                 |
| <b>410</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>411</b>                  | 32.654                | 32.761                | 32.531                | 0.0289                 | 0.0008                 |
| <b>412</b>                  | 32.556                | 32.590                | 32.437                | 0.0187                 | 0.0004                 |

Figure 39. 210 Watts Heat Input at 15% Flow Rate

|                                    |                        |          |            |        |         |
|------------------------------------|------------------------|----------|------------|--------|---------|
| <b>413</b>                         | 32.597                 | 32.640   | 32.549     | 0.0143 | 0.0002  |
| <b>414 - Bath Temp</b>             | 20.092                 | 20.649   | 19.342     | 0.2973 | 0.0884  |
| <b>415 - Replaced 410</b>          | 35.798                 | 36.080   | 35.439     | 0.1163 | 0.0135  |
| <b>416 - Zero Reference</b>        | 0.105                  | 0.356    | -0.176     | 0.1090 | 0.0119  |
| <b>417 - Top of Plate</b>          | 32.423                 | 32.630   | 32.341     | 0.0461 | 0.0021  |
| <b>418 - Ambient Air</b>           | 19.576                 | 31.989   | 17.184     | 5.1134 | 26.1465 |
| <b>419 - Bottom Insulation</b>     | 32.758                 | 32.981   | 32.459     | 0.1094 | 0.0120  |
|                                    |                        |          |            |        |         |
| <b>421 - Side Insulation</b>       | 20.069                 | 20.631   | 19.166     | 0.4539 | 0.2061  |
| <b>422 - Plate Top (over 417)</b>  | 17.863                 | 18.384   | 17.312     | 0.3611 | 0.1304  |
| <b>423 - Side of Plate</b>         | 26.141                 | 26.616   | 25.646     | 0.2219 | 0.0493  |
|                                    |                        |          |            |        |         |
| <b>V1 - Flow Meter Vdc</b>         | 0.520                  | 0.548    | 0.490      | 0.0142 | 0.0002  |
| <b>V2 - Precision Resistor Vdc</b> | 31.854                 | 31.856   | 31.850     | 0.0011 | 0.0000  |
| <b>V3 - Heater Terminals Vdc</b>   | 68.084                 | 68.085   | 68.084     | 0.0001 | 0.0000  |
|                                    |                        |          |            |        |         |
| <b>Bath Temp (C)</b>               | 32.8                   |          |            |        |         |
| <b>Sampling Time</b>               | 0.128                  | 0.156    | 0.098      | 0.0142 | 0.0002  |
| <b>Power (watts)</b>               | 210.560                | 210.570  | 210.535    | 0.0071 | 0.0000  |
| <b>Flow Rate (mL/sec)</b>          | 21.30649               | 25.92346 | 16.3037    |        |         |
|                                    | Plate Mean Temperature |          |            |        |         |
| <b>Centerline Mean Temp</b>        | 34.209                 |          |            |        |         |
| <b>Standard Deviation</b>          | 1.851                  |          | Delta Temp | 1.4087 |         |
| <b>Variance</b>                    | 3.425                  |          |            |        |         |
| <b>Centerline Maximum Temp</b>     | 39.786                 | 39.873   | 39.751     | 1.1683 | 1.3649  |
| <b>Centerline Minimum Temp</b>     | 31.791                 | 33.015   | 30.069     | 0.0196 | 0.0004  |
| <b>Centerline Delta Temp</b>       | 7.995                  | 6.858    | 9.682      | 1.1487 | 1.3645  |

Figure 39. 210 Watts Heat Input at 15% Flow Rate

| <b>Pump Setting</b>         | <b>15</b>      |                | <b>Run Three</b> |                 |                 |
|-----------------------------|----------------|----------------|------------------|-----------------|-----------------|
| <b>T.C.</b>                 | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b>   | <b>Std Dev.</b> | <b>Variance</b> |
| <b>100</b>                  | N/A            | N/A            | N/A              | N/A             | N/A             |
| <b>101</b>                  | 33.560         | 33.614         | 33.484           | 0.0243          | 0.0005          |
| <b>102</b>                  | 33.159         | 33.228         | 32.962           | 0.0359          | 0.0013          |
| <b>103</b>                  | 38.867         | 39.179         | 38.777           | 0.0475          | 0.0023          |
| <b>104</b>                  | 33.496         | 33.546         | 33.414           | 0.0227          | 0.0005          |
| <b>105</b>                  | 33.105         | 33.189         | 32.980           | 0.0308          | 0.0010          |
| <b>106</b>                  | 33.614         | 34.020         | 33.203           | 0.1050          | 0.0110          |
| <b>107</b>                  | 33.533         | 33.660         | 33.292           | 0.0471          | 0.0022          |
| <b>108</b>                  | 33.692         | 33.734         | 33.519           | 0.0295          | 0.0009          |
| <b>109</b>                  | 34.210         | 34.467         | 34.056           | 0.0459          | 0.0021          |
| <b>110</b>                  | 33.750         | 33.867         | 33.651           | 0.0315          | 0.0010          |
| <b>111</b>                  | 40.616         | 40.695         | 40.235           | 0.0546          | 0.0030          |
| <b>112</b>                  | 39.886         | 39.998         | 39.829           | 0.0264          | 0.0007          |
| <b>113</b>                  | 34.406         | 34.689         | 34.328           | 0.0448          | 0.0020          |
| <b>114</b>                  | 31.981         | 32.031         | 31.827           | 0.0357          | 0.0013          |
| <b>115-Inlet Pipe</b>       | 32.291         | 32.347         | 32.162           | 0.0284          | 0.0008          |
| <b>116 - Zero Reference</b> | 0.129          | 0.172          | 0.079            | 0.0179          | 0.0003          |
| <b>117 - Outlet Plenum</b>  | 32.336         | 32.390         | 32.298           | 0.0176          | 0.0003          |
| <b>118 - Inlet Plenum</b>   | 19.472         | 19.831         | 18.660           | 0.2611          | 0.0682          |
| <b>T.C.</b>                 | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b>   | <b>Std Dev.</b> | <b>Variance</b> |
| <b>400</b>                  | 19.112         | 19.483         | 18.958           | 0.1233          | 0.0152          |
| <b>401</b>                  | 33.069         | 33.155         | 32.910           | 0.0393          | 0.0015          |
| <b>402</b>                  | 32.424         | 32.456         | 32.255           | 0.0268          | 0.0007          |
| <b>403</b>                  | 34.405         | 35.140         | 34.330           | 0.0970          | 0.0094          |
| <b>404</b>                  | 35.033         | 35.176         | 34.903           | 0.0330          | 0.0011          |
| <b>405</b>                  | 37.055         | 37.134         | 36.999           | 0.0265          | 0.0007          |
| <b>406</b>                  | 34.047         | 34.101         | 33.257           | 0.1046          | 0.0109          |
| <b>407</b>                  | 34.930         | 35.014         | 34.874           | 0.0215          | 0.0005          |
| <b>408</b>                  | N/A            | N/A            | N/A              | N/A             | N/A             |
| <b>409</b>                  | 35.215         | 35.277         | 35.143           | 0.0245          | 0.0006          |
| <b>410</b>                  | N/A            | N/A            | N/A              | N/A             | N/A             |
| <b>411</b>                  | 32.432         | 32.595         | 32.364           | 0.0386          | 0.0015          |
| <b>412</b>                  | 32.515         | 32.564         | 32.450           | 0.0242          | 0.0006          |

Figure 40. 210 Watts Heat Input at 15% Flow Rate

|                             |            |             |            |        |        |
|-----------------------------|------------|-------------|------------|--------|--------|
| 413                         | 32.546     | 32.585      | 32.491     | 0.0203 | 0.0004 |
| 414 - Bath Temp             | 20.640     | 21.119      | 19.927     | 0.2901 | 0.0842 |
| 415 - Replaced 410          | 35.763     | 35.837      | 35.630     | 0.0415 | 0.0017 |
| 416 - Zero Reference        | 0.156      | 0.269       | -0.111     | 0.0826 | 0.0068 |
| 417 - Top of Plate          | 32.479     | 32.614      | 32.256     | 0.0426 | 0.0018 |
| 418 - Ambient Air           | 17.277     | 17.328      | 17.238     | 0.0206 | 0.0004 |
| 419 - Bottom Insulation     | 37.210     | 37.279      | 37.116     | 0.0235 | 0.0006 |
|                             |            |             |            |        |        |
| 421 - Side Insulation       | 18.541     | 18.604      | 18.463     | 0.0300 | 0.0009 |
| 422 - Plate Top (over 417)  | 18.318     | 18.516      | 18.245     | 0.0427 | 0.0018 |
| 423 - Side of Plate         | 29.124     | 29.409      | 28.938     | 0.0871 | 0.0076 |
|                             |            |             |            |        |        |
| V1 - Flow Meter Vdc         | 0.527      | 0.543       | 0.511      | 0.0063 | 0.0000 |
| V2 - Precision Resistor Vdc | 31.855     | 31.855      | 31.853     | 0.0007 | 0.0000 |
| V3 - Heater Terminals Vdc   | 68.085     | 68.085      | 68.084     | 0.0001 | 0.0000 |
|                             |            |             |            |        |        |
| Bath Temp (C)               | 32.8       |             |            |        |        |
| Sampling Time               | 0.135      | 0.151       | 0.119      | 0.0063 | 0.0000 |
| Power (watts)               | 210.564    | 210.569     | 210.555    | 0.0045 | 0.0000 |
| Flow Rate (mL/sec)          | 22.34715   | 25.10121    | 19.74101   |        |        |
|                             | Plate Mean | Temperature |            |        |        |
| Centerline Mean Temp        | 34.848     |             |            |        |        |
| Standard Deviation          | 2.656      |             | Delta Temp | 2.0482 |        |
| Variance                    | 7.057      |             |            |        |        |
| Centerline Maximum Temp     | 40.616     | 40.695      | 40.235     | 0.1050 | 0.0110 |
| Centerline Minimum Temp     | 31.981     | 32.031      | 31.827     | 0.0227 | 0.0005 |
| Centerline Delta Temp       | 8.635      | 8.664       | 8.408      | 0.0823 | 0.0105 |

Figure 40. 210 Watts Heat Input at 15% Flow Rate

| <b>Pump Setting</b>  |                |                |                |                 |                 |
|----------------------|----------------|----------------|----------------|-----------------|-----------------|
| <b>T.C.</b>          | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b> | <b>Std Dev.</b> | <b>Variance</b> |
| 100                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 101                  | 33.635         | 33.678         | 33.596         | 0.0195          | 0.0004          |
| 102                  | 33.563         | 33.603         | 33.508         | 0.0196          | 0.0004          |
| 103                  | 38.163         | 38.240         | 38.113         | 0.0291          | 0.0008          |
| 104                  | 33.569         | 33.608         | 33.530         | 0.0161          | 0.0003          |
| 105                  | 33.093         | 33.241         | 32.992         | 0.0354          | 0.0012          |
| 106                  | 33.913         | 34.026         | 33.534         | 0.1161          | 0.0135          |
| 107                  | 33.583         | 33.729         | 32.649         | 0.1410          | 0.0199          |
| 108                  | 33.676         | 33.742         | 33.593         | 0.0341          | 0.0012          |
| 109                  | 34.269         | 34.325         | 34.180         | 0.0283          | 0.0008          |
| 110                  | 33.814         | 33.864         | 33.543         | 0.0392          | 0.0015          |
| 111                  | 40.610         | 40.728         | 40.563         | 0.0281          | 0.0008          |
| 112                  | 39.828         | 39.890         | 39.789         | 0.0208          | 0.0004          |
| 113                  | 34.412         | 34.510         | 34.346         | 0.0284          | 0.0008          |
| 114                  | 31.963         | 32.038         | 31.898         | 0.0269          | 0.0007          |
| 115-Inlet Pipe       | 32.297         | 32.350         | 32.214         | 0.0236          | 0.0006          |
| 116 - Zero Reference | 0.097          | 0.127          | 0.074          | 0.0128          | 0.0002          |
| 117 - Outlet Plenum  | 32.241         | 32.278         | 32.192         | 0.0165          | 0.0003          |
| 118 - Inlet Plenum   | 18.879         | 19.694         | 18.099         | 0.4064          | 0.1652          |
| <b>T.C.</b>          | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b> | <b>Std Dev.</b> | <b>Variance</b> |
| 400                  | 19.573         | 19.607         | 19.526         | 0.0177          | 0.0003          |
| 401                  | 33.022         | 33.064         | 32.892         | 0.0277          | 0.0008          |
| 402                  | 32.450         | 32.486         | 32.415         | 0.0155          | 0.0002          |
| 403                  | 33.539         | 33.617         | 33.478         | 0.0320          | 0.0010          |
| 404                  | 35.019         | 35.066         | 34.970         | 0.0205          | 0.0004          |
| 405                  | 37.085         | 37.149         | 37.016         | 0.0208          | 0.0004          |
| 406                  | 33.684         | 33.879         | 33.233         | 0.1848          | 0.0342          |
| 407                  | 34.848         | 35.005         | 34.736         | 0.0769          | 0.0059          |
| 408                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 409                  | 35.200         | 35.254         | 35.140         | 0.0258          | 0.0007          |
| 410                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 411                  | 32.637         | 32.675         | 32.466         | 0.0330          | 0.0011          |
| 412                  | 32.573         | 32.623         | 32.544         | 0.0148          | 0.0002          |

Figure 41. 210 Watts Heat Input at 20% Flow Rate



|                             |            |             |            |         |        |
|-----------------------------|------------|-------------|------------|---------|--------|
| 413                         | 32.595     | 32.617      | 32.562     | 0.0126  | 0.0002 |
| 414 - Bath Temp             | 20.436     | 21.208      | 19.278     | 0.3483  | 0.1213 |
| 415 - Replaced 410          | 35.925     | 36.013      | 35.865     | 0.0276  | 0.0008 |
| 416 - Zero Reference        | 0.061      | 0.225       | -0.179     | 0.0823  | 0.0068 |
| 417 - Top of Plate          | 32.357     | 32.424      | 32.277     | 0.0291  | 0.0008 |
| 418 - Ambient Air           | 17.324     | 17.412      | 17.228     | 0.0467  | 0.0022 |
| 419 - Bottom Insulation     | 37.087     | 37.208      | 37.039     | 0.0343  | 0.0012 |
|                             |            |             |            |         |        |
| 421 - Side Insulation       | 18.620     | 18.719      | 18.530     | 0.0494  | 0.0024 |
| 422 - Plate Top (over 417)  | 18.857     | 18.962      | 18.306     | 0.0766  | 0.0059 |
| 423 - Side of Plate         | 29.609     | 30.295      | 29.120     | 0.4297  | 0.1846 |
|                             |            |             |            |         |        |
| V1 - Flow Meter Vdc         | 0.528      | 0.546       | 0.520      | 0.0053  | 0.0000 |
| V2 - Precision Resistor Vdc | 31.855     | 31.855      | 31.854     | 0.0002  | 0.0000 |
| V3 - Heater Terminals Vdc   | 68.084     | 68.084      | 68.084     | 0.0001  | 0.0000 |
|                             |            |             |            |         |        |
| Bath Temp (C)               | 22.1       |             |            |         |        |
| Sampling Time               | N/A        |             |            |         |        |
| Power (watts)               | 210.563    | 210.566     | 210.559    | 0.0014  | 0.0000 |
| Flow Rate (mL/sec)          | 22.56937   | 25.60486    | 21.15394   |         |        |
|                             | Plate Mean | Temperature |            |         |        |
| Centerline Mean Temp        | 34.864     |             |            |         |        |
| Standard Deviation          | 2.544      |             | Delta Temp | 12.7636 |        |
| Variance                    | 6.471      |             |            |         |        |
| Centerline Maximum Temp     | 40.610     | 40.728      | 40.563     | 0.1410  | 0.0199 |
| Centerline Minimum Temp     | 31.963     | 32.038      | 31.898     | 0.0161  | 0.0003 |
| Centerline Delta Temp       | 8.647      | 8.689       | 8.665      | 0.1249  | 0.0196 |

Figure 41. 210 Watts Heat Input at 20% Flow Rate

| Pump Setting         | 25      |         |         |          |          |
|----------------------|---------|---------|---------|----------|----------|
| T.C.                 | Average | Maximum | Minimum | Std Dev. | Variance |
| 100                  | N/A     | N/A     | N/A     | N/A      | N/A      |
| 101                  | 33.563  | 33.644  | 33.374  | 0.0448   | 0.0020   |
| 102                  | 33.531  | 33.762  | 33.429  | 0.0416   | 0.0017   |
| 103                  | 38.101  | 38.165  | 37.956  | 0.0525   | 0.0028   |
| 104                  | 33.705  | 33.811  | 33.411  | 0.0979   | 0.0096   |
| 105                  | 33.517  | 33.693  | 33.245  | 0.1314   | 0.0173   |
| 106                  | 33.717  | 33.941  | 33.342  | 0.1471   | 0.0216   |
| 107                  | 33.373  | 33.497  | 33.298  | 0.0371   | 0.0014   |
| 108                  | 33.576  | 33.645  | 33.490  | 0.0348   | 0.0012   |
| 109                  | 34.241  | 34.310  | 34.194  | 0.0245   | 0.0006   |
| 110                  | 33.783  | 33.819  | 33.736  | 0.0190   | 0.0004   |
| 111                  | 40.548  | 40.629  | 40.485  | 0.0255   | 0.0006   |
| 112                  | 39.777  | 39.903  | 39.722  | 0.0264   | 0.0007   |
| 113                  | 34.445  | 34.518  | 34.351  | 0.0273   | 0.0007   |
| 114                  | 31.890  | 31.941  | 31.818  | 0.0285   | 0.0008   |
| 115-Inlet Pipe       | 32.194  | 32.276  | 32.001  | 0.0668   | 0.0045   |
| 116 - Zero Reference | -0.027  | 0.013   | -0.061  | 0.0163   | 0.0003   |
| 117 - Outlet Plenum  | 32.060  | 32.179  | 31.449  | 0.1406   | 0.0198   |
| 118 - Inlet Plenum   | 18.567  | 19.432  | 17.688  | 0.3144   | 0.0989   |
| T.C.                 | Average | Maximum | Minimum | Std Dev. | Variance |
| 400                  | 19.840  | 19.939  | 19.776  | 0.0356   | 0.0013   |
| 401                  | 32.910  | 33.258  | 32.804  | 0.0672   | 0.0045   |
| 402                  | 32.448  | 32.506  | 32.340  | 0.0415   | 0.0017   |
| 403                  | 33.589  | 33.625  | 33.541  | 0.0181   | 0.0003   |
| 404                  | 34.918  | 34.995  | 34.797  | 0.0381   | 0.0014   |
| 405                  | 35.616  | 35.733  | 35.384  | 0.1094   | 0.0120   |
| 406                  | 33.428  | 33.590  | 32.835  | 0.2448   | 0.0599   |
| 407                  | 34.587  | 34.666  | 34.468  | 0.0441   | 0.0019   |
| 408                  | N/A     | N/A     | N/A     | N/A      | N/A      |
| 409                  | 34.965  | 35.065  | 34.820  | 0.0805   | 0.0065   |
| 410                  | N/A     | N/A     | N/A     | N/A      | N/A      |
| 411                  | 32.574  | 32.707  | 32.398  | 0.0682   | 0.0047   |
| 412                  | 32.544  | 32.565  | 32.522  | 0.0113   | 0.0001   |

Figure 42. 210 Watts Heat Input at 25% Flow Rate

|                             |                        |          |            |        |        |
|-----------------------------|------------------------|----------|------------|--------|--------|
| 413                         | 32.576                 | 32.605   | 32.534     | 0.0150 | 0.0002 |
| 414 - Bath Temp             | 19.711                 | 20.578   | 18.468     | 0.4241 | 0.1798 |
| 415 - Replaced 410          | 35.783                 | 35.985   | 35.668     | 0.0734 | 0.0054 |
| 416 - Zero Reference        | 0.022                  | 0.187    | -0.231     | 0.0896 | 0.0080 |
| 417 - Top of Plate          | 32.279                 | 32.386   | 32.172     | 0.0411 | 0.0017 |
| 418 - Ambient Air           | 17.106                 | 17.228   | 16.998     | 0.0474 | 0.0022 |
| 419 - Bottom Insulation     | 36.407                 | 36.712   | 36.004     | 0.2245 | 0.0504 |
|                             | N/A                    | N/A      | N/A        | N/A    | N/A    |
| 421 - Side Insulation       | 18.326                 | 18.592   | 18.166     | 0.1148 | 0.0132 |
| 422 - Plate Top (over 417)  | 19.087                 | 19.185   | 18.986     | 0.0312 | 0.0010 |
| 423 - Side of Plate         | 30.313                 | 30.503   | 30.166     | 0.0741 | 0.0055 |
|                             |                        |          |            |        |        |
| V1 - Flow Meter Vdc         | 0.541                  | 0.562    | 0.526      | 0.0073 | 0.0001 |
| V2 - Precision Resistor Vdc | 31.855                 | 31.855   | 31.854     | 0.0001 | 0.0000 |
| V3 - Heater Terminals Vdc   | 68.081                 | 68.082   | 68.081     | 0.0003 | 0.0000 |
|                             |                        |          |            |        |        |
| Bath Temp (C)               | 32.2                   |          |            |        |        |
| Sampling Time               | N/A                    |          |            |        |        |
| Power (watts)               | 210.554                | 210.556  | 210.551    | 0.0012 | 0.0000 |
| Flow Rate (mL/sec)          | 24.6594                | 28.14285 | 22.27718   |        |        |
|                             | Plate Mean Temperature |          |            |        |        |
| Centerline Mean Temp        | 34.840                 |          |            |        |        |
| Standard Deviation          | 2.526                  |          | Delta Temp | 2.6405 |        |
| Variance                    | 6.379                  |          |            |        |        |
| Centerline Maximum Temp     | 40.548                 | 40.629   | 40.485     | 0.1471 | 0.0216 |
| Centerline Minimum Temp     | 31.890                 | 31.941   | 31.818     | 0.0190 | 0.0004 |
| Centerline Delta Temp       | 8.658                  | 8.688    | 8.667      | 0.1282 | 0.0213 |

Figure 42. 210 Watts Heat Input at 25% Flow Rate

| <b>Pump Setting</b>  | <b>15</b>      |                |                |                 |                 |
|----------------------|----------------|----------------|----------------|-----------------|-----------------|
| <b>T.C.</b>          | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b> | <b>Std Dev.</b> | <b>Variance</b> |
| 100                  | 32.52824       | 33.05665       | 32.41553       | 0.080657        | 0.009587        |
| 101                  | 33.6794        | 33.91211       | 33.49707       | 0.062601        | 0.003919        |
| 102                  | 33.67123       | 33.8584        | 33.52734       | 0.05738         | 0.003292        |
| 103                  | 39.01044       | 39.14551       | 38.75293       | 0.05486         | 0.00301         |
| 104                  | 33.8882        | 34.1377        | 33.69629       | 0.055788        | 0.003112        |
| 105                  | 33.77191       | 34.20215       | 33.58691       | 0.082866        | 0.006867        |
| 106                  | 34.138         | 34.37012       | 33.9209        | 0.065734        | 0.004321        |
| 107                  | 33.72125       | 33.83203       | 33.54199       | 0.048287        | 0.002332        |
| 108                  | 33.74936       | 33.97852       | 33.56348       | 0.068509        | 0.004693        |
| 109                  | 34.70972       | 35.05859       | 34.47949       | 0.072411        | 0.005243        |
| 110                  | 34.12235       | 34.3584        | 33.71777       | 0.086161        | 0.007424        |
| 111                  | 42.17258       | 42.5166        | 41.94727       | 0.065499        | 0.00429         |
| 112                  | 41.41339       | 41.58887       | 41.21094       | 0.064194        | 0.004121        |
| 113                  | 35.02194       | 35.21484       | 34.52344       | 0.083282        | 0.006936        |
| 114                  | 32.00789       | 32.11719       | 31.9082        | 0.047771        | 0.002282        |
| 115 - Inlet Pipe     | 32.23669       | 32.44531       | 32.11914       | 0.060569        | 0.003669        |
| 116 - Zero Reference | 0.039307       | 0.066406       | 0.003906       | 0.014403        | 0.000207        |
| 117 - Outlet Plenum  | 32.29709       | 32.34375       | 32.2373        | 0.021249        | 0.000452        |
| 118 - Inlet Plenum   | 18.50949       | 19.13281       | 17.56641       | 0.423555        | 0.179399        |
| <b>T.C.</b>          | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b> | <b>Std Dev.</b> | <b>Variance</b> |
| 400                  | 19.40492       | 19.47461       | 19.33984       | 0.02895         | 0.000838        |
| 401                  | 32.74313       | 33.75684       | 32.61426       | 0.136168        | 0.018542        |
| 402                  | 32.31334       | 32.35645       | 32.2168        | 0.025147        | 0.000632        |
| 403                  | 34.27692       | 34.67773       | 34.12695       | 0.081514        | 0.006645        |
| 404                  | 35.31786       | 35.50586       | 35.21582       | 0.048862        | 0.002387        |
| 405                  | 36.13042       | 36.68262       | 35.89648       | 0.146397        | 0.021432        |
| 406                  | 33.54317       | 33.82227       | 33.08887       | 0.193794        | 0.037556        |
| 407                  | 35.15036       | 35.30762       | 34.92676       | 0.06748         | 0.004554        |
| 408                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 409                  | 34.54453       | 34.75488       | 34.45605       | 0.050951        | 0.002596        |
| 410                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 411                  | 32.51852       | 32.67871       | 32.38867       | 0.060007        | 0.003601        |
| 412                  | 32.56595       | 32.64258       | 32.46289       | 0.047396        | 0.002246        |
| 413                  | 32.61501       | 32.68164       | 32.52734       | 0.040324        | 0.001626        |
| 414 - Bath Temp      | 19.50726       | 20.26465       | 18.68262       | 0.371153        | 0.137755        |
| 415 - Replaced 410   | 36.68518       | 36.83203       | 36.29785       | 0.0734          | 0.005388        |
| 416 - Zero Reference | 0.028015       | 0.201172       | -0.21875       | 0.087199        | 0.007604        |

Figure 43. 250 Watts Heat Input at 15% Flow Rate

|                           |          |          |            |          |          |
|---------------------------|----------|----------|------------|----------|----------|
| 417 - Top of Plate        | 32.58939 | 32.99316 | 32.39648   | 0.081926 | 0.006712 |
| 418 - Ambient Air         | 17.02158 | 17.58301 | 16.71582   | 0.090212 | 0.008138 |
| 419 - bottom insulation   | 37.30475 | 37.46484 | 37.1582    | 0.056463 | 0.003188 |
| 420 Bottom Insulation     | -76.6115 | -52.1719 | -103.742   | 14.22186 | 202.2613 |
| 421 -Side Insulation      | 19.24953 | 19.3125  | 19.16309   | 0.031165 | 0.000971 |
| 422 - Plate Top (over 27) | 17.5573  | 17.80078 | 17.41992   | 0.068015 | 0.004626 |
| 423-Side of Plate         | 29.96733 | 30.1084  | 29.82031   | 0.060086 | 0.00361  |
|                           |          |          |            |          |          |
| v1 - Flowmeter            | 0.520382 | 0.536996 | 0.50902    | 0.005716 | 0.000033 |
| v2 - Resistor             | 34.69889 | 34.6997  | 34.6981    | 0.000414 | 1.7E-07  |
| v3 - Heater               | 74.17609 | 74.1766  | 74.1757    | 0.000187 | 3.5E-08  |
|                           |          |          |            |          |          |
| Bath Temp (C)             | 32.1     |          |            |          |          |
| Sampling Time             | 0.128182 | 0.144796 | 0.11682    | 0.005716 | 0.000033 |
| Power                     | 249.8862 | 249.8917 | 249.8812   | 0.002518 | 6.3E-06  |
| Flowrate                  | 21.29227 | 24.05206 | 19.40497   |          |          |
| Inlet Temperature         | 32.23669 |          |            |          |          |
| Centerline Mean Temp      | 35.36269 |          |            |          |          |
| Standard Deviation        | 3.009787 |          | Delta Temp | 3.26269  |          |
| Variance                  | 9.058818 |          |            |          |          |
| Centerline Maximum Temp   | 42.17258 |          |            |          |          |
| Centerline Minimum Temp   | 32.00789 |          |            |          |          |
| Centerline Delta Temp     | 10.16469 |          |            |          |          |

Figure 43. 250 Watts Heat Input at 15% Flow Rate

| <b>Pump Setting</b>  | <b>20</b>      |                |                |                 |                 |
|----------------------|----------------|----------------|----------------|-----------------|-----------------|
| <b>T.C.</b>          | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b> | <b>Std Dev.</b> | <b>Variance</b> |
| 100                  | 32.61304       | 32.77979       | 32.50928       | 0.041404        | 0.001958        |
| 101                  | 33.80925       | 34.02637       | 33.6582        | 0.075495        | 0.005699        |
| 102                  | 33.81379       | 34.15234       | 33.46973       | 0.092835        | 0.008618        |
| 103                  | 39.15909       | 39.44238       | 38.98828       | 0.082204        | 0.006758        |
| 104                  | 34.19204       | 34.33984       | 33.67285       | 0.090538        | 0.008197        |
| 105                  | 34.07239       | 34.22656       | 33.66895       | 0.092302        | 0.00852         |
| 106                  | 34.2809        | 34.42773       | 34.12305       | 0.064459        | 0.004155        |
| 107                  | 33.84938       | 34.22949       | 33.6123        | 0.083615        | 0.006991        |
| 108                  | 33.86002       | 34.36621       | 33.66797       | 0.103478        | 0.010708        |
| 109                  | 34.72646       | 34.85547       | 34.62793       | 0.048254        | 0.002328        |
| 110                  | 34.2216        | 34.44043       | 33.98633       | 0.085618        | 0.00733         |
| 111                  | 42.18317       | 42.47266       | 41.98438       | 0.079564        | 0.00633         |
| 112                  | 41.46361       | 42.09766       | 41.13672       | 0.106651        | 0.011375        |
| 113                  | 35.03133       | 35.27051       | 34.80762       | 0.082958        | 0.006882        |
| 114                  | 32.06202       | 33.19238       | 31.85938       | 0.158891        | 0.025246        |
| 115 - Inlet Pipe     | 32.2962        | 32.47852       | 32.11719       | 0.065611        | 0.004305        |
| 116 - Zero Reference | 0.050376       | 0.080078       | 0.017578       | 0.013552        | 0.000184        |
| 117 - Outlet Plenum  | 32.27184       | 32.32617       | 32.22754       | 0.023933        | 0.000573        |
| 118 - Inlet Plenum   | 18.56295       | 19.13477       | 17.69824       | 0.316347        | 0.100075        |
| <b>T.C.</b>          | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b> | <b>Std Dev.</b> | <b>Variance</b> |
| 400                  | 19.55644       | 19.7666        | 19.48633       | 0.041646        | 0.001734        |
| 401                  | 32.80778       | 33.04297       | 32.66895       | 0.057014        | 0.003251        |
| 402                  | 32.4183        | 32.5166        | 32.34961       | 0.025794        | 0.000665        |
| 403                  | 34.38673       | 34.73047       | 34.2041        | 0.091769        | 0.008421        |
| 404                  | 35.40267       | 35.66211       | 35.20215       | 0.075781        | 0.005743        |
| 405                  | 37.52045       | 37.83301       | 37.24902       | 0.082261        | 0.006767        |
| 406                  | 33.72366       | 33.89844       | 33.3252        | 0.093921        | 0.008821        |
| 407                  | 35.55658       | 36.29004       | 35.37891       | 0.120529        | 0.014527        |
| 408                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 409                  | 34.55305       | 34.81445       | 34.27539       | 0.084794        | 0.00719         |
| 410                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 411                  | 32.6901        | 32.95312       | 32.34961       | 0.095029        | 0.009031        |
| 412                  | 32.71315       | 32.76367       | 32.68262       | 0.015455        | 0.000239        |
| 413                  | 32.75856       | 32.83984       | 32.71875       | 0.015727        | 0.000247        |
| 414 - Bath Temp      | 19.50473       | 20.48926       | 18.70215       | 0.324519        | 0.105313        |
| 415 - Replaced 410   | 36.78075       | 37.28613       | 36.62109       | 0.089993        | 0.008099        |
| 416 - Zero Reference | 0.107197       | 0.236328       | -0.13574       | 0.072979        | 0.005326        |

Figure 44. 250 Watts Heat Input at 20% Flow Rate

|                           |          |          |            |          |          |
|---------------------------|----------|----------|------------|----------|----------|
| 417 - Top of Plate        | 32.59892 | 32.77344 | 32.24121   | 0.072904 | 0.005315 |
| 418 - Ambient Air         | 17.03645 | 17.34082 | 16.85742   | 0.089767 | 0.008058 |
| 419 - bottom insulation   | 37.04769 | 37.30762 | 36.77344   | 0.08455  | 0.007149 |
|                           |          |          |            |          |          |
| 421 -Side Insulation      | 18.8012  | 19.00293 | 18.66309   | 0.079689 | 0.00635  |
| 422 - Plate Top (over 27) | 17.51396 | 17.87207 | 17.07422   | 0.102023 | 0.010409 |
| 423-Side of Plate         | 29.53807 | 29.84668 | 29.27637   | 0.150423 | 0.022627 |
|                           |          |          |            |          |          |
| v1 - Flowmeter            | 0.528281 | 0.544564 | 0.520887   | 0.004189 | 0.000018 |
| v2 - Resistor             | 34.6936  | 34.6946  | 34.6925    | 0.000608 | 3.7E-07  |
| v3 - Heater               | 74.17682 | 74.1771  | 74.1766    | 0.00012  | 1.4E-08  |
|                           |          |          |            |          |          |
| Bath Temp (C)             | 32.2     |          |            |          |          |
| Sampling Time             | 0.136081 | 0.152364 | 0.128687   | 0.004189 | 0.000018 |
| Power                     | 249.8506 | 249.858  | 249.8433   | 0.004115 | 0.000017 |
| Flowrate                  | 22.60448 | 25.30918 | 21.3762    |          |          |
| Inlet Temperature         | 32.2962  |          |            |          |          |
| Centerline Mean Temp      | 35.48036 |          |            |          |          |
| Standard Deviation        | 2.978927 |          | Delta Temp | 3.280361 |          |
| Variance                  | 8.874004 |          |            |          |          |
| Centerline Maximum Temp   | 42.18317 |          |            |          |          |
| Centerline Minimum Temp   | 32.06202 |          |            |          |          |
| Centerline Delta Temp     | 10.12115 |          |            |          |          |
| Centerline Delta Temp     | 6.2E+74  | 6.2E+74  | 6.2E+74    |          |          |

Figure 44. 250 Watts Heat Input at 20% Flow Rate

| <b>Pump Setting</b>  | <b>25</b>             |                       |                       |                        |                        |
|----------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>I.C.</u></b>   | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| 100                  | 32.63862              | 33.07617              | 32.14258              | 0.002784               | 1.5E-07                |
| 101                  | 33.7739               | 34.15137              | 33.54199              | 0.104591               | 0.010939               |
| 102                  | 33.73885              | 34.16504              | 33.18652              | 0.124748               | 0.015562               |
| 103                  | 39.19515              | 39.87402              | 38.28125              | 0.169993               | 0.028897               |
| 104                  | 33.98239              | 34.375                | 33.58301              | 0.12471                | 0.015552               |
| 105                  | 34.06672              | 34.44336              | 33.87793              | 0.092178               | 0.008497               |
| 106                  | 34.29309              | 34.47363              | 34.13184              | 0.083382               | 0.006953               |
| 107                  | 33.79872              | 34.49707              | 33.5918               | 0.143118               | 0.020483               |
| 108                  | 33.74781              | 34.03125              | 33.39063              | 0.114848               | 0.01319                |
| 109                  | 34.79072              | 35.48242              | 34.54004              | 0.140579               | 0.019762               |
| 110                  | 34.18564              | 34.60547              | 33.8291               | 0.123711               | 0.015305               |
| 111                  | 42.06941              | 42.61426              | 41.80664              | 0.1081                 | 0.011686               |
| 112                  | 41.34952              | 42.19824              | 40.49316              | 0.181945               | 0.033104               |
| 113                  | 35.00116              | 35.36523              | 34.69531              | 0.110656               | 0.012245               |
| 114                  | 31.88851              | 32.37305              | 31.58594              | 0.138152               | 0.019086               |
| 115 - Inlet Pipe     | 32.32906              | 33.24805              | 32.10742              | 0.140212               | 0.019659               |
| 116 - Zero Reference | 0.209105              | 0.607422              | 0.039063              | 0.151747               | 0.023027               |
| 117 - Outlet Plenum  | 32.2442               | 32.29297              | 32.17871              | 0.028233               | 0.000797               |
| 118 - Inlet Plenum   | 18.1136               | 18.81543              | 17.47266              | 0.301478               | 0.090889               |
| <b><u>I.C.</u></b>   |                       |                       |                       |                        |                        |
| 400                  | 19.60066              | 19.70703              | 19.53516              | 0.036123               | 0.001305               |
| 401                  | 32.91336              | 33.07617              | 32.70801              | 0.073464               | 0.005397               |
| 402                  | 32.36388              | 32.4668               | 32.14258              | 0.067896               | 0.00461                |
| 403                  | 34.36651              | 34.76855              | 33.76855              | 0.128846               | 0.016601               |
| 404                  | 35.41882              | 35.82422              | 35.11133              | 0.107828               | 0.011627               |
| 405                  | 37.46188              | 38.05273              | 37.16113              | 0.136465               | 0.018623               |
| 406                  | 33.68078              | 33.9873               | 33.26855              | 0.126068               | 0.015893               |
| 407                  | 35.56797              | 36.19238              | 35.23145              | 0.130296               | 0.016977               |
| 408                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| 409                  | 34.41952              | 34.80371              | 33.80371              | 0.155898               | 0.024304               |
| 410                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| 411                  | 32.54929              | 32.89063              | 32.12305              | 0.116311               | 0.013528               |
| 412                  | 32.50666              | 32.63477              | 32.3291               | 0.081492               | 0.006641               |

Figure 45. 250 Watts Heat Input at 25% Flow Rate



|                           |          |          |            |          |          |
|---------------------------|----------|----------|------------|----------|----------|
| 413                       | 32.58439 | 32.73535 | 32.4209    | 0.083469 | 0.006967 |
| 414 - Bath Temp           | 19.66188 | 20.29688 | 18.95801   | 0.339488 | 0.115252 |
| 415 - Replaced 410        | 36.57279 | 38.09082 | 36.125     | 0.24622  | 0.060625 |
| 416 - Zero Reference      | 0.035907 | 0.217773 | -0.24023   | 0.10792  | 0.011647 |
| 417 - Top of Plate        | 32.4351  | 32.97559 | 32.20117   | 0.128136 | 0.016419 |
| 418 - Ambient Air         | 16.99988 | 17.37988 | 16.49316   | 0.100303 | 0.010061 |
| 419 - bottom insulation   | 37.26837 | 37.57715 | 36.43652   | 0.147756 | 0.021832 |
| 420 Bottom Insulation     | 221.4878 | 232.5732 | 204.8467   | 7.678248 | 58.9555  |
| 421 -Side Insulation      | 18.76865 | 19.16992 | 18.51855   | 0.141287 | 0.019962 |
| 422 - Plate Top (over 27) | 17.44044 | 17.58496 | 17.27148   | 0.064396 | 0.004147 |
| 423-Side of Plate         | 28.06599 | 28.31738 | 27.80664   | 0.095857 | 0.009189 |
|                           |          |          |            |          |          |
| v1 - Flowmeter            | 0.535177 | 0.546487 | 0.52537    | 0.004135 | 0.000017 |
| v2 - Resistor             | 34.68836 | 34.6898  | 34.6872    | 0.000748 | 5.6E-07  |
| v3 - Heater               | 74.17698 | 74.1772  | 74.1767    | 0.000107 | 1.2E-08  |
|                           |          |          |            |          |          |
| Bath Temp (C)             | 32.1     |          |            |          |          |
| Sampling Time             | 0.142977 | 0.154287 | 0.13317    | 0.004135 | 0.000017 |
| Power                     | 249.8134 | 249.8235 | 249.8044   | 0.005317 | 0.000028 |
| Flowrate                  | 23.74989 | 25.62861 | 22.12087   |          |          |
| Inlet Temperature         | 32.32906 |          |            |          |          |
| Centerline Mean Temp      | 35.42011 |          |            |          |          |
| Standard Deviation        | 2.979942 |          | Delta Temp | 3.320113 |          |
| Variance                  | 8.880057 |          |            |          |          |
| Centerline Maximum Temp   | 42.06941 |          |            |          |          |
| Centerline Minimum Temp   | 31.88851 |          |            |          |          |
| Centerline Delta Temp     | 10.1809  |          |            |          |          |

Figure 45. 250 Watts Heat Input at 25% Flow Rate

| Pump Setting         | 15             |                | Run One        |                 |                 |
|----------------------|----------------|----------------|----------------|-----------------|-----------------|
| <u>T.C.</u>          | <u>Average</u> | <u>Maximum</u> | <u>Minimum</u> | <u>Std Dev.</u> | <u>Variance</u> |
| 100                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 101                  | 35.431         | 35.489         | 35.281         | 0.0427          | 0.0018          |
| 102                  | 36.440         | 36.483         | 36.271         | 0.0385          | 0.0015          |
| 103                  | 42.567         | 42.629         | 42.500         | 0.0293          | 0.0009          |
| 104                  | 35.740         | 35.784         | 35.693         | 0.0196          | 0.0004          |
| 105                  | 35.991         | 36.101         | 35.912         | 0.0327          | 0.0011          |
| 106                  | 36.429         | 36.472         | 36.060         | 0.0678          | 0.0046          |
| 107                  | 35.854         | 35.948         | 35.823         | 0.0374          | 0.0014          |
| 108                  | 36.062         | 36.091         | 35.917         | 0.0313          | 0.0010          |
| 109                  | 42.174         | 42.214         | 42.148         | 0.0134          | 0.0002          |
| 110                  | 36.203         | 36.246         | 36.177         | 0.0143          | 0.0002          |
| 111                  | 45.202         | 45.249         | 45.142         | 0.0277          | 0.0008          |
| 112                  | 44.262         | 44.285         | 44.207         | 0.0210          | 0.0004          |
| 113                  | 36.910         | 36.971         | 36.824         | 0.0288          | 0.0008          |
| 114                  | 35.715         | 35.903         | 35.661         | 0.0604          | 0.0037          |
| 115-Inlet Pipe       | 34.261         | 34.338         | 34.227         | 0.0303          | 0.0009          |
| 116 - Zero Reference | 0.120          | 0.144          | 0.075          | 0.0125          | 0.0002          |
| 117 - Outlet Plenum  | 34.423         | 34.445         | 34.386         | 0.0163          | 0.0003          |
| 118 - Inlet Plenum   | 19.752         | 20.281         | 18.370         | 0.4852          | 0.2354          |
| <u>T.C.</u>          | <u>Average</u> | <u>Maximum</u> | <u>Minimum</u> | <u>Std Dev.</u> | <u>Variance</u> |
| 400                  | 19.374         | 20.067         | 19.220         | 0.1703          | 0.0290          |
| 401                  | 34.745         | 34.852         | 34.711         | 0.0409          | 0.0017          |
| 402                  | 34.604         | 34.654         | 34.556         | 0.0262          | 0.0007          |
| 403                  | 37.221         | 37.246         | 37.169         | 0.0200          | 0.0004          |
| 404                  | 38.009         | 38.024         | 37.991         | 0.0078          | 0.0001          |
| 405                  | 39.555         | 39.616         | 39.453         | 0.0516          | 0.0027          |
| 406                  | 35.785         | 35.811         | 35.626         | 0.0293          | 0.0009          |
| 407                  | 38.250         | 38.280         | 38.188         | 0.0164          | 0.0003          |
| 408                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 409                  | 37.104         | 37.156         | 37.020         | 0.0376          | 0.0014          |
| 410                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 411                  | 34.966         | 34.990         | 34.906         | 0.0183          | 0.0003          |
| 412                  | 34.824         | 34.854         | 34.770         | 0.0156          | 0.0002          |

Figure 46. 275 Watts Heat Input at 15% Flow Rate

|                                    |                        |         |            |        |         |
|------------------------------------|------------------------|---------|------------|--------|---------|
| <b>413</b>                         | 34.883                 | 34.916  | 34.849     | 0.0117 | 0.0001  |
| <b>414 - Bath Temp</b>             | 19.997                 | 20.556  | 19.279     | 0.3678 | 0.1353  |
| <b>415 - Replaced 410</b>          | 24.542                 | 39.668  | 23.952     | 7.6520 | 58.5535 |
| <b>416 - Zero Reference</b>        | 0.262                  | 0.540   | -0.243     | 0.2026 | 0.0410  |
| <b>417 - Top of Plate</b>          | 34.919                 | 34.964  | 34.753     | 0.0382 | 0.0015  |
| <b>418 - Ambient Air</b>           | 17.872                 | 17.979  | 17.789     | 0.0444 | 0.0020  |
| <b>419 - Bottom Insulation</b>     | 41.433                 | 41.482  | 41.318     | 0.0445 | 0.0020  |
|                                    |                        |         |            |        |         |
| <b>421 - Side Insulation</b>       | 20.397                 | 20.661  | 19.915     | 0.2559 | 0.0655  |
| <b>422 - Plate Top (over 417)</b>  | 21.110                 | 21.300  | 20.952     | 0.0749 | 0.0056  |
| <b>423 - Side of Plate</b>         | 32.031                 | 32.159  | 31.811     | 0.0696 | 0.0048  |
|                                    |                        |         |            |        |         |
| <b>V1 - Flow Meter Vdc</b>         | 0.528                  | 0.544   | 0.520      | 0.0060 | 0.0000  |
| <b>V2 - Precision Resistor Vdc</b> | 36.251                 | 36.254  | 36.245     | 0.0036 | 0.0000  |
| <b>V3 - Heater Terminals Vdc</b>   | 77.590                 | 77.590  | 77.590     | 0.0002 | 0.0000  |
|                                    |                        |         |            |        |         |
| <b>Bath Temp (C)</b>               | 35.0                   |         |            |        |         |
| <b>Sampling Time</b>               | 0.136                  | 0.152   | 0.128      | 0.0060 | 0.0000  |
| <b>Power (watts)</b>               | 273.077                | 273.103 | 273.031    | 0.0278 | 0.0008  |
| <b>Flow Rate (mL/sec)</b>          | 22.635                 | 25.242  | 21.192     |        |         |
|                                    | Plate Mean Temperature |         |            |        |         |
| <b>Centerline Mean Temp</b>        | 38.213                 |         |            |        |         |
| <b>Standard Deviation</b>          | 3.458                  |         | Delta Temp | 3.2128 |         |
| <b>Variance</b>                    | 11.955                 |         |            |        |         |
| <b>Centerline Maximum Temp</b>     | 45.202                 | 45.249  | 45.142     | 0.0678 | 0.0046  |
| <b>Centerline Minimum Temp</b>     | 35.431                 | 35.489  | 35.281     | 0.0134 | 0.0002  |
| <b>Centerline Delta Temp</b>       | 9.771                  | 9.760   | 9.860      | 0.0544 | 0.0044  |

Figure 46. 275 Watts Heat Input at 15% Flow Rate

| Pump Setting         | 15             |                | Run Two        |                 |                 |
|----------------------|----------------|----------------|----------------|-----------------|-----------------|
| <u>T.C.</u>          | <u>Average</u> | <u>Maximum</u> | <u>Minimum</u> | <u>Std Dev.</u> | <u>Variance</u> |
| 100                  | 32.882         | 34.785         | 32.845         | 0.520           | 0.2707          |
| 101                  | 35.329         | 35.366         | 35.234         | 0.041           | 0.0017          |
| 102                  | 36.431         | 36.466         | 36.370         | 0.025           | 0.0006          |
| 103                  | 42.437         | 42.496         | 42.390         | 0.024           | 0.0006          |
| 104                  | 35.806         | 35.829         | 35.778         | 0.013           | 0.0002          |
| 105                  | 35.987         | 36.024         | 35.862         | 0.054           | 0.0029          |
| 106                  | 36.459         | 36.484         | 36.433         | 0.011           | 0.0001          |
| 107                  | 35.922         | 35.948         | 35.896         | 0.014           | 0.0002          |
| 108                  | 35.974         | 35.997         | 35.950         | 0.011           | 0.0001          |
| 109                  | 42.223         | 42.243         | 42.180         | 0.014           | 0.0002          |
| 110                  | 36.155         | 36.171         | 36.131         | 0.008           | 0.0001          |
| 111                  | 45.160         | 45.181         | 45.130         | 0.012           | 0.0001          |
| 112                  | 44.236         | 44.260         | 44.209         | 0.013           | 0.0002          |
| 113                  | 36.913         | 36.939         | 36.885         | 0.014           | 0.0002          |
| 114                  | 35.859         | 35.874         | 35.835         | 0.009           | 0.0001          |
| 115-Inlet Pipe       | 34.339         | 34.361         | 34.309         | 0.011           | 0.0001          |
| 116 - Zero Reference | 0.119          | 0.168          | 0.063          | 0.023           | 0.0005          |
| 117 - Outlet Plenum  | 34.423         | 34.459         | 34.384         | 0.018           | 0.0003          |
| 118 - Inlet Plenum   | 19.737         | 20.417         | 18.607         | 0.534           | 0.2851          |
| <u>T.C.</u>          | <u>Average</u> | <u>Maximum</u> | <u>Minimum</u> | <u>Std Dev.</u> | <u>Variance</u> |
| 400                  | 19.192         | 19.808         | 19.090         | 0.173           | 0.0299          |
| 401                  | 34.816         | 35.178         | 34.689         | 0.077           | 0.0060          |
| 402                  | 34.617         | 34.650         | 34.556         | 0.022           | 0.0005          |
| 403                  | 37.126         | 37.145         | 37.082         | 0.015           | 0.0002          |
| 404                  | 38.002         | 38.047         | 37.979         | 0.014           | 0.0002          |
| 405                  | 39.575         | 39.610         | 39.550         | 0.016           | 0.0003          |
| 406                  | 35.770         | 35.787         | 35.724         | 0.013           | 0.0002          |
| 407                  | 38.184         | 38.215         | 38.158         | 0.015           | 0.0002          |
| 408                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 409                  | 37.079         | 37.109         | 37.056         | 0.013           | 0.0002          |
| 410                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 411                  | 34.955         | 34.985         | 34.929         | 0.013           | 0.0002          |
| 412                  | 34.827         | 34.847         | 34.771         | 0.014           | 0.0002          |

Figure 47. 275 Watts Heat Input at 15% Flow Rate

|                                    |                        |         |            |         |          |
|------------------------------------|------------------------|---------|------------|---------|----------|
| <b>413</b>                         | 34.870                 | 34.896  | 34.845     | 0.012   | 0.0002   |
| <b>414 - Bath Temp</b>             | 20.020                 | 20.646  | 19.156     | 0.374   | 0.1402   |
| <b>415 - Replaced 410</b>          | 39.652                 | 40.229  | 39.286     | 0.225   | 0.0507   |
| <b>416 - Zero Reference</b>        | 0.181                  | 0.489   | -0.511     | 0.209   | 0.0435   |
| <b>417 - Top of Plate</b>          | 34.880                 | 34.912  | 34.818     | 0.024   | 0.0006   |
| <b>418 - Ambient Air</b>           | 17.760                 | 17.802  | 17.732     | 0.015   | 0.0002   |
| <b>419 - Bottom Insulation</b>     | 41.202                 | 41.248  | 41.150     | 0.025   | 0.0006   |
|                                    |                        |         |            |         |          |
| <b>421 - Side Insulation</b>       | 21.516                 | 22.131  | 20.380     | 0.624   | 0.3898   |
| <b>422 - Plate Top (over 417)</b>  | 21.247                 | 21.369  | 21.061     | 0.060   | 0.0036   |
| <b>423 - Side of Plate</b>         | 30.974                 | 31.271  | 30.776     | 0.131   | 0.0171   |
|                                    |                        |         |            |         |          |
| <b>V1 - Flow Meter Vdc</b>         | 0.524                  | 0.538   | 0.511      | 0.005   | 0.0000   |
| <b>V2 - Precision Resistor Vdc</b> | 36.241                 | 36.246  | 36.237     | 0.001   | 0.0000   |
| <b>V3 - Heater Terminals Vdc</b>   | 77.589                 | 77.590  | 77.589     | 0.000   | 0.0000   |
|                                    |                        |         |            |         |          |
| <b>Bath Temp (C)</b>               | 35.0                   |         |            |         |          |
| <b>Sampling Time</b>               | 0.132                  | 0.146   | 0.119      | 0.005   | 0.0000   |
| <b>Power (watts)</b>               | 273.003                | 273.036 | 272.973    | 0.011   | 0.0001   |
| <b>Flow Rate (mL/sec)</b>          | 21.944                 | 24.282  | 19.758     | -90.887 | -91.9051 |
|                                    | Plate Mean Temperature |         |            |         |          |
| <b>Centerline Mean Temp</b>        | 38.207                 |         |            |         |          |
| <b>Standard Deviation</b>          | 3.438                  |         | Delta Temp | 3.207   |          |
| <b>Variance</b>                    | 11.821                 |         |            |         |          |
| <b>Centerline Maximum Temp</b>     | 45.160                 | 45.181  | 45.130     | 0.054   | 0.0029   |
| <b>Centerline Minimum Temp</b>     | 35.329                 | 35.366  | 35.234     | 0.008   | 0.0001   |
| <b>Centerline Delta Temp</b>       | 9.831                  | 9.814   | 9.895      | 0.045   | 0.0028   |

Figure 47. 275 Watts Heat Input at 15% Flow Rate

| <b>Pump Setting</b>         | <b>15</b>             |                       | <b>Run Three</b>      |                        |                        |
|-----------------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>100</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>101</b>                  | 33.682                | 33.912                | 33.497                | 0.0626                 | 0.0039                 |
| <b>102</b>                  | 33.669                | 33.858                | 33.527                | 0.0574                 | 0.0033                 |
| <b>103</b>                  | 39.012                | 39.146                | 38.753                | 0.0549                 | 0.0030                 |
| <b>104</b>                  | 33.881                | 34.138                | 33.696                | 0.0558                 | 0.0031                 |
| <b>105</b>                  | 33.760                | 34.202                | 33.587                | 0.0829                 | 0.0069                 |
| <b>106</b>                  | 34.135                | 34.370                | 33.921                | 0.0657                 | 0.0043                 |
| <b>107</b>                  | 33.725                | 33.832                | 33.542                | 0.0483                 | 0.0023                 |
| <b>108</b>                  | 33.744                | 33.979                | 33.563                | 0.0685                 | 0.0047                 |
| <b>109</b>                  | 34.701                | 35.059                | 34.479                | 0.0724                 | 0.0052                 |
| <b>110</b>                  | 34.125                | 34.358                | 33.718                | 0.0862                 | 0.0074                 |
| <b>111</b>                  | 42.172                | 42.517                | 41.947                | 0.0655                 | 0.0043                 |
| <b>112</b>                  | 41.422                | 41.589                | 41.211                | 0.0642                 | 0.0041                 |
| <b>113</b>                  | 35.027                | 35.215                | 34.523                | 0.0833                 | 0.0069                 |
| <b>114</b>                  | 32.009                | 32.117                | 31.908                | 0.0478                 | 0.0023                 |
| <b>115-Inlet Pipe</b>       | 32.224                | 32.445                | 32.119                | 0.0606                 | 0.0037                 |
| <b>116 - Zero Reference</b> | 0.041                 | 0.066                 | 0.004                 | 0.0144                 | 0.0002                 |
| <b>117 - Outlet Plenum</b>  | 32.297                | 32.344                | 32.237                | 0.0212                 | 0.0005                 |
| <b>118 - Inlet Plenum</b>   | 18.586                | 19.133                | 17.566                | 0.4236                 | 0.1794                 |
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>400</b>                  | 19.408                | 19.475                | 19.340                | 0.0289                 | 0.0008                 |
| <b>401</b>                  | 32.729                | 33.757                | 32.614                | 0.1362                 | 0.0185                 |
| <b>402</b>                  | 32.315                | 32.356                | 32.217                | 0.0251                 | 0.0006                 |
| <b>403</b>                  | 34.267                | 34.678                | 34.127                | 0.0815                 | 0.0066                 |
| <b>404</b>                  | 35.313                | 35.506                | 35.216                | 0.0489                 | 0.0024                 |
| <b>405</b>                  | 36.073                | 36.683                | 35.896                | 0.1464                 | 0.0214                 |
| <b>406</b>                  | 33.634                | 33.822                | 33.089                | 0.1938                 | 0.0376                 |
| <b>407</b>                  | 35.138                | 35.308                | 34.927                | 0.0675                 | 0.0046                 |
| <b>408</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>409</b>                  | 34.538                | 34.755                | 34.456                | 0.0510                 | 0.0026                 |
| <b>410</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>411</b>                  | 32.519                | 32.679                | 32.389                | 0.0600                 | 0.0036                 |
| <b>412</b>                  | 32.573                | 32.643                | 32.463                | 0.0474                 | 0.0022                 |

Figure 48. 275 Watts Heat Input at 15% Flow Rate

|                             |                        |         |            |        |        |
|-----------------------------|------------------------|---------|------------|--------|--------|
| 413                         | 32.625                 | 32.682  | 32.527     | 0.0403 | 0.0016 |
| 414 - Bath Temp             | 19.488                 | 20.265  | 18.683     | 0.3712 | 0.1378 |
| 415 - Replaced 410          | 36.686                 | 36.832  | 36.298     | 0.0734 | 0.0054 |
| 416 - Zero Reference        | 0.050                  | 0.201   | -0.219     | 0.0872 | 0.0076 |
| 417 - Top of Plate          | 32.582                 | 32.993  | 32.396     | 0.0819 | 0.0067 |
| 418 - Ambient Air           | 17.009                 | 17.583  | 16.716     | 0.0902 | 0.0081 |
| 419 - Bottom Insulation     | 37.304                 | 37.465  | 37.158     | 0.0565 | 0.0032 |
|                             |                        |         |            |        |        |
| 421 - Side Insulation       | 19.249                 | 19.313  | 19.163     | 0.0312 | 0.0010 |
| 422 - Plate Top (over 417)  | 17.544                 | 17.801  | 17.420     | 0.0680 | 0.0046 |
| 423 - Side of Plate         | 29.968                 | 30.108  | 29.820     | 0.0601 | 0.0036 |
|                             |                        |         |            |        |        |
| V1 - Flow Meter Vdc         | 0.519                  | 0.537   | 0.509      | 0.0057 | 0.0000 |
| V2 - Precision Resistor Vdc | 34.699                 | 34.700  | 34.698     | 0.0004 | 0.0000 |
| V3 - Heater Terminals Vdc   | 74.176                 | 74.177  | 74.176     | 0.0002 | 0.0000 |
|                             |                        |         |            |        |        |
| Bath Temp (C)               | 32.2                   |         |            |        |        |
| Sampling Time               | 0.127                  | 0.145   | 0.117      | 0.0057 | 0.0000 |
| Power (watts)               | 249.886                | 249.892 | 249.881    | 0.0025 | 0.0000 |
| Flow Rate (mL/sec)          | 21.091                 | 24.052  | 19.405     |        |        |
|                             | Plate Mean Temperature |         |            |        |        |
| Centerline Mean Temp        | 35.362                 |         |            |        |        |
| Standard Deviation          | 3.012                  |         | Delta Temp | 3.1619 |        |
| Variance                    | 9.071                  |         |            |        |        |
| Centerline Maximum Temp     | 42.172                 | 42.517  | 41.947     | 0.0862 | 0.0074 |
| Centerline Minimum Temp     | 32.009                 | 32.117  | 31.908     | 0.0478 | 0.0023 |
| Centerline Delta Temp       | 10.163                 | 10.399  | 10.039     | 0.0384 | 0.0051 |

Figure 48. 275 Watts Heat Input at 15% Flow Rate

| <b>Pump Setting</b>         | <b>20</b>             |                       | <b>Run One</b>        |                        |                        |
|-----------------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>100</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>101</b>                  | 35.229                | 35.306                | 35.167                | 0.0439                 | 0.0019                 |
| <b>102</b>                  | 36.299                | 36.348                | 36.259                | 0.0270                 | 0.0007                 |
| <b>103</b>                  | 41.103                | 41.124                | 41.072                | 0.0129                 | 0.0002                 |
| <b>104</b>                  | 36.083                | 36.117                | 36.064                | 0.0130                 | 0.0002                 |
| <b>105</b>                  | 35.839                | 35.859                | 35.805                | 0.0142                 | 0.0002                 |
| <b>106</b>                  | 36.063                | 36.110                | 35.960                | 0.0398                 | 0.0016                 |
| <b>107</b>                  | 35.925                | 35.949                | 35.896                | 0.0127                 | 0.0002                 |
| <b>108</b>                  | 35.886                | 36.011                | 35.846                | 0.0299                 | 0.0009                 |
| <b>109</b>                  | 42.230                | 42.266                | 42.209                | 0.0172                 | 0.0003                 |
| <b>110</b>                  | 36.115                | 36.153                | 36.091                | 0.0118                 | 0.0001                 |
| <b>111</b>                  | 45.018                | 45.063                | 44.982                | 0.0240                 | 0.0006                 |
| <b>112</b>                  | 44.068                | 44.087                | 44.039                | 0.0128                 | 0.0002                 |
| <b>113</b>                  | 36.866                | 36.888                | 36.850                | 0.0101                 | 0.0001                 |
| <b>114</b>                  | 35.706                | 35.721                | 35.687                | 0.0088                 | 0.0001                 |
| <b>115-Inlet Pipe</b>       | 34.240                | 34.262                | 34.181                | 0.0149                 | 0.0002                 |
| <b>116 - Zero Reference</b> | 0.088                 | 0.117                 | 0.049                 | 0.0155                 | 0.0002                 |
| <b>117 - Outlet Plenum</b>  | 34.368                | 34.430                | 34.328                | 0.0254                 | 0.0006                 |
| <b>118 - Inlet Plenum</b>   | 19.924                | 20.542                | 18.557                | 0.4040                 | 0.1632                 |
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>400</b>                  | 19.132                | 19.327                | 19.015                | 0.0663                 | 0.0044                 |
| <b>401</b>                  | 34.770                | 34.853                | 34.699                | 0.0381                 | 0.0015                 |
| <b>402</b>                  | 34.579                | 34.612                | 34.541                | 0.0182                 | 0.0003                 |
| <b>403</b>                  | 36.663                | 36.711                | 36.641                | 0.0177                 | 0.0003                 |
| <b>404</b>                  | 37.500                | 37.519                | 37.471                | 0.0134                 | 0.0002                 |
| <b>405</b>                  | 38.989                | 39.331                | 38.959                | 0.1396                 | 0.0195                 |
| <b>406</b>                  | 35.745                | 35.774                | 35.723                | 0.0122                 | 0.0001                 |
| <b>407</b>                  | 38.034                | 38.063                | 38.013                | 0.0106                 | 0.0001                 |
| <b>408</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>409</b>                  | 36.931                | 36.974                | 36.907                | 0.0150                 | 0.0002                 |
| <b>410</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>411</b>                  | 34.905                | 34.932                | 34.876                | 0.0148                 | 0.0002                 |
| <b>412</b>                  | 34.781                | 34.799                | 34.753                | 0.0116                 | 0.0001                 |

Figure 49. 275 Watts Heat Input at 20% Flow Rate



|                             |                        |         |            |        |        |
|-----------------------------|------------------------|---------|------------|--------|--------|
| 413                         | 34.834                 | 34.858  | 34.812     | 0.0128 | 0.0002 |
| 414 - Bath Temp             | 20.440                 | 21.203  | 19.834     | 0.3018 | 0.0911 |
| 415 - Replaced 410          | 39.504                 | 39.806  | 39.269     | 0.1269 | 0.0161 |
| 416 - Zero Reference        | 0.282                  | 0.625   | -0.229     | 0.2133 | 0.0455 |
| 417 - Top of Plate          | 34.761                 | 34.824  | 34.723     | 0.0213 | 0.0005 |
| 418 - Ambient Air           | 17.824                 | 17.871  | 17.785     | 0.0219 | 0.0005 |
| 419 - Bottom Insulation     | 39.357                 | 39.431  | 38.711     | 0.2048 | 0.0419 |
|                             | *****                  | *****   | -39.378    | *****  | *****  |
| 421 - Side Insulation       | 21.289                 | 21.508  | 20.742     | 0.2492 | 0.0621 |
| 422 - Plate Top (over 417)  | 21.694                 | 21.752  | 21.507     | 0.0454 | 0.0021 |
| 423 - Side of Plate         | 31.521                 | 31.633  | 31.429     | 0.0467 | 0.0022 |
|                             |                        |         |            |        |        |
| V1 - Flow Meter Vdc         | 0.523                  | 0.533   | 0.507      | 0.0047 | 0.0000 |
| V2 - Precision Resistor Vdc | 36.219                 | 36.220  | 36.219     | 0.0003 | 0.0000 |
| V3 - Heater Terminals Vdc   | 77.588                 | 77.588  | 77.588     | 0.0001 | 0.0000 |
|                             |                        |         |            |        |        |
| Bath Temp (C)               | 35.0                   |         |            |        |        |
| Sampling Time               | 0.131                  | 0.141   | 0.115      | 0.0047 | 0.0000 |
| Power (watts)               | 272.833                | 272.840 | 272.827    | 0.0029 | 0.0000 |
| Flow Rate (mL/sec)          | 21.710                 | 23.356  | 19.050     |        |        |
|                             | Plate Mean Temperature |         |            |        |        |
| Centerline Mean Temp        | 38.031                 |         |            |        |        |
| Standard Deviation          | 3.329                  |         | Delta Temp | 3.0308 |        |
| Variance                    | 11.081                 |         |            |        |        |
| Centerline Maximum Temp     | 45.018                 | 45.063  | 44.982     | 0.0439 | 0.0019 |
| Centerline Minimum Temp     | 35.229                 | 35.306  | 35.167     | 0.0088 | 0.0001 |
| Centerline Delta Temp       | 9.789                  | 9.758   | 9.815      | 0.0351 | 0.0018 |

Figure 49. 275 Watts Heat Input at 20% Flow Rate

| Pump Setting         | 20             |                | Run Two        |                 |                 |
|----------------------|----------------|----------------|----------------|-----------------|-----------------|
| <u>T.C.</u>          | <u>Average</u> | <u>Maximum</u> | <u>Minimum</u> | <u>Std Dev.</u> | <u>Variance</u> |
| 100                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 101                  | 35.227         | 35.323         | 35.201         | 0.0312          | 0.0010          |
| 102                  | 36.335         | 36.369         | 36.284         | 0.0155          | 0.0002          |
| 103                  | 41.127         | 41.154         | 41.095         | 0.0133          | 0.0002          |
| 104                  | 36.122         | 36.176         | 36.095         | 0.0179          | 0.0003          |
| 105                  | 35.848         | 35.876         | 35.777         | 0.0195          | 0.0004          |
| 106                  | 36.041         | 36.073         | 35.980         | 0.0202          | 0.0004          |
| 107                  | 35.949         | 35.971         | 35.914         | 0.0128          | 0.0002          |
| 108                  | 35.901         | 36.013         | 35.856         | 0.0333          | 0.0011          |
| 109                  | 42.222         | 42.269         | 42.155         | 0.0225          | 0.0005          |
| 110                  | 36.119         | 36.146         | 36.080         | 0.0138          | 0.0002          |
| 111                  | 45.087         | 45.108         | 45.046         | 0.0159          | 0.0003          |
| 112                  | 44.066         | 44.112         | 43.914         | 0.0315          | 0.0010          |
| 113                  | 36.859         | 36.918         | 36.817         | 0.0217          | 0.0005          |
| 114                  | 35.714         | 35.742         | 35.680         | 0.0119          | 0.0001          |
| 115-Inlet Pipe       | 34.274         | 34.305         | 34.249         | 0.0128          | 0.0002          |
| 116 - Zero Reference | 0.098          | 0.156          | -0.003         | 0.0280          | 0.0008          |
| 117 - Outlet Plenum  | 34.409         | 34.449         | 34.345         | 0.0249          | 0.0006          |
| 118 - Inlet Plenum   | 19.939         | 20.416         | 18.688         | 0.4787          | 0.2292          |
| <u>T.C.</u>          | <u>Average</u> | <u>Maximum</u> | <u>Minimum</u> | <u>Std Dev.</u> | <u>Variance</u> |
| 400                  | 19.082         | 19.321         | 18.997         | 0.0832          | 0.0069          |
| 401                  | 34.813         | 35.088         | 34.722         | 0.0856          | 0.0073          |
| 402                  | 34.619         | 34.646         | 34.572         | 0.0188          | 0.0004          |
| 403                  | 36.675         | 36.709         | 36.654         | 0.0115          | 0.0001          |
| 404                  | 37.537         | 37.570         | 37.521         | 0.0111          | 0.0001          |
| 405                  | 39.031         | 39.061         | 38.955         | 0.0326          | 0.0011          |
| 406                  | 35.760         | 35.782         | 35.740         | 0.0114          | 0.0001          |
| 407                  | 38.056         | 38.070         | 38.030         | 0.0102          | 0.0001          |
| 408                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 409                  | 36.949         | 36.994         | 36.917         | 0.0150          | 0.0002          |
| 410                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| 411                  | 34.851         | 34.881         | 34.791         | 0.0235          | 0.0006          |
| 412                  | 34.725         | 34.765         | 34.641         | 0.0305          | 0.0009          |

Figure 50. 275 Watts Heat Input at 20% Flow Rate

|                                    |            |             |            |        |        |
|------------------------------------|------------|-------------|------------|--------|--------|
| <b>413</b>                         | 34.784     | 34.885      | 34.739     | 0.0312 | 0.0010 |
| <b>414 - Bath Temp</b>             | 20.520     | 21.064      | 19.839     | 0.3066 | 0.0940 |
| <b>415 - Replaced 410</b>          | 39.477     | 40.123      | 39.136     | 0.1591 | 0.0253 |
| <b>416 - Zero Reference</b>        | 0.144      | 0.544       | -0.527     | 0.2635 | 0.0695 |
| <b>417 - Top of Plate</b>          | 34.748     | 34.830      | 34.688     | 0.0318 | 0.0010 |
| <b>418 - Ambient Air</b>           | 17.828     | 20.684      | 17.750     | 0.6506 | 0.4232 |
| <b>419 - Bottom Insulation</b>     | 39.353     | 39.372      | 39.331     | 0.0108 | 0.0001 |
|                                    |            |             |            |        |        |
| <b>421 - Side Insulation</b>       | 20.513     | 20.645      | 20.417     | 0.0527 | 0.0028 |
| <b>422 - Plate Top (over 417)</b>  | 21.595     | 21.728      | 21.464     | 0.0636 | 0.0040 |
| <b>423 - Side of Plate</b>         | 31.317     | 31.522      | 31.087     | 0.1005 | 0.0101 |
|                                    |            |             |            |        |        |
| <b>V1 - Flow Meter Vdc</b>         | 0.523      | 0.536       | 0.517      | 0.0038 | 0.0000 |
| <b>V2 - Precision Resistor Vdc</b> | 36.221     | 36.224      | 36.220     | 0.0014 | 0.0000 |
| <b>V3 - Heater Terminals Vdc</b>   | 77.588     | 77.588      | 77.588     | 0.0001 | 0.0000 |
|                                    |            |             |            |        |        |
| <b>Bath Temp (C)</b>               | 35.0       |             |            |        |        |
| <b>Sampling Time</b>               | 0.131      | 0.144       | 0.124      | 0.0038 | 0.0000 |
| <b>Power (watts)</b>               | 272.847    | 272.868     | 272.838    | 0.0104 | 0.0001 |
| <b>Flow Rate (mL/sec)</b>          | 21.759     | 23.894      | 20.653     |        |        |
|                                    | Plate Mean | Temperature |            |        |        |
| <b>Centerline Mean Temp</b>        | 38.044     |             |            |        |        |
| <b>Standard Deviation</b>          | 3.335      |             | Delta Temp | 3.0441 |        |
| <b>Variance</b>                    | 11.124     |             |            |        |        |
| <b>Centerline Maximum Temp</b>     | 45.087     | 45.108      | 45.046     | 0.0333 | 0.0011 |
| <b>Centerline Minimum Temp</b>     | 35.227     | 35.323      | 35.201     | 0.0119 | 0.0001 |
| <b>Centerline Delta Temp</b>       | 9.860      | 9.785       | 9.845      | 0.0214 | 0.0010 |

Figure 50. 275 Watts Heat Input at 20% Flow Rate

| <b>Pump Setting</b>         | <b>25</b>      |                |                |                 |                 |
|-----------------------------|----------------|----------------|----------------|-----------------|-----------------|
| <b>T.C.</b>                 | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b> | <b>Std Dev.</b> | <b>Variance</b> |
| <b>100</b>                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| <b>101</b>                  | 35.928         | 35.954         | 35.898         | 0.0147          | 0.0002          |
| <b>102</b>                  | 36.265         | 36.295         | 36.242         | 0.0123          | 0.0002          |
| <b>103</b>                  | 41.097         | 41.141         | 41.066         | 0.0186          | 0.0003          |
| <b>104</b>                  | 36.198         | 36.221         | 36.153         | 0.0153          | 0.0002          |
| <b>105</b>                  | 36.032         | 36.076         | 35.960         | 0.0311          | 0.0010          |
| <b>106</b>                  | 36.211         | 36.276         | 36.069         | 0.0603          | 0.0036          |
| <b>107</b>                  | 35.852         | 35.882         | 35.813         | 0.0176          | 0.0003          |
| <b>108</b>                  | 36.035         | 36.063         | 36.001         | 0.0149          | 0.0002          |
| <b>109</b>                  | 41.768         | 41.822         | 41.642         | 0.0503          | 0.0025          |
| <b>110</b>                  | 36.156         | 36.245         | 36.102         | 0.0429          | 0.0018          |
| <b>111</b>                  | 44.926         | 44.955         | 44.897         | 0.0170          | 0.0003          |
| <b>112</b>                  | 44.047         | 44.064         | 44.010         | 0.0146          | 0.0002          |
| <b>113</b>                  | 37.021         | 37.065         | 36.974         | 0.0233          | 0.0005          |
| <b>114</b>                  | 35.986         | 36.053         | 35.661         | 0.0782          | 0.0061          |
| <b>115-Inlet Pipe</b>       | 34.387         | 34.411         | 34.344         | 0.0144          | 0.0002          |
| <b>116 - Zero Reference</b> | 0.069          | 0.152          | 0.033          | 0.0273          | 0.0007          |
| <b>117 - Outlet Plenum</b>  | 34.395         | 34.427         | 34.355         | 0.0163          | 0.0003          |
| <b>118 - Inlet Plenum</b>   | 20.462         | 20.819         | 18.866         | 0.5512          | 0.3038          |
| <b>T.C.</b>                 | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b> | <b>Std Dev.</b> | <b>Variance</b> |
| <b>400</b>                  | 19.987         | 20.086         | 19.903         | 0.0420          | 0.0018          |
| <b>401</b>                  | 34.788         | 34.842         | 34.747         | 0.0256          | 0.0007          |
| <b>402</b>                  | 34.607         | 34.636         | 34.568         | 0.0188          | 0.0004          |
| <b>403</b>                  | 36.624         | 36.685         | 36.594         | 0.0230          | 0.0005          |
| <b>404</b>                  | 37.436         | 37.467         | 37.419         | 0.0106          | 0.0001          |
| <b>405</b>                  | 40.259         | 40.313         | 40.167         | 0.0492          | 0.0024          |
| <b>406</b>                  | 35.776         | 35.803         | 35.749         | 0.0128          | 0.0002          |
| <b>407</b>                  | 38.127         | 38.196         | 38.012         | 0.0607          | 0.0037          |
| <b>408</b>                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| <b>409</b>                  | 36.836         | 36.872         | 36.790         | 0.0251          | 0.0006          |
| <b>410</b>                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| <b>411</b>                  | 34.915         | 34.952         | 34.893         | 0.0126          | 0.0002          |
| <b>412</b>                  | 34.810         | 34.836         | 34.782         | 0.0111          | 0.0001          |

Figure 51. 275 Watts Heat Input at 25% Flow Rate

|                                    |                        |         |            |        |        |
|------------------------------------|------------------------|---------|------------|--------|--------|
| <b>413</b>                         | 34.855                 | 34.877  | 34.824     | 0.0121 | 0.0001 |
| <b>414 - Bath Temp</b>             | 20.577                 | 21.169  | 19.917     | 0.3285 | 0.1079 |
| <b>415 - Replaced 410</b>          | 39.682                 | 39.960  | 39.484     | 0.1326 | 0.0176 |
| <b>416 - Zero Reference</b>        | 0.389                  | 0.650   | -0.373     | 0.2165 | 0.0469 |
| <b>417 - Top of Plate</b>          | 34.696                 | 34.735  | 34.636     | 0.0232 | 0.0005 |
| <b>418 - Ambient Air</b>           | 18.086                 | 18.149  | 18.005     | 0.0440 | 0.0019 |
| <b>419 - Bottom Insulation</b>     | 38.837                 | 38.961  | 38.793     | 0.0560 | 0.0031 |
|                                    |                        |         |            |        |        |
| <b>421 - Side Insulation</b>       | 21.026                 | 21.644  | 20.297     | 0.4416 | 0.1950 |
| <b>422 - Plate Top (over 417)</b>  | 22.386                 | 22.431  | 22.317     | 0.0329 | 0.0011 |
| <b>423 - Side of Plate</b>         | 32.829                 | 33.107  | 32.712     | 0.1068 | 0.0114 |
|                                    |                        |         |            |        |        |
| <b>V1 - Flow Meter Vdc</b>         | 0.536                  | 0.548   | 0.527      | 0.0044 | 0.0000 |
| <b>V2 - Precision Resistor Vdc</b> | 36.201                 | 36.202  | 36.200     | 0.0006 | 0.0000 |
| <b>V3 - Heater Terminals Vdc</b>   | 77.585                 | 77.585  | 77.584     | 0.0002 | 0.0000 |
|                                    |                        |         |            |        |        |
| <b>Bath Temp (C)</b>               | 35.0                   |         |            |        |        |
| <b>Sampling Time</b>               | 0.144                  | 0.156   | 0.135      | 0.0044 | 0.0000 |
| <b>Power (watts)</b>               | 272.682                | 272.693 | 272.674    | 0.0051 | 0.0000 |
| <b>Flow Rate (mL/sec)</b>          | 23.842                 | 25.884  | 22.372     |        |        |
|                                    | Plate Mean Temperature |         |            |        |        |
| <b>Centerline Mean Temp</b>        | 38.109                 |         |            |        |        |
| <b>Standard Deviation</b>          | 3.192                  |         | Delta Temp | 3.1086 |        |
| <b>Variance</b>                    | 10.191                 |         |            |        |        |
| <b>Centerline Maximum Temp</b>     | 44.926                 | 44.955  | 44.897     | 0.0782 | 0.0061 |
| <b>Centerline Minimum Temp</b>     | 35.852                 | 35.882  | 35.661     | 0.0123 | 0.0002 |
| <b>Centerline Delta Temp</b>       | 9.074                  | 9.073   | 9.236      | 0.0659 | 0.0060 |

Figure 51. 275 Watts Heat Input at 25% Flow Rate

| <b>Pump Setting</b>         | <b>30</b>      |                |                |                 |                 |
|-----------------------------|----------------|----------------|----------------|-----------------|-----------------|
| <b>T.C.</b>                 | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b> | <b>Std Dev.</b> | <b>Variance</b> |
| <b>100</b>                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| <b>101</b>                  | 24.137         | 24.173         | 23.956         | 0.0332          | 0.0011          |
| <b>102</b>                  | 24.336         | 24.390         | 24.259         | 0.0230          | 0.0005          |
| <b>103</b>                  | 30.294         | 30.334         | 30.243         | 0.0195          | 0.0004          |
| <b>104</b>                  | 24.518         | 24.640         | 24.450         | 0.0323          | 0.0010          |
| <b>105</b>                  | 24.377         | 24.645         | 24.291         | 0.0894          | 0.0080          |
| <b>106</b>                  | 24.880         | 24.916         | 24.799         | 0.0237          | 0.0006          |
| <b>107</b>                  | 23.802         | 24.390         | 23.690         | 0.1804          | 0.0326          |
| <b>108</b>                  | 24.298         | 24.330         | 24.244         | 0.0216          | 0.0005          |
| <b>109</b>                  | 25.459         | 25.506         | 25.408         | 0.0184          | 0.0003          |
| <b>110</b>                  | 24.638         | 24.675         | 24.417         | 0.0671          | 0.0045          |
| <b>111</b>                  | 28.178         | 28.220         | 28.113         | 0.0248          | 0.0006          |
| <b>112</b>                  | 30.856         | 30.905         | 30.787         | 0.0232          | 0.0005          |
| <b>113</b>                  | 24.963         | 25.014         | 24.910         | 0.0194          | 0.0004          |
| <b>114</b>                  | 24.053         | 24.325         | 24.014         | 0.0509          | 0.0026          |
| <b>115-Inlet Pipe</b>       | 22.629         | 22.668         | 22.491         | 0.0393          | 0.0015          |
| <b>116 - Zero Reference</b> | 0.005          | 0.102          | -0.096         | 0.0370          | 0.0014          |
| <b>117 - Outlet Plenum</b>  | 22.304         | 22.389         | 22.212         | 0.0382          | 0.0015          |
| <b>118 - Inlet Plenum</b>   | 18.257         | 18.765         | 17.141         | 0.3830          | 0.1467          |
| <b>T.C.</b>                 | <b>Average</b> | <b>Maximum</b> | <b>Minimum</b> | <b>Std Dev.</b> | <b>Variance</b> |
| <b>400</b>                  | 18.092         | 18.483         | 17.959         | 0.1234          | 0.0152          |
| <b>401</b>                  | 23.215         | 23.252         | 23.154         | 0.0231          | 0.0005          |
| <b>402</b>                  | 22.951         | 22.985         | 22.898         | 0.0176          | 0.0003          |
| <b>403</b>                  | 25.670         | 25.700         | 25.616         | 0.0160          | 0.0003          |
| <b>404</b>                  | 26.700         | 26.738         | 26.651         | 0.0181          | 0.0003          |
| <b>405</b>                  | 28.935         | 28.961         | 28.893         | 0.0143          | 0.0002          |
| <b>406</b>                  | 24.927         | 24.959         | 24.865         | 0.0197          | 0.0004          |
| <b>407</b>                  | 26.285         | 26.332         | 26.240         | 0.0195          | 0.0004          |
| <b>408</b>                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| <b>409</b>                  | 27.186         | 27.233         | 27.115         | 0.0244          | 0.0006          |
| <b>410</b>                  | N/A            | N/A            | N/A            | N/A             | N/A             |
| <b>411</b>                  | 23.296         | 23.468         | 23.256         | 0.0603          | 0.0036          |
| <b>412</b>                  | 23.398         | 23.445         | 23.360         | 0.0232          | 0.0005          |

Figure 52. 275 Watts Heat Input at 30% Flow Rate

|                             |                        |         |            |        |        |
|-----------------------------|------------------------|---------|------------|--------|--------|
| 413                         | 23.346                 | 23.383  | 23.294     | 0.0219 | 0.0005 |
| 414 - Bath Temp             | 17.757                 | 18.958  | 17.000     | 0.3720 | 0.1384 |
| 415 - Replaced 410          | 25.912                 | 25.982  | 25.851     | 0.0282 | 0.0008 |
| 416 - Zero Reference        | -0.050                 | 0.086   | -0.228     | 0.0591 | 0.0035 |
| 417 - Top of Plate          | 22.771                 | 22.928  | 22.696     | 0.0446 | 0.0020 |
| 418 - Ambient Air           | 16.477                 | 16.571  | 16.357     | 0.0618 | 0.0038 |
| 419 - Bottom Insulation     | 29.477                 | 29.514  | 29.433     | 0.0214 | 0.0005 |
|                             |                        |         |            |        |        |
| 421 - Side Insulation       | 18.199                 | 18.612  | 17.957     | 0.1710 | 0.0293 |
| 422 - Plate Top (over 417)  | 16.519                 | 16.562  | 16.487     | 0.0142 | 0.0002 |
| 423 - Side of Plate         | 21.639                 | 21.973  | 21.367     | 0.1447 | 0.0209 |
|                             |                        |         |            |        |        |
| V1 - Flow Meter Vdc         | 0.592                  | 0.656   | 0.528      | 0.0396 | 0.0016 |
| V2 - Precision Resistor Vdc | 0.366                  | 0.368   | 0.366      | 0.0007 | 0.0000 |
| V3 - Heater Terminals Vdc   | 40.653                 | 40.653  | 40.652     | 0.0002 | 0.0000 |
|                             |                        |         |            |        |        |
| Bath Temp (C)               | 22.2                   |         |            |        |        |
| Sampling Time               | 0.199                  | 0.264   | 0.136      | 0.0396 | 0.0016 |
| Power (watts)               | 147.404                | 148.152 | 147.176    | 0.2737 | 0.0749 |
| Flow Rate (mL/sec)          | 33.130                 | 43.829  | 22.549     |        |        |
|                             | Plate Mean Temperature |         |            |        |        |
| Centerline Mean Temp        | 25.628                 |         |            |        |        |
| Standard Deviation          | 2.266                  |         | Delta Temp | 3.4277 |        |
| Variance                    | 5.136                  |         |            |        |        |
| Centerline Maximum Temp     | 30.856                 | 30.905  | 30.787     | 0.1804 | 0.0326 |
| Centerline Minimum Temp     | 23.802                 | 24.173  | 23.690     | 0.0184 | 0.0003 |
| Centerline Delta Temp       | 7.055                  | 6.732   | 7.097      | 0.1621 | 0.0322 |

Figure 52. 275 Watts Heat Input at 30% Flow Rate

| <b>Pump Setting</b>         | <b>40</b>             |                       |                       |                        |                        |
|-----------------------------|-----------------------|-----------------------|-----------------------|------------------------|------------------------|
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>100</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>101</b>                  | 35.462                | 35.982                | 31.809                | 1.4785                 | 2.1859                 |
| <b>102</b>                  | 35.964                | 36.413                | 32.344                | 1.4382                 | 2.0685                 |
| <b>103</b>                  | 40.989                | 41.150                | 37.863                | 1.0841                 | 1.1753                 |
| <b>104</b>                  | 35.932                | 36.199                | 32.396                | 1.3132                 | 1.7246                 |
| <b>105</b>                  | 35.818                | 36.018                | 32.440                | 1.2162                 | 1.4791                 |
| <b>106</b>                  | 36.276                | 36.476                | 32.472                | 1.3289                 | 1.7659                 |
| <b>107</b>                  | 35.747                | 35.879                | 32.431                | 1.1449                 | 1.3107                 |
| <b>108</b>                  | 35.748                | 35.844                | 32.186                | 1.2350                 | 1.5251                 |
| <b>109</b>                  | 41.657                | 41.731                | 38.641                | 1.0167                 | 1.0337                 |
| <b>110</b>                  | 36.082                | 36.222                | 32.913                | 1.1132                 | 1.2391                 |
| <b>111</b>                  | 43.315                | 44.030                | 40.569                | 1.0195                 | 1.0394                 |
| <b>112</b>                  | 39.536                | 40.826                | 36.443                | 1.2520                 | 1.5674                 |
| <b>113</b>                  | 36.645                | 36.724                | 33.783                | 0.9510                 | 0.9044                 |
| <b>114</b>                  | 35.813                | 35.886                | 32.959                | 0.9516                 | 0.9055                 |
| <b>115-Inlet Pipe</b>       | 31.191                | 34.512                | 28.579                | 2.2733                 | 5.1679                 |
| <b>116 - Zero Reference</b> | 0.060                 | 0.336                 | -0.141                | 0.0604                 | 0.0036                 |
| <b>117 - Outlet Plenum</b>  | 31.570                | 34.363                | 27.603                | 2.5782                 | 6.6470                 |
| <b>118 - Inlet Plenum</b>   | 20.295                | 20.736                | 18.542                | 0.4610                 | 0.2125                 |
| <b><u>T.C.</u></b>          | <b><u>Average</u></b> | <b><u>Maximum</u></b> | <b><u>Minimum</u></b> | <b><u>Std Dev.</u></b> | <b><u>Variance</u></b> |
| <b>400</b>                  | 20.982                | 21.301                | 20.813                | 0.1261                 | 0.0159                 |
| <b>401</b>                  | 34.477                | 34.971                | 31.184                | 1.2896                 | 1.6631                 |
| <b>402</b>                  | 34.250                | 34.470                | 31.095                | 1.1633                 | 1.3533                 |
| <b>403</b>                  | 36.429                | 36.838                | 33.054                | 1.2824                 | 1.6445                 |
| <b>404</b>                  | 37.189                | 37.393                | 33.866                | 1.2489                 | 1.5597                 |
| <b>405</b>                  | 39.737                | 39.813                | 37.302                | 0.8115                 | 0.6585                 |
| <b>406</b>                  | 35.698                | 35.758                | 32.411                | 1.1550                 | 1.3341                 |
| <b>407</b>                  | 37.954                | 38.067                | 35.236                | 0.9143                 | 0.8359                 |
| <b>408</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>409</b>                  | 36.340                | 36.448                | 33.618                | 0.9122                 | 0.8321                 |
| <b>410</b>                  | N/A                   | N/A                   | N/A                   | N/A                    | N/A                    |
| <b>411</b>                  | 34.693                | 34.799                | 33.716                | 0.2894                 | 0.0838                 |
| <b>412</b>                  | 34.567                | 34.659                | 33.614                | 0.2799                 | 0.0783                 |

Figure 53. 275 Watts Heat Input at 40% Flow Rate



|                             |                        |         |            |        |        |
|-----------------------------|------------------------|---------|------------|--------|--------|
| 413                         | 34.641                 | 34.730  | 33.376     | 0.3912 | 0.1531 |
| 414 - Bath Temp             | 20.513                 | 20.996  | 19.678     | 0.2867 | 0.0822 |
| 415 - Replaced 410          | 39.426                 | 39.738  | 36.441     | 1.0065 | 1.0131 |
| 416 - Zero Reference        | 0.158                  | 0.416   | -0.590     | 0.2262 | 0.0511 |
| 417 - Top of Plate          | 34.434                 | 34.594  | 31.991     | 0.7842 | 0.6150 |
| 418 - Ambient Air           | 18.455                 | 18.515  | 18.403     | 0.0243 | 0.0006 |
| 419 - Bottom Insulation     | 37.657                 | 37.817  | 34.997     | 0.8891 | 0.7906 |
|                             |                        |         |            |        |        |
| 421 - Side Insulation       | 21.067                 | 21.313  | 20.593     | 0.2037 | 0.0415 |
| 422 - Plate Top (over 417)  | 22.698                 | 22.883  | 22.587     | 0.0603 | 0.0036 |
| 423 - Side of Plate         | 33.041                 | 33.497  | 30.029     | 1.0902 | 1.1885 |
|                             |                        |         |            |        |        |
| V1 - Flow Meter Vdc         | 0.624                  | 0.664   | 0.613      | 0.0105 | 0.0001 |
| V2 - Precision Resistor Vdc | 36.201                 | 36.207  | 36.199     | 0.0022 | 0.0000 |
| V3 - Heater Terminals Vdc   | 77.584                 | 77.584  | 77.584     | 0.0002 | 0.0000 |
|                             |                        |         |            |        |        |
| Bath Temp (C)               | 35.0                   |         |            |        |        |
| Sampling Time               | 0.232                  | 0.272   | 0.220      | 0.0105 | 0.0001 |
| Power (watts)               | 272.677                | 272.726 | 272.665    | 0.0172 | 0.0003 |
| Flow Rate (mL/sec)          | 38.520                 | 45.217  | 36.616     |        |        |
|                             | Plate Mean Temperature |         |            |        |        |
| Centerline Mean Temp        | 37.499                 |         |            |        |        |
| Standard Deviation          | 2.570                  |         | Delta Temp | 2.4989 |        |
| Variance                    | 6.604                  |         |            |        |        |
| Centerline Maximum Temp     | 43.315                 | 44.030  | 40.569     | 1.4785 | 2.1859 |
| Centerline Minimum Temp     | 35.462                 | 35.844  | 31.809     | 0.9510 | 0.9044 |
| Centerline Delta Temp       | 7.854                  | 8.187   | 8.761      | 0.5275 | 1.2815 |

Figure 53. 275 Watts Heat Input at 40% Flow Rate

## Colburn j Factor Spreadsheet

| Dh (m) | Q (ml/sec) | v (m/s) | Tavg | Tin  | T prop | density | viscosity | sp heat | power | flux | thermal cond |
|--------|------------|---------|------|------|--------|---------|-----------|---------|-------|------|--------------|
| 0.0164 | 154.08     | 0.0441  | 37.5 | 31.2 | 34.3   | 993.9   | 0.00076   | 0.00015 | 273   | 3522 | 0.622        |
| 0.0164 | 110.416    | 0.0316  | 38.1 | 34.4 | 36.2   | 993.7   | 0.00074   | 0.00015 | 273   | 3522 | 0.62496      |
| 0.0164 | 107.716    | 0.0308  | 34.6 | 31.8 | 33.2   | 994.3   | 0.00076   | 0.00015 | 211   | 2719 | 0.6208       |
| 0.0164 | 98.636     | 0.0282  | 35.5 | 32.3 | 33.9   | 994.1   | 0.00075   | 0.00015 | 250   | 3227 | 0.623        |
| 0.0164 | 97.692     | 0.028   | 35.4 | 32.2 | 33.8   | 994.2   | 0.00076   | 0.00015 | 250   | 3228 | 0.6228       |
| 0.0164 | 98.636     | 0.0282  | 34.8 | 32.3 | 33.6   | 994.3   | 0.00077   | 0.00015 | 211   | 2720 | 0.6204       |
| 0.0164 | 95.368     | 0.0273  | 34.1 | 32.2 | 33.2   | 994.3   | 0.00076   | 0.00015 | 215   | 2773 | 0.6208       |
| 0.0164 | 90.276     | 0.0258  | 38.2 | 34.3 | 36.2   | 993.7   | 0.00073   | 0.00015 | 273   | 3527 | 0.62496      |
| 0.0164 | 110.416    | 0.0316  | 26   | 22.7 | 24.4   | 997.4   | 0.0009    | 0.00015 | 146   | 1888 | 0.609905     |
| 0.0164 | 89.388     | 0.0256  | 38.2 | 34.3 | 36.3   | 993.7   | 0.00073   | 0.00015 | 273   | 3526 | 0.62496      |
| 0.0164 | 90.54      | 0.0259  | 35.4 | 32.3 | 33.8   | 994.2   | 0.00076   | 0.00015 | 250   | 3228 | 0.6228       |
| 0.0164 | 90.54      | 0.0259  | 34.9 | 32.3 | 33.6   | 994.3   | 0.00077   | 0.00015 | 211   | 2720 | 0.6204       |
| 0.0164 | 85.16908   | 0.0244  | 34.2 | 32.3 | 33.3   | 994.3   | 0.00076   | 0.00015 | 211   | 2720 | 0.6208       |
| 0.0164 | 85.224     | 0.0244  | 35.4 | 32.2 | 33.8   | 994.2   | 0.00076   | 0.00015 | 211   | 2720 | 0.6228       |
| 0.0164 | 87.776     | 0.0251  | 26   | 22.8 | 24.4   | 997.4   | 0.0009    | 0.00015 | 146   | 1890 | 0.609905     |
| 0.0164 | 86.84      | 0.0249  | 26   | 22.7 | 24.4   | 997.4   | 0.0009    | 0.00015 | 146   | 1888 | 0.609905     |
| 0.0164 | 84.364     | 0.0242  | 25.2 | 20.7 | 23     | 997.8   | 0.00091   | 0.00015 | 99.1  | 1281 | 0.608769     |
| 0.0164 | 7.2        | 0.0021  | 38   | 34.2 | 36.1   | 993.7   | 0.00074   | 0.00015 | 273   | 3524 | 0.62496      |
| Dh (m) | Q (ml/sec) | v (m/s) | Tavg | Tin  | T prop | density | viscosity | sp heat | power | flux | thermal cond |

| Delta T | Nu_avg | Pr   | Reynolds | j      | j_wetling | j_M&B  | j_J&W  | Nu | j_low   | j_high |        |
|---------|--------|------|----------|--------|-----------|--------|--------|----|---------|--------|--------|
| 2.5     | 26.79  | 5.02 | 942.5    | 0.0166 | 0.0121    | 0.0122 | 0.0154 | 1  | 10.5059 | 0.0153 | 0.018  |
| 3.11    | 22.07  | 4.88 | 693.77   | 0.0188 | 0.0142    | 0.0144 | 0.018  | 2  | 8.12954 | 0.0173 | 0.0203 |
| 2.44    | 21.37  | 5.24 | 663.18   | 0.0185 | 0.0146    | 0.0148 | 0.0184 | 3  | 8.06801 | 0.0171 | 0.0201 |
| 3.32    | 18.54  | 5.03 | 616.62   | 0.0175 | 0.0151    | 0.0154 | 0.0191 | 4  | 7.48808 | 0.0161 | 0.019  |
| 3.28    | 18.77  | 5.05 | 600.89   | 0.0182 | 0.0154    | 0.0156 | 0.0193 | 5  | 7.34648 | 0.0168 | 0.0198 |
| 2.05    | 25.43  | 5.08 | 597.16   | 0.0248 | 0.0154    | 0.0156 | 0.0194 | 6  | 7.3273  | 0.0228 | 0.0269 |
| 1.91    | 27.85  | 5.24 | 587.16   | 0.0273 | 0.0155    | 0.0158 | 0.0196 | 7  | 7.31921 | 0.0251 | 0.0296 |
| 3.21    | 20.87  | 4.88 | 579.43   | 0.0212 | 0.0157    | 0.0159 | 0.0197 | 8  | 7.03881 | 0.0195 | 0.023  |
| 3.89    | 9.451  | 5.12 | 574.54   | 0.0095 | 0.0157    | 0.016  | 0.0198 | 9  | 7.12675 | 0.0088 | 0.0104 |
| 3.21    | 20.9   | 4.88 | 573.73   | 0.0215 | 0.0157    | 0.016  | 0.0198 | 10 | 6.98337 | 0.0198 | 0.0233 |
| 3.16    | 19.55  | 5.05 | 556.9    | 0.0205 | 0.016     | 0.0162 | 0.0201 | 11 | 6.91296 | 0.0188 | 0.0222 |
| 12.8    | 4.08   | 5.08 | 548.14   | 0.0043 | 0.0161    | 0.0164 | 0.0203 | 12 | 6.84208 | 0.004  | 0.0047 |
| 1.41    | 36.95  | 5.24 | 524.37   | 0.0406 | 0.0165    | 0.0168 | 0.0207 | 13 | 6.68602 | 0.0373 | 0.044  |
| 3.26    | 15.9   | 5.05 | 524.2    | 0.0177 | 0.0165    | 0.0168 | 0.0207 | 14 | 6.5863  | 0.0163 | 0.0192 |
| 3.88    | 9.492  | 5.12 | 456.73   | 0.0121 | 0.0178    | 0.0181 | 0.0222 | 15 | 5.93153 | 0.0111 | 0.0131 |
| 3.79    | 9.7    | 5.12 | 451.86   | 0.0125 | 0.0179    | 0.0182 | 0.0223 | 16 | 5.88088 | 0.0115 | 0.0135 |
| 3.22    | 7.761  | 6.29 | 432.09   | 0.0097 | 0.0183    | 0.0186 | 0.0228 | 17 | 6.16098 | 0.009  | 0.0106 |
| 3.03    | 22.18  | 4.88 | 45.239   | 0.2891 | 0.0614    | 0.063  | 0.0705 | 18 | 0.91518 | 0.2659 | 0.3136 |
| Delta T | Nu_avg | Pr   | Reynolds | j      | j_wetling | j_M&B  | j_J&W  | Nu | j_low   | j_high |        |

## LIST OF REFERENCES

1. Bar-Cohen, A. and Kraus, A.D. "Thermal Considerations in the Packaging of Electrical and Electronic Components", Heat Transfer in Electronic Equipment, HTD vol. 20, ASME, pp. 1 - 8, 1981.
2. Brinkmann, R., Ramadhyani, S. and Incopera, F. P. "Enhancement of Convective Heat Transfer from Small Heat Sources to Liquid Coolants using Strip Fins", Experimental Heat Transfer, Vol. 1, pp. 315-330, 1987-1988.
3. Buechler, A.J. "Preliminary Thermal Analysis for Advanced Electronics Cooling System (AECS) Task (NSWC-6043-AECS-1)", Crane Division, Naval Surface Warfare Center, Mar 1992.
4. Buechler, A.J. and Brough, A.J. "Liquid Flow-Through-Module Thermal Evaluation Test Report (NSWC-6043-AECS-3)", Crane Division, Naval Surface Warfare Center, Mar 1993.
5. Webb, R. "Advances in Modeling Enhanced Heat Transfer Surfaces", Heat Transfer 1994: Proceedings of the Tenth International Heat Transfer Conference, vol 1, G.F. Hewitt, ed., Taylor Francis, Bristol, PA, 1994.
6. Weiting, A.R. "Empirical Correlations for Heat Transfer and Flow Friction Characteristics of rectangular Offset-Fin Plate-Fin Heat Exchangers", Journal of Heat Transfer, v. 97, pp. 488 - 490, 1975.
7. Joshi, H.M. and Webb, R.L. "Heat Transfer and Friction in the Offset Strip-Fin Heat Exchanger", International Journal of Heat Mass Transfer, vol 30, No. 1, pp. 69-84, 1987.
8. Manglik, R.M. and Bergles, A.E. "The Thermal-Hydraulic Design of the Rectangular Offset-Strip-Fin Compact Heat Exchanger", Compact Heat Exchangers, Hemisphere, pp. 123-140, 1990.
9. Xi, G. and Futagami, S. Hagiwara, Y. and Suzuki, K. "Flow and Heat Transfer Characteristics of Offset-Fin Array in the Middle Reynolds Number Range" ASME/JSME Thermal Engineering Proceedings, vol. 3, ASME, 1991.
10. Pantakar, S.V, and Prakash, C. "An Analysis of the Effect of Plate Thickness on Laminar Flow and Heat Transfer in Interrupted-Plate Passages", International Journal of Heat and Mass Transfer, Vol. 24, No. 11, pp 1801-1810, 1981.

11. Masterson, J.M. "Heat Transfer Studies on a Rectangular Channel with Offset Plate Fins", Naval Postgraduate School Thesis, Dec. 1993.
12. Parsley, M. "The Use of Thermochromic Crystals in Heat Transfer and Flow Visualization Research", Second International Symposium on Fluid Control, Measurement, Mechanics and Flow Visualization, Sept. 1988.
13. Incopera, F.P. and DeWitt, D.P. Introduction to Heat Transfer, John Wiley & Sons, New York, 1985.

## INITIAL DISTRIBUTION LIST

- |    |  |   |
|----|--|---|
| 1. | Defense Technical Information Center<br>8725 John J. Kingman Rd., STE 0944<br>Ft. Belvior, VA 22060-6218   | 2 |
| 2. | Dudley Knox Library<br>Naval Postgraduate School<br>411 Dyer Rd<br>Monterey, CA 93943-5101   | 2 |
| 3. | Chairman<br>Department of Mechanical Engineering, Code ME<br>Naval Postgraduate School<br>Monterey, Ca 93943-5002                                | 1 |
| 4. | Dr. M. D. Kelleher<br>Department of Mechanical Engineering, Code ME/KK<br>Naval Postgraduate School<br>Monterey, Ca 93943-5002                   | 2 |
| 5. | Mr. Kip Hoffer<br>Naval Weapons Support Center<br>Code 6042<br>Crane, IN 47522   | 1 |
| 6. | Mr Anthony J. Buechler<br>Naval Weapons Support Center<br>Code 6042<br>Crane, IN 47522   | 1 |
| 7. | Prof Y. Joshi<br>Department of Mechanical Engineering<br>3147 Engineering Classroom Building<br>University of Maryland<br>College Park, MD 20742 | 1 |
| 8. | Naval/Mechanical Engineering Curricular Officer, Code 34<br>Naval Postgraduate School<br>Monterey, CA 93943-5002                                 | 2 |

9. LT Carlos M. Suarez, USN  
4217 Buttonwood CT  
Virginia Beach, VA 23462

1