

Progress on the NDE Characterization of Impact Damage in Armor Materials

Joseph M. Wells, Sc.D.

XCT

JMW ASSOCIATES

102 Pine Hills Blvd
Mashpee, MA 02649-2869
(508) 477-5764

jmwconsultant@comcast.net

Terminal Ballistics Oral Session #1 - Abstract #1854



Grateful Acknowledgements to:



W.H. Green, and N.L.Rupert, *ARL Weapons & Materials Research Directorate, APG, MD, 21005*

2002 ARL Summer Students


*Mr. Jeff Wheeler (UCSC),
Mr. Herb Miller, (UMBC)*



Dr. S.J. Cimpoeu, *DSTO Aeronautical and Maritime Research Laboratory, PO Box 4331, Melbourne 30001, Australia*



Dr. Christof Reinhart, *Volume Graphics GmbH, Heidelberg, Germany*



Talk Outline

- Introduction – Challenge for Ceramic Armor
- Perspective on Damage Diagnostics & Cognitive Visualization
- Advanced 3D Voxel Analysis & Visualization
- **3D XCT Damage Characterization & Visualization**
- Summary Comments

Challenge for Ceramic Armor




Ancient Chinese terra
cotta armor vest

- History: Application of ceramic armor against high L/D penetrators is in its' **third** millennium.
- Still Searching for Best Ceramic Armor !
- Knowledge & Understanding - to design, make and apply notional ceramic armor materials.

Perspective – Damage Diagnostics & Performance

- Penetration Analysis:

- DOP, V50, Field Ballistic Tests



DESIGN BASIS:

- Theoretical
- Empirical & Numerical Computational Focus
- Diagnostic/ Analytical & Mechanistic Focus

- Damage Diagnostics & Assessment:

- Destructive Sectioning & 2D Examination
- Traditional Nondestructive Examination
- **High Resolution X-ray Computed Tomography, XCT, for 3D Diagnosis**
- Ideally we want a Engineering Predictive Modeling Capability addressing **both** penetration & damage considerations.

Perspective on Problem Solving & Cognitive Visualization

**“Imagination is more important than knowledge.
Knowledge is limited. Imagination encircles the world.” –
Albert Einstein**

Define Problem (Challenge)

- Create Engineering Approach (Plan)

- Data (Acquire & Process)

- Information (Analyze)

- Knowledge (Understanding)

- **Visualization (Intellectual Conceptualization)**

- Creativity (New Ideas)

- Innovation (Putting Ideas to Work)

- Applications (Utilization of Technology)

- Presentation & Reporting

IMAGINATION

INSIGHT

REASONING

CREATIVITY

Cognitive

VISUALIZATION

DATA

**XCT Digital
Image Scans**



INFORMATION

KNOWLEDGE

**Image Processing
& Reconstruction**

**Understanding of feature
relationships & significance**

Primer on Modern XCT



Advanced 3D Voxel Visualization & Analysis Software



- Sophisticated image analysis and visualization capability to process, analyze and visualize voxel/volume data.
- Up to 3 GB of memory utilization with Windows XP Professional OS
- Multiple Import/Export File Formats
- Virtual Metrology Capabilities
- Variable Transparency & Virtual Sectioning
- Iso-Surface Extraction
- Segmentation & Grey-Value-Classification
- Porosity / Defect Analysis
- Wall Thickness Analysis
- Stereo Viewing Tool

StudioMax v1.2.1

www.volumegraphics.com

Ballistic Impact Damage Diagnostics in Encapsulated TiB₂ Ceramic Targets

Encapsulated TiB₂ Experiment (N.L. Rupert, ARL ~1997)

- **Single Shot (Full Penetration w/o compressive ring)**
- Single Shot (Partial Penetration with compressive prestress ring)
- Double Shot (Full Penetration with compressive prestress ring)

Summary Damage Observations

Penetration Decrease with Prestress (17-4 PH Ring)

Surface Topography – Ring Steps, Radial Expansion & Cracking

W-alloy Residual Fragments

Complex Cracking Modes

Impact Induced Porosity

Impacted TiB2 Ceramics

Macro –Photos
Impact surface



Single Shot
(Full Penetration
w/o compressive
ring)






Single Shot
(Partial Penetration with
compressive prestress
ring)




Double Shot
(Full Penetration with
compressive prestress ring)

XCT Scans ~
mid-thickness




Penetration & Internal Damage


Back
Face




(z = 015)




(z = 020)




(z = 025)




(z = 030)




(z = 035)




(z = 040)



(z = 045)



(z = 050)



(z = 055)


Front
Face

Sequential XCT Scans showing impact damage cracking features and residual penetrator (white) in TiB₂ S1wo Disk - near back (Z=015) to front face (Z=55).


Surface Topography -TiB₂ 1S w/o prestress



Macro-photograph - Normal View
Surface Steps – **NOT** Visible
Radial OD Cracks – **ARE** Visible





OD Radial
cracks on
Impact
Surface
**intersect at
different loci**




XCT 3D Solid Object - Oblique View
Surface Steps – **ARE** Visible
Radial OD Cracks – **ARE** Visible

Impact Surface- Flow of Mixed Penetrator & Ceramic Rubble



TiB₂ S1wo

Surface Steps –Sectioned



Step Height

C = ~3.5 mm

B = ~2.5 mm




A = ~1.2 mm

**Step Heights Vary along
the ring circumference**

Note: Higher density (lighter color) of Steps vs Bulk TiB₂

Impact Surface Radial Expansion

Nonuniform – but localized radial expansion near impact surface



Axial Slice #51

Dia. A = 73.8 mm

Dia. B = 73.4 mm

Dia. C = 72.3 mm

Dia. D = 72.4 mm



Axial Slice #41


Dia. A = 72.7 mm

Dia. B = 72.9 mm

Dia. C = 72.1 mm

Dia. D = 72.0 mm

Fragments in TiB_2 - Segmented & Virtual Transparency




TiB_2 S1wo

Opaque 3D Solid
Object Reconstructions

Segmented & Variable
Transparency

Fragments are Porous

Virtual Metrology




TiB_2 S2w

$W = \sim 22 \text{ mm}$ $H = \sim 24.5 \text{ mm}$
 $A_s = 4794 \text{ mm}^2$ $V = 2076 \text{ mm}^3$



$W = \sim 60 \text{ mm}$ $H = \sim 25.5 \text{ mm}$
 $A_s = 8911 \text{ mm}^2$ $V = 2859 \text{ mm}^3$

Complexity of 3D Ring Cracking Damage

Early Point Cloud
Images of 3D Cracking




TiB2 1S w/o
Prestress Ring




Schematic of Concentric
Hourglass Ring Cracking

Visualization of 3D Cracking Damage in TiB_2

Orthogonal Sectioning
3D Oblique View




Recent (**Preliminary**) 3D Images
of Segmented Impact Cracking





S1wo

Impact Induced Porosity




Porosity along Ring Cracks

**TiB2 1S w/o
Prestress Ring**




Point Cloud Visualizations of Spiral Cracking in Ballistic Impact Samples

Metallic




**Ti-6Al-4V pc showing spiral cracking
(Full Penetration)**



**TiB₂ surfaced pc showing spiral
(Dual Impact – Full Penetration)**

Ceramic



**TiC pc showing spiral- blue
(No Penetration)**

Summary Comments

- The NDE Diagnostic Interrogation of Impact Damage in Armor Ceramics is a Challenging Task.
- XCT Diagnostics, Voxel Analysis, and 3D Visualization have revealed new details & insights into:
 - Impact Surface - Topography & Damage
 - Internal Residual Fragment Distribution
 - Internal Mesoscale Cracking Modes
 - Impact-created Porosity/Void Distributions
 - Volumetric (3D) Damage Perspectives
- The XCT Diagnostic approach to armor ceramic Damage Analysis & Visualization is NOT yet widely practiced.
- Further Improvements in and Benefits from this technique are possible and realistically anticipated.



**As far as the laws of mathematics refer to reality, they are not certain:
and as far as they are certain, they do not refer to reality” – A. Einstein**

