

Long Wavelength Hyperspectral Imaging Applications 12 Oct 2000

by
Raymond E. Hanna
Lockheed Martin Fairchild Systems
300 Robbins Lane
Syosset, NY 11791

12 Oct 00

TOPICS



Hyperspectral Concept Design Application

- Hyperspectral Imager (HSI) for Target Detection and Cueing
 - LWIR Spectral Band for Day/Night Operation
 - High Spectral Sensitivity (Low NESR)
 - High Spectral Fidelity (Low Optical Distortion)
- High Resolution Imager (HRI) for Image Analysis
 - High Spatial Resolution (High NIIRS Rating)
 - MWIR Spectral Band for Day/Night Operation

Hyperspectral Tactical Demonstrator System Design

Lower Cost System to Prove LWIR HSI Performance



Hyperspectral Sensor System (HSS) Concept Design

12 Oct 00

Concept Design Objective




Provide Tactical Design for LWIR Hyperspectal Application

- Hyperspectral Imager to Generate Data Cube
- High Resolution Imagery for Image Analysis
- On-Board Target Detection Processor
- Tactical Package for Airborne Platforms

Hyperspectral Application System Concept Design

12% Overlap





Pan-Scan Provides Flexible Architecture for High Ground Coverage

1.0 km Swath Width


Above 8,000 Feet AGL

Pixel HRI

HRI Chip

Target Detection and Cueing Application






Target Detection and Cueing Application

- Target Spectrum Separated from Terrain Spectrum
- LWIR Hyperspectral Sensor Provides NESR < 0.5 mFlicks for Target Automatic Detection
- High Resolution Imager Provides >NIIRS 6 Imagery for Target Visual Identification
- Image Buffer Holds HRI Imagery
- Target Detect Flag from High Speed Algorithm Processor Cues Image Buffer
- Visual Image Captured & Stored for Imager Interpreter

Hyperspectral Data Cube






12 Oct 00

LWIR NESR Demands NUC Correction






Target Detection Demands
NESR < 0.5 mFlicks


HSS Concept Design





HSI/HRI Block Diagram






HSI Optics Shares Common Telescope




- LWIR HSS shares threemirror front telescope with MWIR HRI
- Germanium beamsplitter transmits LWIR.
- Field lenses change telescope focal length from 18 inches to 7.5 inches and provide a telecentric image for the slit.
- Well-corrected F/2.0 image at slit allows modular alignment and test.
- Accessible intermediate image permits field stop stray light baffling.



HRI Optics Share Common Telescope



- LWIR and MWIR share common front telescope folded in a compact assembly.
- Three-mirror anastigmat design meets specified performance over the full field-of-view.
- Unobscurred, reflective design minimizes background radiation.
- Accessible, real exit pupil permits 100% geometric cold shielding.
- Accessible intermediate image permits field stop for stray light baffling.
- Beamsplitter separates
 MWIR (reflected) and LWIR
 (transmitted).





Hyperspectral Long Wave Imaging for the Tactical Environment (HyLITE) Tactical Demonstrator System (TDS) Design

HyLITE TDS Objectives



Demonstrate LWIR Spectrometer Performance

- Spatial Resolution
- Spectral Resolution and Data Cube Fidelity
- NESR Sensitivity

• Demonstrate Airborne Target Detection Capability


RTOP LWIR Detection Algorithms

• Store LWIR Spectrometer Field Data

- Archive for Ground Tests of Real Airborne Data
 - Post Flight Ground Testing
 - Distribute for Laboratory Testing

TDS Operational Scenario






Pushbroom Provides Simple Installation for Demonstration System

LWIR HyLITE Tactical Demonstrator System Design






TDS Packaged for Demonstration

12 Oct 00


TDS Block Diagram





TDS Internal Features






On-Board Calibration System

TDS Operator Control Interface






Rackmount PC Provides Operator Interface with TDS

TDS Optical Design





- The Front-End
 Telescope is a classic
 Three Mirror Anastigmat
 (TMA). All of the
 mirrors have standard
 null tests and are
 diamond turnable.
- A 1:1 imaging Offner type spectrometer relays the slit image to the Focal Plane.
- The grating is on the secondary mirror of the spectrometer.

TDS Spectrometer Performance




Parameter	Design
Effective Focal Length	7.50" <u>+</u> 3.0%
Aperture Diameter	3.75"
F/Number	2.0
Field-of-View	6.16 Deg
Spectral Distortion (Smile)	< 1/10 Spectral Channel
Keystone Distortion	< 1/10 Spatial Sample
Operational* Optics MTF (12.5cycles/mm) (no grating degradation)	>0.5 spatial across most of the format.
Spectral Band	7.95 um – 11.05 um
Spectral Channel	50 nm

Optics Provides Low Distortion Data Cube

TDS NESR Performance





SUMMARY



• HSS Concept Design Illustrates Tactical Package

- Hyperspectral Target Detection Cueing
- High Resolution Imagery for Image Interpreter
 - → NIIRS 6

HyLITE TDS Provides Field Test Demonstration

- Demonstrates Hyperspectral Sensor for Tactical Environment
 - Spectrometer Performance
 - Target Detection Performance
 - Growth to Tactical Package